

SEIKO

PARTS LIST FOR MODELS

CW-1, 7, 7B, 8, 8B, 8V, 8BV
LCW-7, 7B, 8, 8B, 8V, 8BV, 6F
CYLINDRICAL BED MACHINES




SEIKO SEWING MACHINE CO., LTD.
TOKYO · JAPAN


INDEX

Page

Thread take up lever, needle bar for all models	1
天秤・針棒関係	
Arm shaft, feeding mechanism for CW.LCW-7, 8 & 8V	2
CW・LCW-7、8 & 8V 上軸・送り機構関係	
Lifting lever, face plate, slide plate for all models	3
弓、面板、差し板、ベース関係	
Presser bar, lifting rock shaft, vibrating presser foot for CW.LCW-8, 8B, 8V & 8BV . . .	4
CW・LCW-8、8B、8V、& 8BV 押え棒・横軸・中押え関係	
Hook driving shaft, rotating hook, timing belt for all models	5
下軸、カム関係	
Thread tension, feed driving rock shaft, feeder, needle plate for all models	6
糸掛、糸調子、送り竿関係	
Accessories	7
附属関係	
Reverse stitch mechanism for CW.LCW-7B, 8B & 8BV	8
CW・LCW-7B・8B&8BV バック関係	
Special parts for CW.LCW-8V & 8BV	9
CW・LCW-8V&8BV 専用部品	
Presser bar, needle bar, needle plate, feeder for CW.LCW-7 & 7B	10
CW・LCW-7 & 7B 針棒・押え棒関係	
Special parts for LCW	11
LCW 専用部品	
Special parts for CW-1	12
CW-1 専用部品	
Belt guard	13
ベルトガード	
Special parts for LCW-6F	14
LCW-6F 専用部品	




Model CW-8V



Model LCW-8B


THREAD TAKE UP LEVER, NEEDLE BAR, ETC. FOR ALL MODELS EXCEPT PARTS MARKED * . O . X . Δ




Parts marked * are not necessary for CW-7 & 7B
 Parts marked O are not necessary for LCW
 Parts marked X are not necessary for CW-1
 Parts marked Δ are not necessary for LCW-6F

(* 印は CW-7、CW-7B には不要)
 (O 印は LCW タイプには不要)
 (X 印は CW-1 には不要)
 (Δ 印は LCW-6F には不要)

ARM SHAFT, FEEDING MECHANISM
FOR CW・LCW - 7, 8 & 8V




LIFTING LEVER, FACE PLATE, SLIDE PLATE FOR ALL MODELS EXCEPT PARTS MARKED ○.X.*



Parts marked * are not necessary for CW, LCW-8V & 8BV (*印は CW・LCW-8V & 8BV には不要)
 Parts marked ○ are not necessary for LCW (○印は LCW には不要)
 Parts marked X are not necessary for CW-1 (X印は CW-1 には不要)


CW・LCW-8, 8B, 8V, & 8BV 押え棒・横軸・中押え関係
 PRESSER BAR, LIFTING ROCK SHAFT, VIBRATING PRESSER
 FOR CW・LCW-8, 8B, 8V & 8BV

4



Parts marked * are not necessary for CW・LCW-8V & 8BV (*印は CW-8V, CW-8BV, LCW-8V, LCW-8BV には不要)
 Parts marked ○ are not necessary for LCW (○印は LCW には不要)

HOOK DRIVING SHAFT, ROTATING HOOK, TIMING BELT FOR ALL MODELS EXCEPT PARTS MARKED *, +, -, x, Δ



Part marked * is not necessary for CW, LCW-7B, 8B & 8BV

Part marked + is for only CW, LCW-7B, 8B & 8BV

Part marked - is not necessary for CW, LCW-8V & 8BV

Parts marked X are not necessary for CW-1

Parts marked Δ is for only LCW-6F

(*印は CW・LCW-7B、8B&8BV には不要)

(+印は CW・LCW-7B、8B&8BV にのみ)


(-印は CW・LCW-8V&8BV には不要)

(X印は CW-1 には不要)

(Δ印は LCW-6F のみ)


THREAD TENSION, FEED DRIVING ROCK SHAFT, FEEDER, NEEDLE PLATE FOR ALL MODELS EXCEPT PARTS MARKED *.+.O.X.Δ

6



Parts marked * are not necessary for CW, LCW-7, 7B, 8V & 8BV (*印は CW-LCW-7, 7B, 8V & 8BV には不要)
 Parts marked + are not necessary for CW, LCW-8V & 8BV (+印は CW-LCW-8V & 8BV には不要)
 Parts marked O are not necessary for LCW (O印は LCW には不要)
 Parts marked X are not necessary for CW-1 (X印は CW-1 には不要)
 Parts marked Δ are not necessary for LCW-6F (Δ印は LCW-6F には不要)


ACCESSORIES FOR ALL MODELS



8132



10656

6332
x 13326

10748


10780



*11969



10734




8118

8120

8121

8123
o 11193

13094




8125

8124



13096



Part marked X is used for only CW-1


Part marked O is used for only LCW

Part marked * is used for only CW . LCW-7B . 8B & 8BV

(X印は CW-1のみ)

(O印は LCWのみ)


(*印は CW, LCW-7B, 8B & 8BVのみ)



13423 A ... Use with guard A ... ガード付用


B ... Use without guard B ... ガード無用

CW・LCW-8V&8BV 専用部品
SPECIAL PARTS FOR CW・LCW-8V & 8BV




CW・LCW-7 & 7B 針棒・押え棒関係
PRESSER BAR, NEEDLE BAR, NEEDLE PLATE, FEEDER
FOR CW・LCW-7 & 7B

10



LCW 専用部品
SPECIAL PARTS FOR LCW




Parts marked * is used for only LCW-7, 7B
Parts marked + is used for only LCW-8, 8V, 8B & 8BV
Parts marked Δ is not necessary for LCW-6F

(*印は LCW-7, 7B のみ)
(+印は LCW-8, 8V, 8B & 8BV のみ)
(△印は LCW-6F には不要)

CW-1 専用部品
SPECIAL PARTS FOR CW-1


12



NOTE) 13423 A ... Use with guard B ... Use without guard 注) 13423

A ガード付用 B ガード無用

ベルトガード BELT GUARD




Parts marked ○ are not used CW, LCW-7, 8 & 8V
 Parts marked * are used for only CW, LCW-7, 8 & 8V
 Parts marked Δ are used for only LCW-6F

(○印は CW・LCW-7, 8 & 8V には不要)
 (*印は CW・LCW-7, 8 & 8V のみ)
 (Δ印は LCW-6F のみ)

LCW - 6F 専用部品
SPECIAL PARTS FOR LCW - 6F

14



注) 13613 A.....Use with guard (Aガード付用)
B.....Use without guard (Bガード無用)

