

SEIKO

PARTS LIST FOR MODELS


**CW-1, 7, 7B, 8, 8B, 8V, 8BV
LCW-7, 7B, 8, 8B, 8V, 8BV, 6F
CYLINDRICAL BED MACHINES**




**SEIKO SEWING MACHINE CO., LTD.
TOKYO · JAPAN**

INDEX

	Page
Thread take up lever, needle bar for all models	1
天秤・針棒関係	
Arm shaft, feeding mechanism for CW.LCW-7, 8 & 8V	2
CW・LCW-7, 8 & 8V 上軸・送り機構関係	
Lifting lever, face plate, slide plate for all models	3
弓、面板、差し板、ベース関係	
Presser bar, lifting rock shaft, vibrating presser foot for CW.LCW-8, 8B, 8V & 8BV . . .	4
CW・LCW-8, 8B, 8V, & 8BV 押え棒・横軸・中押え関係	
Hook driving shaft, rotating hook, timing belt for all models	5
下軸、カマ関係	
Thread tension, feed driving rock shaft, feeder, needle plate for all models	6
糸掛、糸調子、送り竿関係	
Accessories	7
附属関係	
Reverse stitch mechanism for CW.LCW-7B, 8B & 8BV	8
CW・LCW-7B・8B&8BV バック関係	
Special parts for CW.LCW-8V & 8BV	9
CW・LCW-8V&8BV 専用部品	
Presser bar, needle bar, needle plate, feeder for CW.LCW-7 & 7B	10
CW・LCW-7 & 7B 針棒・押え棒関係	
Special parts for LCW	11
LCW 専用部品	
Special parts for CW-1	12
CW-1 専用部品	
Belt guard	13
ベルトガード	
Special parts for LCW-6F	14
LCW-6F 専用部品	
Feed mechanism for LCW-8B	15
LCW-8B 送り関係	




Model CW-8V




Model LCW-8B

THREAD TAKE UP LEVER, NEEDLE BAR, ETC. FOR ALL MODELS EXCEPT PARTS MARKED * . O . X . Δ



Parts marked * are not necessary for CW-7 & 7B
 Parts marked O are not necessary for LCW
 Parts marked X are not necessary for CW-1
 Parts marked Δ are not necessary for LCW-6F

(*印は CW-7, CW-7B には不要)
 (O印は LCW タイプには不要)
 (X印は CW-1 には不要)
 (Δ印は LCW-6F には不要)



LIFTING LEVER, FACE PLATE, SLIDE PLATE FOR ALL MODELS EXCEPT PARTS MARKED O.X.*

 10712

13056-A



13059



O 10707

10706



10705



13079A

O 10699




O 10704

O 10703

XO 10702



XO 10698




O 10700

13440
37100

13440

37100

13005

13004
13436


13027



13026



X13009



13024



13025



13027



13089

13438 882
13383

19403



13006



13388-A



13008


Parts marked * are not necessary for CW.LCW-8V & 8BV (*印は CW・LCW-8V&8BV には不要)

Parts marked O are not necessary for LCW (O印は LCW には不要)

Parts marked X are not necessary for CW-1 (X印は CW-1 には不要)


CW・LCW-8, 8B, 8V, & 8BV 押え棒・横軸・中押え関係
 PRESSER BAR, LIFTING ROCK SHAFT, VIBRATING PRESSER
 FOR CW・LCW-8, 8B, 8V & 8BV

4



Parts marked * are not necessary for CW・LCW-8V & 8BV (*印は CW-8V, CW-8BV, LCW-8V, LCW-8BV には不要)
 Parts marked ○ are not necessary for LCW (○印は LCW には不要)


HOOK DRIVING SHAFT, ROTATING HOOK, TIMING BELT FOR ALL MODELS EXCEPT PARTS MARKED *. +. -. X. Δ




Part marked * is not necessary for CW, LCW-7B, 8B & 8BV
 Part marked + is for only CW, LCW-7B, 8B & 8BV
 Part marked - is not necessary for CW, LCW-8V & 8BV
 Parts marked X are not necessary for CW-1
 Parts marked Δ is for only LCW-6F

(*印は CW・LCW-7B, 8B & 8BV には不要)
 (+印は CW・LCW-7B, 8B & 8BV にのみ)
 (-印は CW・LCW-8V & 8BV には不要)
 (X印は CW-1 には不要)
 (Δ印は LCW-6F のみ)

THREAD TENSION, FEED DRIVING ROCK SHAFT, FEEDER, NEEDLE PLATE FOR ALL MODELS EXCEPT PARTS MARKED * . + . ○ . X . △




Parts marked * are not necessary for CW, LCW-7, 7B, 8V & 8BV (*印は CW・LCW-7, 7B, 8V & 8BV には不要)
 Parts marked + are not necessary for CW, LCW-8V & 8BV (+印は CW・LCW-8V & 8BV には不要)
 Parts marked ○ are not necessary for LCW (○印は LCW には不要)
 Parts marked X are not necessary for CW-1 (X印は CW-1 には不要)
 Parts marked △ are not necessary for LCW-6F (△印は LCW-6F には不要)



8132A


10656

N0122
X-N0618

N0118




10748



35254

10734



8118C


*11969

11487



8123


O 11193



10709




8124



13094



13096



Part marked X is used for only CW-1

Part marked O is used for only LCW

Part marked * is used for only CW, LCW-7B, 8B & 8BV


(X印は CW-1のみ)

(O印は LCWのみ)

(*印は CW, LCW-7B, 8B&8BVのみ)

CW・LCW-7B・8B&8BV バック関係
 REVERSE STITCH MECHANISM FOR
 CW・LCW-7B, 8B & CW-8BV

8



13423-B A ... Use with guard A ... ガード付用
 B ... Use without guard B ... ガード無用

13246



13249



13234



13235



11823




8086-02



13240



13221C



10561



13235



13218



13217



12128C



13219




2067



13243



13216



13256

13252



13212



13213



2067



13207



13208



13209



2067



13253




13206



10545



13204



8111



10659



13383



13263


11830




13261



13264




13260




CW・LCW-7 & 7B 針棒・押え棒関係
 PRESSER BAR, NEEDLE BAR, NEEDLE PLATE, FEEDER
 FOR CW・LCW-7 & 7B

10



LCW 専用部品

SPECIAL PARTS FOR LCW



Parts marked * is used for only LCW-7, 7B

Parts marked + is used for only LCW-8, 8V, 8B & 8BV

Parts marked Δ is not necessary for LCW-6F


(*印は LCW-7, 7B のみ)

(+印は LCW-8, 8V, 8B & 8BV のみ)

(Δ印は LCW-6F には不要)


CW-1 専用部品
SPECIAL PARTS FOR CW-1

12



NOTE) 13423 A ... Use with guard B ... Use without guard (注) 13423

A ガード付用
B ガード無用




Parts marked ○ are not used CW, LCW-7, 8 & 8V.
 Parts marked * are used for only CW, LCW-7, 8 & 8V
 Parts marked Δ are used for only LCW-6F

(○印は CW・LCW-7、8 & 8V には不要)
 (*印は CW・LCW-7、8 & 8V のみ)
 (Δ印は LCW-6F のみ)

LCW - 6F 専用部品
SPECIAL PARTS FOR LCW - 6F

14



注) 13613 A.....Use with guard (A ガード付用)
B.....Use without guard (B ガード無用)

LCW-8B 送り関係

FEED MECHANISM FOR LCW - 8B

