


The logo features the word "SINGER" in a bold, black, sans-serif font, with "96K" in a smaller, black, sans-serif font directly below it. This text is centered within a light gray oval frame. A large, light gray "CSMP" watermark is superimposed horizontally across the middle of the oval.


SINGER
96K

CSMP

ILLUSTRATED
LIST OF PARTS
FOR
CLASS 96K MACHINES







No. 96K10 Machine.







No. 96K16 Machine.



THE SINGER MANUFACTURING CO.























































































127046 52464




52415




127045



52418




127014




127047



97502




52047



204296

52046

86546



86539





PLATE 7699—FULL SIZE

24443



12436



12438




PLATE 7701—FULL SIZE




PLATE 7703—FULL SIZE




PLATE 7704—FULL SIZE





PLATE 7708—ONE-HALF SIZE



CONTENTS.

ILLUSTRATED LIST OF PARTS FOR CLASS 96K MACHINES

Parts, special, to No. 96K3 Machine- Obsolete	...	...	...	...	...	...	...	...	Page 105
Parts, complete, for 96K10 Machine	...	...	...	...	...	...	...	...	69
" " " 96K12	"	...	...	...	...	...	...	...	77
" " " 96K13	"	...	...	...	...	...	...	...	84
" " " 96K14	"	...	...	...	...	...	...	...	94
" " " 96K16	"	...	...	...	...	...	...	...	99
Accessories	...	...	...	...	...	...	...	...	106
Attachments	...	...	...	...	...	...	...	...	109
Bobbin Winders	...	...	...	...	...	...	...	...	107
Iron Base	...	...	...	...	...	...	...	...	106
Knee Lifter	...	...	...	...	...	...	...	...	118
Numerical List of Parts	...	...	...	...	...	...	...	...	121
Tape Holder	...	...	...	...	...	...	...	...	119
Thread Unwinder	...	...	...	...	...	...	...	...	119

No.	Plate								
56101	1323	Arm Shaft (upright) Gear (upper) with two 1253c	...	...					
1253c	1325	" " (") " (") Set Screw	...	...					
56015	1323	" " (") Oil Tube (lower)	...	...					
56015	1323	" " (") " " (upper)	...	...					
12480	1313	" Side Cap	...	...	...	...	...	...	...
219d	1324	Arm Side Cap Screw	...	...	...	...	...	...	...
12193	1313	" " Cover	...	...	...	...	...	...	...
50053d	1325	" " " Thumb Screw	...	...	...	...	...	...	...
12403	1498	" Spool Pin	...	...	...	...	...	...	...
41591	1314	Arm Top Cover Tension Bracket with 460c	...	...					
24131	1498	" " " " " Oil Tube with 52045	...	...					
52045	1498	" " " " " " " Packing (cotton wick)	...	...					
180d	1515	" " " " " " Screw	...	...	...	...	...	...	...
12403	1498	" " " " " " Spool Pin	...	...					
8879	1316	" " " " " " " Washer (cloth)	...	...					
2455	1498	" " " " " " Disc	...	...	...	...	...	...	...
41593	1316	" " " " " " Spring	...	...	...	...	...	...	...
41594	1316	" " " " " " Stud	...	...	...	...	...	...	...
460c	1324	" " " " " " Set Screw	...	...	...	...	...	...	...
41595	1316	" " " " " " Thread Guide	...	...	...	...	...	...	...
41592	1314	Arm Top Cover Tension Bracket , complete, Nos. 12403, 24131, 41591, 41593 to 41595 and two 2455	...	...	...	...	...	...	...
52005	1313	Balance Wheel (power) light rim, 2 $\frac{3}{16}$ " pulley, with two 448c	...	...					
52081	---	" " (stand) heavy rim, 2 $\frac{11}{16}$ " pulley, with two 448c	...	...					
52063	1497	" " Oil Cover	...	...	...	...	...	...	...
210d	1324	" " " " " Screw	...	...	...	...	...	...	...
448c	1324	" " " Set Screw	...	...	...	...	...	...	...
*52383	---	Bed	...	...	...	...	...	...	...

NOTE. Due to the accuracy required for Gear alignment, Bed cannot be supplied separately and can only be sent out as a unit, Arm and Bed assembled.

12431	---	Bed Slide	...	...	...	...	...	...	...
12432	1313	" " complete, Nos. 4307, 12431 and two 725c	...	...					
4307	1497	" " Spring	...	...	...	...	...	...	...
725c	1324	" " " Screw	...	...	...	...	...	...	...
52051	---	Face Plate	...	...	...	...	...	...	...
190d	1324	" " Screw	...	...	...	...	...	...	...
52053	1323	" " Thread Guard (lower)	...	...	...	...	...	...	...
226d	1324	" " " " (") Screw	...	...	...	...	...	...	...
56086	1323	" " " " (upper)	...	...	...	...	...	...	...
226d	1324	" " " " (") Screw	...	...	...	...	...	...	...
50190d	1325	" " " Thumb Screw	...	...	...	...	...	...	...
52052	1313	Face Plate , complete, Nos. 52051, 52053, 56086 and two 226d	...	...	...	...	...	...	...

No.	Plate								
52452	1313	Feed Bar	...	...	...	...	...	...	...
313c	1324	" " Screw Centre (2)	...	...	...	...	...	...	...
1519c	1325	" " " " Nut (2)	...	...	...	...	...	...	...
3033	1498	" Connecting Link	...	...	...	...	...	...	...
375c	1324	" " " Hinge Screw	...	...	...	...	...	...	...
1518c	1325	" " " " " Nut	...	...	...	...	...	...	...
52073	1498	" " " " Stud	...	...	...	...	...	...	...
50083c	1325	" " " " " Set Screw	...	...	...	...	...	...	...
44136	1510	Feed Dog for tailor work	...	...	...	...	...	...	...
12369	1506	" " " " Cloth, 12 teeth (12 teeth to the inch)	...	...					
12457	1506	" " " " " 16 " (16 " " " ")	...	...					
12370	1506	" " " " " 15 " (16 " " " ")	...	...					
12125	1506	" " " " " "	...	...	...	...	...	...	...
12450	1507	" " " " " 11 teeth (18 teeth to the inch)	...	...					
20348	1507	" " " " Chilton, 22 teeth (36 teeth to the inch)	...	...					
20106	1507	" " " " Cloth	...	...	...	...	...	...	...
20119	1507	" " " " heavy work on duck, overalls, etc.	...	...					
20158	1508	" " " " Shirt work 17 teeth (16 teeth to the inch)	...	...					
20151	1509	" " " " " Bevelled for Hemmer, 13 teeth (14 teeth to the inch)	...	...					
20117	1509	" " " " " " " " 16 teeth (16 teeth to the inch)	...	...					
20138	1509	" " " " " " " " 13 teeth (12 teeth to the inch)	...	...					
20162	1509	" " " " " " " " 17 teeth (16 teeth to the inch)	...	...					
20147	1508	" " " 12 teeth (14 teeth to the inch)	...	...	...	...	...	...	...
12481	1508	" " " for general work, 18 teeth (16 teeth to the inch)	...	...					
50117c	1325	" " " Screw (2)	...	...	...	...	...	...	...

NOTE. Feed Dog No. 44136 is sent with this machine unless otherwise specified on order.

127014	1813	Feed and Feed Lifting Eccentric with 448c and 1299c	...	...					
1299c	1515	" " " " " " Position Screw	...	...					
448c	1324	" " " " " " Set Screw	...	...					
24036	1497	" " " " " " Sleeve	...	...	...	...	...	...	...
20284	1501	" Forked Connection	...	...	...	...	...	...	...
375c	1324	" " " " Hinge Screw	...	...	...	...	...	...	...
1518c	1325	" " " " " Nut	...	...	...	...	...	...	...
52384	1500	Feed Lifting Rock Shaft	...	...	...	...	...	...	...
12430	1497	" " " " " Connecting Rod (steel) with 12204 and two 966c	...	...					
*12204	---	" " " " " " Cap	...	...					
966c	1325	" " " " " " Screw	...	...	...	...	...	...	...
375c	1324	" " " " " " Hinge Screw	...	...					
1518c	1325	" " " " " " Nut	...	...					

No.	Plate								
12376	1498	Feed Lifting Rock Shaft Crank with 157c and 1813 ...							
157c	1324	"	"	"	"	"	Clamping Screw	...	...
1813	1498	"	"	"	"	"	Roller and Stud	...	...
50191c	1325	"	"	"	"	"	Screw Centre (2)	...	...
1513j	1317	"	"	"	"	"	Nut (2)	...	...
52385	---	Feed Lifting Rock Shaft, complete, Nos. 12376 and 52384 ...							
52074	1323	Feed Regulator with 50083c ...							
1128e	1325	"	"	"	"	"	Hinge Screw	...	...
818d	1325	"	"	"	"	"	Thumb Screw	...	...
52359	1512	"	"	"	"	"	Stop	...	...
<i>NOTE: No. 52359 is only supplied when specified on order.</i>									
52386	1500	Feed Rock Shaft ...							
29633	1498	"	"	"	"	"	Crank with 157c	...	...
157c	1324	"	"	"	"	"	Clamping Screw	...	...
50191c	1325	"	"	"	"	"	Screw Centre (2)	...	...
1513j	1317	"	"	"	"	"	Nut (2)	...	...
52387	---	Feed Rock Shaft, complete, Nos. 29633 and 52386 ...							
25866	1512	Guide ...							
50190b	1325	"	"	"	"	"	Thumb Screw	...	...
52455	1505	Needle Bar (hollow) ...							
52305	1504	"	"	"	"	"	Bushing (lower) with 29532	...	...
1133c	1515	"	"	"	"	"	(") Set Screw	...	...
52044	1505	"	"	"	"	"	(upper)	...	...
1133e	1515	"	"	"	"	"	(") Set Screw	...	...
21040	1505	"	"	"	"	"	Connecting Link with 794c	...	...
21894	---	"	"	"	"	"	21040 with 21041	...	...
794c	1515	"	"	"	"	"	Adjusting Screw	...	...
775e	1515	"	"	"	"	"	Cap Screw	...	...
21041	1505	"	"	"	"	"	Stud with 207c	...	...
207c	558	"	"	"	"	"	Clamping Screw	...	...
21052	1505	"	"	"	"	"	Crank with 858c, 1063c, 1037c and 1063c	...	...
1063c	1325	"	"	"	"	"	Position Screw	...	...
858c	1325	"	"	"	"	"	Set Screw	...	...
29532	1498	"	"	"	"	"	Oil Cup	...	...
52306	1505	"	"	"	"	"	Thread Guard	...	...
229d	1515	"	"	"	"	"	" Screw	...	...
52307	1505	"	"	"	"	"	Clamp with 808f	...	...
808f	1515	"	"	"	"	"	Screw	...	...
12391	1497	Presser Bar (hollow) ...							
52338	1316	"	"	"	"	"	Guide Bracket with 223c and 453c	...	...
453c	1316	"	"	"	"	"	Set Screw	...	...
52016	1316	"	"	"	"	"	Lifter	...	...
689c	1316	"	"	"	"	"	Screw	...	...

No.	Plate								
1529r	1317	Presser Bar Lifter Screw Nut ...							
12327	1316	"	"	"	"	"	Lifting and Releasing Lever Bracket	...	...
11167	1497	"	"	"	"	"	Spring	...	...
11170	1316	"	"	"	"	"	Washer	...	...
20458	1511	Presser Foot for 11136 ...							
12143	972	"	"	"	"	"	12369, 12457 and 20406	...	...
12335	1511	"	"	"	"	"	(narrow) for 12369, 12457 and 20406	...	...
12258	1511	"	"	"	"	"	(wide) for 12369, 12457 and 20406	...	...
12142	1511	"	"	"	"	"	for 12370	...	...
12259	1511	"	"	"	"	"	12425	...	...
12144	972	"	"	"	"	"	20417, 20438, 20447, 20451, 20458 and 20467	...	...
12260	972	"	"	"	"	"	12450, 20447 and 20448	...	...
12174	1511	"	"	"	"	"	20438 and 20462	...	...
20342	1511	"	"	"	"	"	12450 and 20348	...	...
20343	1511	"	"	"	"	"	with guide on bottom to the right of needle plate, for 12569, 12450, 12457 and 20348	...	...
12261	972	"	"	"	"	"	for 12481	...	...
62527	---	Presser Foot Hinge Pin ...							
24544	---	"	"	"	"	"	Plate	...	...
24982	---	"	"	"	"	"	Shank	...	...
26231	1498	"	"	"	"	"	Spring	...	...
24983	1511	Presser Foot (crane, longed), complete, Nos. 24544, 24982, 26231 and 62527, for 12425 and 20449							
7298	1498	"	"	"	"	"	Hinge Pin	...	...
19334	---	"	"	"	"	"	Plate	...	...
19335	---	"	"	"	"	"	Shank	...	...
19336	1511	Presser Foot (hinged), complete, Nos. 7298, 19334 and 19335, for 12370							
7298	1498	"	"	"	"	"	Hinge Pin	...	...
20268	---	"	"	"	"	"	Plate	...	...
20269	---	"	"	"	"	"	Shank	...	...
20270	1511	Presser Foot (hinged), complete, No. 7298, 20268 and 20269 for 12369, 12457 and 20406							
2532	1498	"	"	"	"	"	Hinge Pin	...	...
20310	---	"	"	"	"	"	Plate	...	...
19223	---	"	"	"	"	"	Shank	...	...
20311	1511	Presser Foot (hinged), complete, No. 2532, 19223 and 20310, for 20417, 20438, 20447, 20451, 20458 and 20462							
2532	1498	"	"	"	"	"	Hinge Pin	...	...
20344	---	"	"	"	"	"	Plate	...	...
20345	---	"	"	"	"	"	Shank	...	...
26231	1498	"	"	"	"	"	Spring	...	...

No.	Plate								
20346	1511	Presser Foot (spring, hinged), complete, Nos. 2532, 20344, 20345 and 26231, for 20117, 20138, 20147, 20151, 20158 and 20162							
190d	1324	"	"	Screw	...	...	...	...	...
<i>NOTE: Presser Foot No. 20158 is sent with this machine unless otherwise specified on order.</i>									
688j	1324	Pressure Regulating Thumb Screw							
52121	1499	Rotating Hook							
52123	-	"	"	52121 with 52090 and four 1053e	...	...	...	...	...
52089	1499	"	"	52123 " 40274, three each 1253e and 1367d	...	...	...	...	...
52478	-	"	"	52089 " 52474	...	...	...	...	...
40264	1499	"	"	Bobbin	...	...	...	...	...
52472	1499	Rotating Hook Bobbin Case							
52481	-	"	"	" " 52472 with 591f, 1380d and 40394	...	...	...	...	...
40392	1499	"	"	" " Latch	...	...	...	...	...
40409	1499	"	"	" " " Lever	...	...	...	...	...
2974	1499	"	"	" " " Fulcrum Pin	...	...	...	...	...
2975	1499	"	"	" " " Spring	...	...	...	...	...
592e	1324	"	"	" " " Stop Screw	...	...	...	...	...
40393	-	"	"	" " Hinge, Nos. 2974, 40392 and 40409	...	...	...	...	...
591f	1324	"	"	" " Tension Regulating Screw	...	...	...	...	...
40394	1499	"	"	" " " Spring	...	...	...	...	...
1380d	1325	"	"	" " " " Screw	...	...	...	...	...
52473	-	"	"	" " complete, Nos. 592e, 2975, 40393 and 52481	...	...	...	...	...
52474	-	"	"	" " 52473 with 52477	...	...	...	...	...
52477	1499	"	"	" " Holder with 52475 and two 52476	...	...	...	...	...
52018	1498	"	"	" " " Position Bracket	...	...	...	...	...
704j	1324	"	"	" " " " " Screw	...	...	...	...	...
*52175	-	"	"	" " " " " Locating Plate	...	...	...	...	...
*52476	-	"	"	" " " " " Rivet	...	...	...	...	...
40274	1499	"	"	Section	...	...	...	...	...
1367d	1325	"	"	" " Screw	...	...	...	...	...
1253e	1325	"	"	" " Set Screw	...	...	...	...	...
52388	1501	"	"	" " Shaft	...	...	...	...	...
56106	1323	"	"	" " Bushing (back)	...	...	...	...	...
52045	1498	"	"	" " " (") Packing (cotton)	...	...	...	...	...
1143e	1325	"	"	" " " (") Set Screw	...	...	...	...	...
56107	1323	"	"	" " " (front)	...	...	...	...	...
52045	1498	"	"	" " " (") Packing (cotton)	...	...	...	...	...
1148e	1325	"	"	" " " (") Set Screw	...	...	...	...	...
54897	1323	"	"	" " Front Bearing Oil Cup	...	...	...	...	...
56013	1323	"	"	" " Gear with two 1253e	...	...	...	...	...
52072	1313	"	"	" " Case (two pieces) with 121e and 50234d	...	...	...	...	...

No.	Plate								
50234d	1325	Rotating Hook Shaft Gear Case Plug Screw							
121e	1324	"	"	" " " " " Screw	...	...	...	...	...
1253e	1325	"	"	" " " " " Set Screw	...	...	...	...	...
52090	1499	"	"	" " Thread Guard	...	...	...	...	...
1053e	1325	"	"	" " " " " Screw	...	...	...	...	...
52337	1316	Slack Thread Regulator							
223e	1316	"	"	" " " " " Set Screw	...	...	...	...	...
2102	1498	Tension Disc							
1560e	1325	"	"	" " Regulating Thumb Nut	...	...	...	...	...
32572	1498	"	"	" " Releasing Disc	...	...	...	...	...
43944	1316	"	"	" " " Lever	...	...	...	...	...
12398	1316	"	"	" " " " " Hinge Pin	...	...	...	...	...
12329	1316	"	"	" " " " " Spring	...	...	...	...	...
32574	1498	"	"	" " " " " Pin	...	...	...	...	...
50304e	1498	"	"	" " Screw Stud	...	...	...	...	...
50305e	1325	"	"	" " " " " Set Screw	...	...	...	...	...
2103	1505	"	"	" " Spring	...	...	...	...	...
52397	—	Tension , complete, Nos. 1560e, 2103, 32572, 32574, 50304e, 52083, 52394 and two 2102							
52027	1498	Thread Guard (side of arm)							
52454	1323	"	"	" " Retainer	...	...	...	...	...
624e	1515	"	"	" " " " " Set Screw	...	...	...	...	...
52054	—	Thread Take-up , complete, Nos. 11204, 52025 and 52143							
52024	1505	Thread Take-up Crank							
52143	-	"	"	" " " " 52024 with 775e and 24894	...	...	...	...	...
1037e	1515	"	"	" " " " " Position Screw	...	...	...	...	...
1036e	1515	"	"	" " " " " Set Screw	...	...	...	...	...
52022	1503	Thread Take-up Lever with 52130							
52023	1505	"	"	" " " " " Hinge Pin	...	...	...	...	...
52024	1505	"	"	" " " " " Link	...	...	...	...	...
11204	1505	"	"	" " " " " Hinge Pin	...	...	...	...	...
435e	1324	"	"	" " " " " " " Set Screw	...	...	...	...	...
52130	-	"	"	" " " " " Thread Eyelet Bushing	...	...	...	...	...
52025	—	Thread Take-up Lever , complete, Nos. 52022 to 52024							
52394	1505	Thread Take-up Spring							
52083	1498	"	"	" " " " " Regulator with 50305e	...	...	...	...	...
448e	1324	"	"	" " " " " " " Set Screw	...	...	...	...	...

No.	Plate								
41137	1510	Throat Plate , large needle hole, for 41136							
41138		"	"	small	"	"	"	41136	
12411	1506	"	"	large	"	"	"	12369 and 12457	
12449		"	"	small	"	"	"	12369 " 12457	
12412	1506	"	"	large	"	"	"	12370	
12426	1506	"	"	"	"	"	"	12425	
12466		"	"	small	"	"	"	12425	
12464	1507	"	"	large	"	"	"	12450 and 20348	
12451		"	"	small	"	"	"	12450 " 20348	
20315		"	"	large	"	"	"	20106	
20107	1507	"	"	small	"	"	"	20106	
20120	1507	"	"	large oblong needle hole, for 20119					
20187		"	"	small	"	"	"	20119	
19497	1509	"	"	large needle hole, for 20117					
19405		"	"	small	"	"	"	20117	
19409		"	"	large	"	"	"	20438 and 20462	
19410	1509	"	"	small	"	"	"	20438 " 20462	
19415	1509	"	"	large	"	"	"	20451	
19416		"	"	small	"	"	"	20451	
19418	1508	"	"	large	"	"	"	20458	
19419		"	"	small	"	"	"	20458	
19412	1508	"	"	large	"	"	"	20447	
19413		"	"	small	"	"	"	20447	
12482		"	"	large	"	"	"	12481	
12483	1508	"	"	small	"	"	"	12481	
691f	1324	"	"	Screw (2)					

NOTE. Throat Plate No. 41137 is sent with this machine unless otherwise specified on order.

*15404		Trade Mark							
15405		" " Rivet							
41212		Drip Pan with four Wood Screws 1" No. 5							

PARTS COMPLETE FOR No. 96K12 MACHINE

**For Cloaks, Clothing, Overalls and other work in Cloth
Has reversible Feed Mechanism.**

No.	Plate										
*52432		Arm with 15401, two each 15405 and 56015									
<i>NOTE. Due to the accuracy required for Gear alignment, Arm cannot be supplied separately and can only be sent out as a unit, Arm and Bed assembled.</i>											
16532	1498	Arm Dowel Pin (2)									
24431	1498	"	Oil Tube with 52045 for oiling 24036								
52084	1323	"	"	"	"	52045	"	"	24040		
11119	1512	"	"	"	"	52045	"	"	52022		
12454	1498	"	"	"	"	52045	"	"	52024		
52148		"	"	"	"	...	...	...	...		
52149		"	"	"	"	52148 with 52150	...	...	...		
52150		"	"	"	"	Packing (braided cotton)					
52045	1498	"	"	"	"	Packing (cotton wick)					
1116	1324	"	Screw (back) (2)					...	...		
854e	1515	"	"	(front) (2)					...	...	
52382	1500	Arm Shaft (horizontal)								...	...
127062		"	"	(	"	)	52382 with 24036, 24052, 52060 and 127018, for 52005 and 52081				
52400	1528	"	"	(	"	)	...	...	...		
127061		"	"	(	"	)	52400 with 24036, 24052, 52060 and 127018, for 52403				
52059	1497	"	"	(	"	)	Flanged Bushing (back) for 52005 and 52081				
52401	1529	"	"	(	"	)	"	"	(") Oil Pad		
52045	1498	"	"	(	"	)	"	"	(") Oil Pad (cotton wick)		
148c	1324	"	"	(	"	)	"	"	(") Set Screw		
52078	1497	"	"	(	"	)	"	"	(front)		
52045	1498	"	"	(	"	)	"	"	(") Oil Pad (cotton wick)		
135c	1324	"	"	(	"	)	"	"	(") Set Screw		
54897	1323	"	"	(	"	)	Front Bearing Oil Cup				
52060	1323	"	"	(	"	)	Gear with two 1036c				
52151	1313	"	"	(	"	)	"	Case (two pieces) with 121c			
121c	1324	"	"	(	"	)	"	"	Screw		
1036c	1515	"	"	(	"	)	"	Set Screw			
144d	1324	"	"	(	"	)	Screw				

No.	Plate								
52062	1497	Arm Shaft (upright)							
56099	1323	"	"	("	")	Bushing (lower)	...	...	...
432c	1324	"	"	("	")	"	("	")	Set Screw
56100	1323	"	"	("	")	"	(upper)	...	...
1149c	1325	"	"	("	")	"	("	")	Set Screw
56013	1323	"	"	("	")	Gear (lower) with two 1253c	...	...	...
1253c	1325	"	"	("	")	"	("	")	Set Screw
56101	1323	"	"	("	")	"	(upper) with two 1253c	...	...
1253c	1325	"	"	("	")	"	("	")	Set Screw
56015	1323	"	"	("	")	Oil Tube (lower)	...	...	...
56015	1323	"	"	("	")	"	(upper)	...	...
12480	1313	"	Side Cap	...	...	...	...	...	...
219d	1324	"	"	"	Screw	...	...	...	...
12193	1313	"	"	Cover	...	...	...	...	...
50053d	1325	"	"	"	Thumb Screw	...	...	...	...
12403	1498	"	Spool Pin	...	...	...	...	...	...
41591	1314	Arm Top Cover Tension Bracket with 460c							
24131	1498	"	"	"	"	"	Oil Tube with 52045	...	...
52045	1498	"	"	"	"	"	"	Packing (cotton wick)	...
180d	1515	"	"	"	"	"	"	Screw	...
12403	1498	"	"	"	"	"	"	Spool Pin	...
8879	1316	"	"	"	"	"	"	(Washer (cloth)	...
2455	1498	"	"	"	"	"	"	Disc	...
41593	1316	"	"	"	"	"	"	Spring	...
41594	1316	"	"	"	"	"	"	Stud	...
460c	1324	"	"	"	"	"	"	Set Screw	...
41595	1316	"	"	"	"	"	"	Thread Guide	...
41592	1314	Arm Top Cover Tension Bracket , complete, Nos. 12403, 24131, 41591, 41593 to 41595 and two 2455							
52005	1313	Balance Wheel (power) light rim, 2 $\frac{1}{16}$ " pulley, with two 448c for 127062							
52081	—	"	"	(stand)	heavy rim, 2 $\frac{1}{16}$ " pulley, with two 448c for 127062	...	...	...	...
56017	1528	"	"	2 $\frac{1}{4}$ " pulley, for 52405	...	...	...	...	...
52063	1497	"	"	Oil Cover	...	...	...	...	...
210d	1324	"	"	"	Screw	...	...	...	...
448c	1324	"	"	"	Set Screw	...	...	...	...
*52402	—	Bed							

NOTE.—Due to the accuracy required for Gear alignment, Bed cannot be supplied separately and can only be sent out as a unit, Arm and Bed assembled.

No.	Plate								
12431	—	Bed Slide							
12432	1313	"	"	complete, Nos. 4307, 12431 and two 725c	...	...	...	...	...
4307	1497	"	"	Spring	...	...	...	...	...
725c	1324	"	"	"	Screw	...	...	...	...
256j	1515	Clamp Stop Motion Clamp Screw							
248a	1515	"	"	"	"	Stop Screw	...	...	...
2020	1512	"	"	"	"	Washer	...	...	...
*52403	—	Clamp Stop Motion Flanged Bushing							
52404	1529	"	"	"	"	"	52403 with two 50311c	...	...
2022	1512	"	"	"	"	"	Pin	...	...
50311c	1515	"	"	"	"	"	Set Screw	...	...
52405	—	Clamp Stop Motion , complete, Nos. 248a, 256j, 2020 and 52404							
52051	—	Face Plate							
190d	1324	"	"	"	Screw	...	...	...	...
52053	1323	"	"	"	Thread Guard (lower)	...	...	...	...
226d	1324	"	"	"	"	("	")	Screw	...
56086	1323	"	"	"	"	(upper)	...	...	...
226d	1324	"	"	"	"	("	")	Screw	...
50190d	1325	"	"	"	Thumb Screw	...	...	...	...
52052	1313	Face Plate , complete, Nos. 52051, 52053, 56086 and two 226d							
52452	1313	Feed Bar							
313c	1324	"	"	"	Screw Centre (2)	...	...	...	...
1519c	1325	"	"	"	"	Nut (2)	...	...	...
3033	1498	"	"	"	Connecting Link	...	...	...	...
375c	1324	"	"	"	"	Hinge Screw	...	...	...
1518c	1325	"	"	"	"	"	Nut	...	...
52073	1498	"	"	"	"	"	Stud	...	...
50083c	1325	"	"	"	"	"	"	Set Screw	...
26603	1529	Feed Dog							
28360	1529	"	"	"	(15 conical teeth)	...	...	...	...
120001	1502	"	"	"	(spiked teeth)	...	...	...	...
50117c	1325	"	"	"	"	Screw (2)	...	...	...
NOTE.—Feed Dog No. 26603 is sent with this machine unless otherwise specified on order.									
127018	1503	Feed and Feed Lifting Eccentric with two 448c							
448c	1324	"	"	"	"	"	"	Set Screw	...
24036	1497	"	"	"	"	"	"	Sleeve	...
52407	1501	"	"	"	"	Forked Connection	...	...	...
375c	1324	"	"	"	"	"	"	Hinge Screw	...
1518c	1325	"	"	"	"	"	"	"	Nut

No.	Plate								
52384	1500	Feed Lifting Rock Shaft							
12430	1497	"	"	"	"	Connecting Rod (steel) with 12204 and two 966e			
*12204	---	"	"	"	"	"	"	Cap	...
966e	1325	"	"	"	"	"	"	"	Screw
375e	1324	"	"	"	"	"	"	"	Hinge Screw
1518e	1325	"	"	"	"	"	"	"	Nut
12376	1498	"	"	"	"	Crank with 157e and 1813			...
157e	1324	"	"	"	"	"	"	"	Clamping Screw
1813	1498	"	"	"	"	"	"	"	Roller and Stud
50191e	1325	"	"	"	"	Screw Centre (2)	...	...	...
1513j	1317	"	"	"	"	"	"	"	Nut (2)
52385	---	Feed Lifting Rock Shaft, complete, Nos. 12376 and 52384 ...							
50338e	1515	Feed Regulating Screw Stud							
56032	1502	"	"	"	"	Head with 56033			...
50193j	1515	"	"	"	"	"	"	"	Cap Screw
56033	1504	"	"	"	"	"	"	"	Stop Pin
56034	1592	"	"	"	"	"	"	"	Lock Pin
56035	1502	"	"	"	"	"	"	"	Spring
52408	1592	Feed Regulator with 50083e							
1128e	1325	"	"	"	"	"	"	"	Hinge Screw
52409	1502	Feed Reverse Lever with 158e and 51846							
50339d	1515	"	"	"	"	"	"	"	Hinge Screw
158e	1324	"	"	"	"	"	"	"	Clamping Screw
52410	1502	"	"	"	"	"	"	"	Friction Washer
51846	1515	"	"	"	"	"	"	"	Roller and Stud
52386	1500	Feed Rock Shaft							
29633	1498	"	"	"	"	Crank with 157e			...
157e	1324	"	"	"	"	"	"	"	Clamping Screw
50191e	1325	"	"	"	"	"	"	"	Screw Centre (2)
1513j	1317	"	"	"	"	"	"	"	Nut (2)
52387	---	Feed Rock Shaft, complete, Nos. 29633 and 52386 ...							
25866	1512	Guide							
50190b	1325	"	"	"	"	"	"	"	Thumb Screw
52455	1505	Needle Bar (hollow)							
52305	1504	"	"	"	"	Bushing (lower) with 29532			...
1133e	1515	"	"	"	"	(")	"	"	Set Screw
52014	1505	"	"	"	"	(upper)			...
1133e	1515	"	"	"	"	(")	"	"	Set Screw
24040	1505	"	"	"	"	Connecting Link with 794e			...
24894	---	"	"	"	"	"	"	"	24040 with 24041

No.	Plate								
794e	1515	Needle Bar Connecting Link Adjusting Screw							
775e	1515	"	"	"	"	"	"	"	Cap Screw
24041	1505	"	"	"	"	"	"	"	Stud with 207e
207e	558	"	"	"	"	"	"	"	Clamping Screw
24052	1505	"	"	"	"	Crank with 858e, 1036e, 1037e and 1065e			...
1065e	1325	"	"	"	"	"	"	"	Position Screw
858e	1325	"	"	"	"	"	"	"	Set Screw
29532	1498	"	"	"	"	"	"	"	Oil Cup
52306	1505	"	"	"	"	"	"	"	Thread Guard
229d	1515	"	"	"	"	"	"	"	Screw
52307	1505	"	"	"	"	Clamp with 808f			...
808f	1515	"	"	"	"	"	"	"	Screw
12391	1497	Presser Bar (hollow)							
52338	1316	"	"	"	"	Guide Bracket with 223e and 453e			...
453e	1316	"	"	"	"	"	"	"	Set Screw
52016	1316	"	"	"	"	"	"	"	Lifter
689c	1316	"	"	"	"	"	"	"	Screw
1520r	1317	"	"	"	"	"	"	"	Nut
12327	1316	"	"	"	"	"	"	"	Lifting and Releasing Lever Bracket
11167	1497	"	"	"	"	"	"	"	Spring
11170	1316	"	"	"	"	"	"	"	Washer
62527	---	Presser Foot Hinge Pin							
52426	---	"	"	"	"	"	"	"	Plate
52390	---	"	"	"	"	"	"	"	Shank
26231	1498	"	"	"	"	"	"	"	Spring
52427	1529	Presser Foot (spring, hinged), complete, Nos. 26231, 52390, 52426 and 62527 ...							
190d	1324	"	"	"	"	"	"	"	Screw
688j	1324	Pressure Regulating Thumb Screw							
52121	1499	Rotating Hook							
52123	---	"	"	"	"	52121 with 52090 and four 1053e			...
52089	1499	"	"	"	"	52123 with 40274, three each 1253e and 1367d			...
52478	---	"	"	"	"	52089 with 52474			...
40264	1499	"	"	"	"	"	"	"	Bobbin
52472	1499	"	"	"	"	"	"	"	Case
52481	---	"	"	"	"	"	"	"	52472 with 591f, 1380d and 40394
40392	1499	"	"	"	"	"	"	"	Latch
40409	1499	"	"	"	"	"	"	"	Lever
2974	1499	"	"	"	"	"	"	"	Fulcrum Pin
2975	1499	"	"	"	"	"	"	"	Spring
592e	1324	"	"	"	"	"	"	"	Stop Screw
40393	---	"	"	"	"	"	"	"	Hinge Nos. 2974, 40392 and 40409

No.	Plate								
591f	1324	Rotating Hook	Bobbin Case Tension Regulating Screw	...	...	...	...	...	...
40394	1499	"	"	"	"	"	Spring	...	...
1380d	1325	"	"	"	"	"	"	Screw	...
52473	---	"	"	"	"	"	complete, Nos. 592e, 2975, 40393 and 52481	...	...
52474	---	"	"	"	"	"	52473 with 52477	...	...
52477	1499	"	"	"	"	"	Holder with 52475 and two 52476	...	...
52018	1498	"	"	"	"	"	Position Bracket	...	...
704j	1324	"	"	"	"	"	"	Screw	...
*52475	---	"	"	"	"	"	Locating Plate	...	...
*52476	---	"	"	"	"	"	"	Rivet	...
40274	1499	"	"	"	"	"	Section	...	...
1367d	1325	"	"	"	"	"	Screw	...	...
1253c	1325	"	"	"	"	"	Set Screw	...	...
52388	1504	"	"	"	"	"	Shaft	...	...
56106	1323	"	"	"	"	"	Bushing (back)	...	...
52045	1498	"	"	"	"	"	(") Packing (cotton)	...	...
1443c	1325	"	"	"	"	"	(") Set Screw	...	...
56107	1323	"	"	"	"	"	(front)	...	...
52045	1498	"	"	"	"	"	(") Packing (cotton)	...	...
1448c	1325	"	"	"	"	"	(") Set Screw	...	...
54897	1323	"	"	"	"	"	Front Bearing Oil Cup	...	...
56013	1323	"	"	"	"	"	Gear with two 1253c	...	...
52072	1313	"	"	"	"	"	Case (two pieces) with 121e and 50234d	...	...
50234d	1325	"	"	"	"	"	Plug Screw	...	...
121e	1324	"	"	"	"	"	Screw	...	...
1253c	1325	"	"	"	"	"	Set Screw	...	...
52090	1499	"	"	"	"	"	Thread Guard	...	...
1053c	1325	"	"	"	"	"	Screw	...	...
52337	1316	Slack Thread Regulator	...	...	...	...	...	...	...
223c	1316	"	"	"	"	"	Set Screw	...	...
2102	1498	Tension Disc	...	...	...	...	...	...	...
1560c	1325	"	"	"	"	"	Regulating Thumb Nut	...	...
32572	1498	"	"	"	"	"	Releasing Disc	...	...
43944	1316	"	"	"	"	"	Lever	...	...
12398	1316	"	"	"	"	"	Hinge Pin	...	...
12329	1316	"	"	"	"	"	Spring	...	...
32574	1498	"	"	"	"	"	Pin	...	...
50304c	1498	"	"	"	"	"	Screw Stud	...	...
50305c	1325	"	"	"	"	"	Set Screw	...	...
2103	1505	"	"	"	"	"	Spring	...	...
52397	---	Tension , complete, Nos. 1560c, 2103, 32572, 32574, 50304c, 52083, 52394 and two 2102	...	...	...	...	...	...	...

No.	Plate								
52027	1498	Thread Guard (Side of Arm)	...	...	...	...	...	...	...
52154	1323	"	Retainer	...	...	...	...	...	...
624c	1515	"	"	Set Screw	...	...	...	...	...
52054	---	Thread Take-up , complete, Nos. 41204, 52025 and 52143	...	...	...	...	...	...	...
52024	1505	Thread Take-up Crank	...	...	...	...	...	...	...
52143	---	"	"	"	52024 with 775e and 24894	...	...	...	...
1037c	1515	"	"	"	Position Screw	...	...	...	...
1036c	1515	"	"	"	Set Screw	...	...	...	...
52022	1503	Thread Take-up Lever with 52130	...	...	...	...	...	...	...
52023	1505	"	"	"	Hinge Pin	...	...	...	...
52024	1505	"	"	"	Link	...	...	...	...
41204	1505	"	"	"	"	Hinge Pin	...	...	...
435c	1324	Thread Take-up Lever Link Hinge Pin Set Screw	...	...	...	...	...	...	...
52130	---	"	"	"	Thread Eyelet Bushing	...	...	...	...
52025	---	Thread Take-up Lever , complete, Nos. 52022 to 52024	...	...	...	...	...	...	...
52394	1505	Thread Take-up Spring	...	...	...	...	...	...	...
52083	1498	"	"	"	Regulator with 50305c	...	...	...	...
418c	1324	"	"	"	"	Set Screw	...	...	...
20356	1529	Throat Plate , large needle hole, for 26603, 28360 and 120004	...	...	...	...	...	...	...
20357	---	"	"	"	small " " " 26603, 28360 and 120004	...	...	...	...
691f	1324	"	"	"	Screw (2)	...	...	...	...
<i>NOTE: Throat Plate No. 20356 is sent with this machine unless otherwise specified on order.</i>									
245404	---	Trade Mark	...	...	...	...	...	...	...
45405	---	"	"	"	Rivet	...	...	...	...
44212	---	Drip Pan with four Wood Screws $\frac{1}{2}$ " No. 5	...	...	...	...	...	...	...

No.	Plate								
52052	1313	Face Plate , complete, Nos. 52051, 52053, 56086 and two 226d ...							
52152	1313	Feed Bar ...							
313c	1324	"	"	Screw	Centre (2)	...	...	...	...
1519e	1325	"	"	"	"	Nut (2)	...	...	...
3033	1498	"	"	Connecting Link	...	...	...	...	...
375e	1324	"	"	"	"	Hinge Screw	...	...	...
1518e	1325	"	"	"	"	"	Nut	...	...
52073	1498	"	"	"	"	"	Stud	...	...
50083c	1325	"	"	"	"	"	"	Set Screw	...
12436	7699	Feed Dog ...							
50117c	1325	"	"	Screw (2)	...	...	...	...	...
127014	1813	Feed and Feed Lifting Eccentric with 148c and 1299c ...							
1299c	1515	"	"	"	"	"	"	Position Screw	...
148c	1324	"	"	"	"	"	"	Set Screw	...
24036	1497	"	"	"	"	"	"	Sleeve	...
20284	1501	"	"	Forked Connection	...	...	...	...	...
375c	1324	"	"	"	"	"	"	Hinge Screw	...
1518e	1325	"	"	"	"	"	"	"	Nut
52384	1500	Feed Lifting Rock Shaft ...							
12430	1497	"	"	"	"	"	"	Connecting Rod (teeth) with 12204 and two 966e	...
*12204	-	"	"	"	"	"	"	"	Cap
966e	1325	"	"	"	"	"	"	"	Screw
375e	1324	"	"	"	"	"	"	"	Hinge Screw
1518e	1325	"	"	"	"	"	"	"	"
12376	1498	"	"	"	"	"	"	Crank with 157c and 1813	...
157c	1324	"	"	"	"	"	"	"	Clamping Screw
1813	1498	"	"	"	"	"	"	"	Roller and Stud
50191c	1325	"	"	"	"	"	"	"	Screw Centre (2)
1513j	1317	"	"	"	"	"	"	"	"
52385	-	Feed Lifting Rock Shaft , complete, Nos. 12376 and 52384 ...							
52071	1323	Feed Regulator with 50083c ...							
1128c	1325	"	"	"	"	"	"	"	Hinge Screw
818d	1325	"	"	"	"	"	"	"	Thumb Screw
52359	1512	"	"	"	"	"	"	"	Stop
52386	1500	Feed Rock Shaft ...							
29633	1498	"	"	"	"	"	"	"	Crank with 157c
157c	1324	"	"	"	"	"	"	"	Clamping Screw
50191c	1325	"	"	"	"	"	"	"	Screw Centre (2)
1513j	1317	"	"	"	"	"	"	"	"
52387	-	Feed Rock Shaft , complete, Nos. 29633 and 52386 ...							

No.	Plate								
25866	1512	Guide ...							
50190b	1325	"	"	Thumb Screw	...	...	...	...	...
52155	1505	Needle Bar (hollow) ...							
52305	1504	"	"	"	"	Bushing (lower) with 29532	...	...	...
1133c	1515	"	"	"	"	"	"	"	Set Screw
52014	1505	"	"	"	"	"	"	"	(upper)
1133c	1515	"	"	"	"	"	"	"	"
24040	1505	"	"	"	"	"	"	"	Connecting Link with 791c
24894	1515	"	"	"	"	"	"	"	24040 with 24041
791c	1515	"	"	"	"	"	"	"	Adjusting Screw
775c	1515	"	"	"	"	"	"	"	Cap Screw
24041	1505	"	"	"	"	"	"	"	Stud with 297c
207c	558	"	"	"	"	"	"	"	Clamping Screw
24052	1505	"	"	"	"	"	"	"	Crank with 858c, 1036c, 1037c and 1065c
1065c	1325	"	"	"	"	"	"	"	Position Screw
858c	1325	"	"	"	"	"	"	"	Set Screw
29532	1498	"	"	"	"	"	"	"	Oil Cup
127015	1813	"	"	"	"	"	"	"	Thread Guard
229d	1515	"	"	"	"	"	"	"	"
127016	1813	"	"	"	"	"	"	"	Clamp with 808f
808f	1515	"	"	"	"	"	"	"	Screw
12391	1497	Presser Bar (hollow) ...							
52338	1316	"	"	"	"	"	"	"	Guide Bracket with 223c and 453c
453c	1316	"	"	"	"	"	"	"	Set Screw
52016	1316	"	"	"	"	"	"	"	Lifter
689c	1316	"	"	"	"	"	"	"	Screw
1520c	1317	"	"	"	"	"	"	"	"
12327	1316	"	"	"	"	"	"	"	Lifting and Releasing Lever Bracket
11167	1497	"	"	"	"	"	"	"	Spring
11170	1316	"	"	"	"	"	"	"	Washer
688j	1324	Pressure Regulating Thumb Screw ...							
1896	7701	Roller , $\frac{1}{8}$ " diam., fine, with 386d and 1528d, for 12265 ...							
31824	1812	"	"	$\frac{3}{16}$ " diam., coarse, with 388d and 1530h, for 52457	...	...	...	...	...
4986	1812	"	"	$\frac{1}{4}$ " diam., fine, with 652d and 1528d, for 52461	...	...	...	...	...
12256	7701	Roller Arm for 12265 ...							
52456	1812	"	"	"	"	"	"	"	52457
52460	1812	"	"	"	"	"	"	"	52461
4409	7701	"	"	"	"	"	"	"	Adjusting Screw
1547j	1325	"	"	"	"	"	"	"	Nut
2206	7701	"	"	"	"	"	"	"	Bracket
316f	1324	"	"	"	"	"	"	"	Screw Centre
1547j	1325	"	"	"	"	"	"	"	"

No.	Plate								
2205	7701	Roller Arm Lock Spring	...	...	...	...	...	...	...
176d	559	" " " " Screw	...	...	...	...	...	...	...
1549j	7701	" " " " Nut	...	...	...	...	...	...	...
12265	7701	Roller Presser , complete, $\frac{7}{8}$ ", fine roller, Nos. 176d, 140f, 1549j, 1896, 2205, 2206, 12256, two 316f and three 1547j	...	...	...	...	...	...	...
52457	---	Roller Presser , complete, $\frac{9}{16}$ ", coarse roller, Nos. 176d, 140f, 1549j, 2205, 2206, 51824, 52456, two 316f and three 1547j	...	...	...	...	...	...	...
52461	1812	Roller Presser , complete, $\frac{7}{8}$ ", fine roller, Nos. 176d, 140f, 1549j, 1986, 2205, 2206, 52460, two 316f and three 1547j	...	...	...	...	...	...	...
190d	1324	Roller Presser Screw	...	...	...	...	...	...	...
386d	7701	" Screw for 1896	...	...	...	...	...	...	...
388d	1515	" " " 51824	...	...	...	...	...	...	...
652d	7701	" " " 1986	...	...	...	...	...	...	...
1528d	7701	Roller Screw Nut for 1896 and 1986	...	...	...	...	...	...	...
1550h	1688	" " " " 51824	...	...	...	...	...	...	...
52121	1499	Rotating Hook	...	...	...	...	...	...	...
52123	"	" " 52121 with 52090 and four 1053e	...	...	...	...	...	...	...
52089	1499	" " " 52123 " 40274, three each 1253e and 1367d	...	...	...	...	...	...	...
52478	"	" " " 52089 " 52474	...	...	...	...	...	...	...
40264	1499	" " Bobbin	...	...	...	...	...	...	...
52472	1499	" " " Case	...	...	...	...	...	...	...
52481	---	" " " " 52472 with 591f, 1380d and 40394	...	...	...	...	...	...	...
40392	1499	" " " " Latch	...	...	...	...	...	...	...
40409	1499	" " " " Lever	...	...	...	...	...	...	...
2974	1499	" " " " Fulcrum Pin	...	...	...	...	...	...	...
2975	1499	" " " " Spring	...	...	...	...	...	...	...
592e	1324	" " " " Stop Screw	...	...	...	...	...	...	...
40393	"	" " " " Hinge, Nos. 2974, 40392 and 40409	...	...	...	...	...	...	...
591f	1324	" " " " Tension Regulating Screw	...	...	...	...	...	...	...
40394	1499	" " " " Spring	...	...	...	...	...	...	...
1380d	1325	" " " " Screw	...	...	...	...	...	...	...
52473	"	" " " " complete, Nos. 592e, 2975, 40393 and 52481	...	...	...	...	...	...	...
52474	---	" " " " 52473 with 52477	...	...	...	...	...	...	...
52477	1499	" " " " Holder with 52475 and two 52476	...	...	...	...	...	...	...
52018	1498	" " " " Position Bracket	...	...	...	...	...	...	...
704j	1324	" " " " " Screw	...	...	...	...	...	...	...
*52475	---	" " " " Locating Plate	...	...	...	...	...	...	...
*52476	---	" " " " " Rivet	...	...	...	...	...	...	...
40274	1499	" " Section	...	...	...	...	...	...	...
1367d	1325	" " " Screw	...	...	...	...	...	...	...

No.	Plate								
1253e	1325	Rotating Hook Set Screw	...	...	...	...	...	...	...
52388	1501	" " Shaft	...	...	...	...	...	...	...
56106	1323	" " " Bushing (back)	...	...	...	...	...	...	...
52045	1498	" " " " (") Packing (cotton)	...	...	...	...	...	...	...
1143e	1325	" " " " (") Set Screw	...	...	...	...	...	...	...
56107	1323	" " " " (front)	...	...	...	...	...	...	...
52045	1498	" " " " (") Packing (cotton)	...	...	...	...	...	...	...
1148e	1325	" " " " (") Set Screw	...	...	...	...	...	...	...
51897	1323	" " " Front Bearing Oil Cup	...	...	...	...	...	...	...
56043	1323	" " " Gear with two 1253e	...	...	...	...	...	...	...
52072	1313	" " " " Case (two pieces) with 121e and 50234d	...	...	...	...	...	...	...
50234d	1325	" " " " " Plug Screw	...	...	...	...	...	...	...
121e	1324	" " " " " Screw	...	...	...	...	...	...	...
1253e	1325	" " " " " Set Screw	...	...	...	...	...	...	...
52090	1499	" " " Thread Guard	...	...	...	...	...	...	...
1053e	1325	" " " " Screw	...	...	...	...	...	...	...
52337	1316	Slack Thread Regulator	...	...	...	...	...	...	...
223e	1316	" " " " Set Screw	...	...	...	...	...	...	...
52046	1815	Spool Holder Base	...	...	...	...	...	...	...
389d	1515	" " " " Screw	...	...	...	...	...	...	...
204296	1815	" " " " Wire	...	...	...	...	...	...	...
200079b	1515	" " " " Hinge Screw	...	...	...	...	...	...	...
52047	1815	Spool Holder , complete, Nos. 52046, 200079b and 204296	...	...	...	...	...	...	...
2102	1498	Tension Disc	...	...	...	...	...	...	...
1560e	1325	" Regulating Thumb Nut	...	...	...	...	...	...	...
32572	1498	" Releasing Disc	...	...	...	...	...	...	...
43944	1316	" " Lever	...	...	...	...	...	...	...
12398	1316	" " " Hinge Pin	...	...	...	...	...	...	...
12329	1316	" " " Spring	...	...	...	...	...	...	...
32574	1498	" " " Pin	...	...	...	...	...	...	...
50304e	1498	" Screw Stud	...	...	...	...	...	...	...
50305e	1325	" " " Set Screw	...	...	...	...	...	...	...
2403	1505	" Spring	...	...	...	...	...	...	...
52397	---	Tension , complete, Nos. 1560e, 2403, 32572, 32574, 50304e, 52083, 52394 and two 2102	...	...	...	...	...	...	...
52027	1498	Thread Guard (Side of Arm)	...	...	...	...	...	...	...
52454	1323	" Retainer	...	...	...	...	...	...	...
624e	1515	" " Set Screw	...	...	...	...	...	...	...
52054	-	Thread Take-up , complete, Nos. 11204, 52025 and 52143	...	...	...	...	...	...	...

No.	Plate						
52021	1505	Thread Take-up Crank					
52143		"	"	"	52021, with 775e and 24891	...	...
1037c	1515	"	"	"	Position Screw	...	...
1036c	1515	"	"	"	Set Screw	...	...
52022	1503	Thread Take-up Lever with 52430					
52023	1505	"	"	"	Hinge Pin	...	...
52024	1505	"	"	"	Link	...	...
11204	1505	"	"	"	" Hinge Pin	...	...
435c	1324	"	"	"	" " " Set Screw	...	...
52130	-	"	"	"	Thread Eyelet Bushing	...	...
52025	-	Thread Take-up Lever , complete, Nos. 52022 to 52024					
52394	1505	Thread Take-up Spring					
52083	1498	"	"	"	Regulator with 50305c	...	...
448c	1324	"	"	"	" Set Screw	...	...
24444	-	Throat Plate , large oblong needle hole					
24443	7699	"	"	"	small oblong needle hole	...	...
691f	1324	"	"	"	Screw (2)	...	...
<i>NOTE: Throat Plate No. 24444 is sent with this machine unless otherwise specified on order.</i>							
*15404		Trade Mark					
15405		"	"	"	Rivet	...	...
44212	-	Drip Pan with four Wood Screws $\frac{1}{2}$ " No. 5					

PARTS COMPLETE FOR No. 96K14 MACHINE

For Stitching Top Facings to Shee Lining, also for Side and Back Stays.
Drop Feed.

No.	Plate							
*52446	-	Arm with 15404, two each 45405 and 56015						
<i>NOTE: Due to the accuracy required for Gear alignment, Arm cannot be supplied separately and can only be sent out as a unit, Arm and Bed assembled.</i>								
16532	1498	Arm Dowel Pin (2)		...	...	...	...	...
24431	1498	"	"	Oil Tube with 52045 for oiling 24036	...	...	...	...
52084	1323	"	"	"	52045	"	"	24040
11119	1512	"	"	"	52045	"	"	52022
12454	1498	"	"	"	52045	"	"	52024
52148	-	"	"	"	...	...	...	...
52149	-	"	"	"	52148 with 52150	...	...	...
52150	-	"	"	"	Packing (braided cotton)	...	...	...
52045	1498	"	"	"	Packing (cotton wick)	...	...	...
116c	1324	"	"	Screw (back) (2)	...	...	...	...
854c	1515	"	"	(front) (2)	...	...	...	...
127047	1815	Arm Shaft (horizontal)		...	...	...	...	...
127048	-	"	"	(")	127047 with 24036, 24052, 52060 and 127044	...	...	...
52050	1497	"	"	(")	Flanged Bushing (back)	...	...	...
52045	1498	"	"	(")	"	"	(")	Oil Pad
								(cotton wick)
448c	1324	"	"	(")	"	"	(")	Set Screw
52078	1497	"	"	(")	"	"	(front)	...
52045	1498	"	"	(")	"	"	(")	Oil Pad
								(cotton wick)
435c	1324	"	"	(")	"	"	(")	Set Screw
54897	1323	"	"	(")	Front Bearing Oil Cup	...	...	...
52060	1323	"	"	(")	Gear with two 1036c	...	...	...
52151	1313	"	"	(")	"	Case (two pieces) with 1246	...	...
1246	1324	"	"	(")	"	"	Screw	...
1036c	1515	"	"	(")	"	Set Screw	...	...
1440	1324	"	"	(")	Screw	...	...	...
52062	1497	"	"	(upright)	...	...	...	...
56099	1323	"	"	(")	Bushing (lower)	...	...	...
432c	1324	"	"	(")	"	(")	Set Screw	...
56100	1323	"	"	(")	"	(upper)	...	...
1449c	1325	"	"	(")	"	(")	Set Screw	...

No.	Plate									
56013	1323	Arm Shaft (upright) Gear (lower) with two 1253c						...	...	
1253c	1325	"	"	(")	"	(")	Set Screw	...	...	
56101	1323	"	"	(")	"	(upper)	with two 1253c	...	...	
1253c	1325	"	"	(")	"	(")	Set Screw	...	...	
56015	1323	"	"	(")	Oil Tube (lower)	...	...	...	...	
56015	1323	"	"	(")	"	"	(upper)	...	...	
12180	1313	"	Side Cap	...	...	...	...	...	...	
219d	1324	"	"	"	Screw	...	...	...	...	
12193	1313	"	"	Cover	...	...	...	...	...	
50053d	1325	"	"	"	Thumb Screw	...	...	...	...	
12403	1498	"	Spool Pin	...	...	...	...	...	...	
41591	1314	Arm Top Cover Tension Bracket with 460c						...	...	
24131	1498	"	"	"	"	"	Oil Tube with 52015	...	...	
52015	1498	"	"	"	"	"	"	Packing (cotton wick)	...	
180d	1515	"	"	"	"	"	Screw	...	...	
12403	1498	"	"	"	"	"	Spool Pin	...	...	
8879	1316	"	"	"	"	"	"	Washer (cloth)	...	
2455	1498	"	"	"	"	"	Disc	...	...	
41593	1316	"	"	"	"	"	Spring	...	...	
41594	1316	"	"	"	"	"	Stud	...	...	
460c	1324	"	"	"	"	"	Set Screw	...	...	
41595	1316	"	"	"	"	"	Thread Guide	...	...	
41592	1314	Arm Top Cover Tension Bracket , complete, Nos. 12403, 24131, 41591, 41593 to 41595 and two 2455						...	...	
52005	1313	Balance Wheel (power) light rim, $2\frac{3}{16}$ " pulley, with two 448c								...
52081	---	"	"	(stand) heavy rim, $2\frac{15}{16}$ " pulley, with two 448c	...	...	...	...	...	
52063	1497	"	"	Oil Cover	...	...	...	...	...	
210d	1324	"	"	"	"	Screw	...	...	...	
448c	1324	"	"	Set Screw	...	...	...	...	...	
*52383		Bed	...	...	...	...	...	...	...	
<i>NOTE. -Due to the accuracy required for Gear alignment, Bed cannot be supplied separately and can only be sent out as a unit, Arm and Bed assembled.</i>										
52417	-	Bed Slide	...	...	...	...	...	...	...	
52418	1813	"	"	complete, Nos. 52417, 52464 and two 665c	...	...	...	...	...	
52464	1813	"	"	Spring	...	...	...	...	...	
665c	1515	"	"	"	Screw	...	...	...	...	
120063	7703	Edge Guide	...	...	...	...	...	...	...	
50190b	1325	"	"	Thumb Screw	...	...	...	...	...	
52051	-	Face Plate	...	...	...	...	...	...	...	
190d	1324	"	"	Screw	...	...	...	...	...	

No.	Plate								
52053	1323	Face Plate Thread Guard (lower)							
226d	1324	"	"	"	"	(")	Screw	...	...
56086	1323	"	"	"	"	(upper)	...	...	...
226d	1324	"	"	"	"	(")	Screw	...	...
50190d	1325	"	"	"	Thumb Screw	...	...	...	...
52052	1313	Face Plate , complete, Nos. 52051, 52053, 56086 and two 226d ...							
52452	1313	Feed Bar							
313c	1324	"	"	"	Screw Centre (2)	...	...	...	...
1519c	1325	"	"	"	"	Nut (2)	...	...	...
3033	1498	"	"	"	Connecting Link	...	...	...	...
375c	1324	"	"	"	"	Hinge Screw	...	...	...
1518c	1325	"	"	"	"	"	Nut	...	...
52073	1498	"	"	"	"	Stud	...	...	...
50083c	1325	"	"	"	"	"	Set Screw	...	...
12436	7699	Feed Dog							
50117c	1325	"	"	"	Screw (2)	...	...	...	...
127014	1813	Feed and Feed Lifting Eccentric with 448c and 1299c ...							
1299c	1515	"	"	"	"	"	Position Screw	...	...
448c	1324	"	"	"	"	"	Set Screw	...	...
24036	1497	"	"	"	"	"	Sleeve	...	...
20284	1501	"	"	"	"	Forked Connection	...	...	...
375c	1324	"	"	"	"	"	Hinge Screw	...	...
1518c	1325	"	"	"	"	"	Nut	...	...
52384	1500	Feed Lifting Rock Shaft							
12430	1497	"	"	"	"	"	Connecting Rod (steel) with 12204 and two 966e	...	...
*12204	---	"	"	"	"	"	"	Cap	...
966e	1325	"	"	"	"	"	"	"	Screw
375c	1324	"	"	"	"	"	"	"	Hinge Screw
1518c	1325	"	"	"	"	"	"	"	Nut
12376	1498	"	"	"	"	"	Crank with 157c and 1813	...	...
157c	1324	"	"	"	"	"	Clamping Screw	...	...
1813	1498	"	"	"	"	"	"	Roller and Stud	...
50191c	1325	"	"	"	"	"	Screw Centre (2)	...	...
1513j	1317	"	"	"	"	"	"	Nut (2)	...
52385		Feed Lifting Rock Shaft , complete, Nos. 12376 and 52384 ...							
52074	1323	Feed Regulator with 50083c							
1128c	1325	"	"	"	"	"	Hinge Screw	...	...
818d	1325	"	"	"	"	"	Thumb Screw	...	...
52359	1512	"	"	"	"	"	Stop	...	...

No.	Plate								
52386	1500	Feed Rock Shaft							
29633	1498	"	"	"	Crank with 157c	...	...	...	...
157c	1324	"	"	"	"	Clamping Screw	...	...	...
50191c	1325	"	"	"	"	Screw Centre (2)	...	...	...
1513j	1317	"	"	"	"	"	Nut (2)	...	...
52387	-	Feed Rock Shaft, complete, Nos. 29633 and 52386							
52455	1505	Needle Bar (hollow)							
52305	1504	"	"	"	Bushing (lower) with 29532	...	...	...	...
1133c	1515	"	"	"	"	(") Set Screw	...	...	...
52014	1505	"	"	"	"	(upper)	...	...	...
1133c	1515	"	"	"	"	(") Set Screw	...	...	...
24040	1505	"	"	"	"	Connecting Link with 794c	...	...	...
24894	-	"	"	"	"	24040 with 24041	...	...	...
794c	1515	"	"	"	"	Adjusting Screw	...	...	...
775c	1515	"	"	"	"	Cap Screw	...	...	...
24041	1505	"	"	"	"	Stud with 207c	...	...	...
207c	558	"	"	"	"	Clamping Screw	...	...	...
24052	1505	"	"	"	"	Crank with 858c, 1036c, 1037c and 1065c	...	...	...
1065c	1325	"	"	"	"	Position Screw	...	...	...
858c	1325	"	"	"	"	Set Screw	...	...	...
29532	1498	"	"	"	"	Oil Cup	...	...	...
52415	1813	"	"	"	"	Thread Guard	...	...	...
229d	1515	"	"	"	"	Screw	...	...	...
52307	1505	"	"	"	"	Clamp with 808f	...	...	...
808f	1515	"	"	"	"	Screw	...	...	...
12391	1497	Presser Bar (hollow)							
52338	1316	"	"	"	"	Guide Bracket with 223c and 453c	...	...	...
453c	1316	"	"	"	"	Set Screw	...	...	...
52016	1316	"	"	"	"	Lifter	...	...	...
689c	1316	"	"	"	"	Screw	...	...	...
1520r	1317	"	"	"	"	"	Nut	...	...
12327	1316	"	"	"	"	Lifting and Releasing Lever Bracket	...	...	...
11167	1497	"	"	"	"	Spring	...	...	...
11170	1316	"	"	"	"	Washer	...	...	...
688j	1324	Pressure Regulating Thumb Screw							
51841	1812	Roller, 1 1/2" diam., coarse, for 51842							
51842	-	"	"	"	"	(ball-bearing), Nos. 1528j, 1766c, 50553c, 51841 and twenty-four 16232	...	...	...
1903	7701	"	"	"	"	1 1/2" diam., coarse, with 652d and 1528d, for 52414	...	...	...
51824	1812	"	"	"	"	3/16" diam., coarse, with 388d and 1550h, for 52457	...	...	...
1886	1812	"	"	"	"	1 1/2" diam., coarse, with 386d and 1528d, for 52458	...	...	...
1986	1812	"	"	"	"	3/8" diam., fine, with 652d and 1528d, for 52461	...	...	...

No.	Plate								
52453	7701	Roller Arm for 52414 and 52458							
52456	1812	"	"	"	"	52457	...	...	...
52460	1812	"	"	"	"	52461	...	...	...
127041	1812	"	"	"	"	127042	...	...	...
440f	7701	"	"	"	"	Adjusting Screw	...	...	...
1547j	1325	"	"	"	"	"	Nut	...	...
1282	7701	"	"	"	"	Bracket for 52414 and 52458	...	...	...
2206	7701	"	"	"	"	"	52457 and 52461	...	...
46037	-	"	"	"	"	"	127042	...	...
316f	1324	"	"	"	"	"	Screw Centre	...	...
1547j	1325	"	"	"	"	"	"	Nut	...
2205	7701	"	"	"	"	"	Lock Spring	...	...
176d	559	"	"	"	"	"	Screw	...	...
1549j	7701	"	"	"	"	"	"	Nut	...
16232	-	"	"	"	"	"	Ball 3/8" diam.	...	...
1766c	1812	"	"	"	"	"	Retaining Nut	...	...
1528j	7701	"	"	"	"	"	Lock Nut	...	...
52414	7701	Roller Presser, complete, 1 1/2" coarse roller, Nos. 176d, 440f, 1549j, 1903, 2205, 1282, 52453, two 316f and three 1547j							
52457	-	Roller Presser, complete, 3/8" coarse roller, Nos. 176d, 440f, 1549j, 2205, 2206, 51824, 52456, two 316f and three 1547j							
52458	1812	Roller Presser, complete, 1 1/2" coarse roller, Nos. 176d, 440f, 1549j, 1886, 2205, 1282, 52453, two 316f and three 1547j							
52461	1812	Roller Presser, complete, 3/4" fine roller, Nos. 176d, 440f, 1549j, 1986, 2205, 2206, 52460, two 316f and three 1547j							
127042	1812	Roller Presser (ball-bearing), complete, 1 1/2" coarse roller, Nos. 176d, 440f, 1549j, 2205, 46037, 51842, 127041, two 316f and three 1547j							
490d	1324	Roller Presser Screw							
386d	7701	"	"	"	"	"	Screw for 1886	...	...
388d	1515	"	"	"	"	"	51824	...	...
652d	7701	"	"	"	"	"	1903 and 1986	...	...
50553c	1515	"	"	"	"	"	51842	...	...
1528d	7701	"	"	"	"	"	Nut for 1886, 1903 and 1986	...	...
1550b	1688	"	"	"	"	"	51824	...	...
52421	1499	Rotating Hook							
52423	-	"	"	"	"	"	52421 with 52090 and four 1053c	...	...
52089	1499	"	"	"	"	"	52423 with 40274, three each 1253c and 1367d	...	...
52478	-	"	"	"	"	"	52089 with 52474	...	...
40264	1499	"	"	"	"	"	Robbin	...	...

No.	Plate								
52472	1499	Rotating Hook Bobbin Case							
52481	---	"	"	"	"	52472 with 5911, 1380d and 40394	...	...	...
40392	1499	"	"	"	"	Latch	...	...	...
40409	1499	"	"	"	"	" Lever	...	...	...
2974	1499	"	"	"	"	" Fulcrum Pin	...	...	...
2975	1499	"	"	"	"	" Spring	...	...	...
592e	1324	"	"	"	"	" Stop Screw	...	...	...
40393	---	"	"	"	"	Hinge, Nos. 2974, 40392 and 40409	...	...	...
591f	1324	"	"	"	"	Tension Regulating Screw	...	...	...
40394	1499	"	"	"	"	" Spring	...	...	...
1380d	1325	"	"	"	"	" Screw	...	...	...
52473	---	"	"	"	"	complete, Nos. 592e, 2975, 4-393 and 52481	...	...	...
52474	---	"	"	"	"	52473 with 52477	...	...	...
52477	1499	"	"	"	"	Holder with 52475 and two 52476	...	...	...
52018	1498	"	"	"	"	" Position Bracket	...	...	...
704j	1324	"	"	"	"	" " " Screw	...	...	...
*52475	---	"	"	"	"	Locating Plate	...	...	...
*52476	---	"	"	"	"	" " " Rivet	...	...	...
40274	1499	"	"	"	"	Section	...	...	...
1367d	1325	"	"	"	"	" Screw	...	...	...
1253e	1325	"	"	"	"	Set Screw	...	...	...
52388	1501	"	"	"	"	Shaft	...	...	...
56106	1323	"	"	"	"	Bushing (back)	...	...	...
52045	1498	"	"	"	"	(") Packing (cotton)	...	...	...
1143e	1325	"	"	"	"	(") Set Screw	...	...	...
56107	1323	"	"	"	"	(front)	...	...	...
52045	1498	"	"	"	"	(") Packing (cotton)	...	...	...
1148e	1325	"	"	"	"	(") Set Screw	...	...	...
54897	1323	"	"	"	"	Front Bearing Oil Cup	...	...	...
56013	1323	"	"	"	"	Gear with two 1253e	...	...	...
52072	1313	"	"	"	"	Case (two pieces) with 121e and 50234d	...	...	...
50234d	1325	"	"	"	"	" Plug Screw	...	...	...
121e	1324	"	"	"	"	" Screw	...	...	...
1253e	1325	"	"	"	"	Set Screw	...	...	...
52090	1499	"	"	"	"	Thread Guard	...	...	...
1053e	1325	"	"	"	"	" Screw	...	...	...
52337	1316	Slack Thread Regulator							
223e	1316	"	"	"	"	Set Screw	...	...	...
52046	1815	Spool Holder Base							
389d	1515	"	"	"	"	" Screw	...	...	...
204296	1815	"	"	"	"	" Wire	...	...	...
200079h	1515	"	"	"	"	" Hinge Screw	...	...	...
52047	1815	Spool Holder , complete, Nos. 52046, 200079h and 204296							

No.	Plate								
120067	7704	Strip Guide							
120068	7704	"	"	"	"	(adjustable) with 291f	...	...	...
120069	7704	"	"	"	"	(") Bar	...	...	...
120070	7704	"	"	"	"	(") " Plate	...	...	...
50169d	7704	"	"	"	"	(") " " Screw	...	...	...
50169d	7704	"	"	"	"	(") " " Screw	...	...	...
291f	7704	"	"	"	"	(") Thumb Screw	...	...	...
120071	7704	Strip Guide (adjustable), complete, Nos. 120067 to 120070 and six 50169d							
1423d	7704	Strip Guide Screw							
2102	1498	Tension Disc							
1560e	1325	"	"	"	"	Regulating Thumb Nut	...	...	...
32572	1498	"	"	"	"	Releasing Disc	...	...	...
4394f	1316	"	"	"	"	" Lever	...	...	...
12398	1316	"	"	"	"	" " Hinge Pin	...	...	...
12329	1316	"	"	"	"	" " Spring	...	...	...
32574	1498	"	"	"	"	" Pin	...	...	...
50304e	1498	"	"	"	"	" Screw Stud	...	...	...
50305e	1325	"	"	"	"	" " Set Screw	...	...	...
2103	1505	"	"	"	"	" Spring	...	...	...
52397	---	Tension , complete, Nos. 1560e, 2103, 32572, 32574, 50304e, 52083, 52394 and two 2102							
52027	1498	Thread Guard (Side of Arm)							
52454	1323	"	"	"	"	Retainer	...	...	...
624e	1515	"	"	"	"	" Set Screw	...	...	...
52054	---	Thread Take-up , complete, Nos. 11204, 52025 and 52143							
52021	1505	Thread Take-up Crank							
52143	---	"	"	"	"	52021, with 775e and 24894	...	...	...
1037e	1515	"	"	"	"	Position Screw	...	...	...
1036e	1515	"	"	"	"	Set Screw	...	...	...
52022	1503	Thread Take-up Lever with 52130							
52023	1505	"	"	"	"	" Hinge Pin	...	...	...
52024	1505	"	"	"	"	" Link	...	...	...
11204	1505	"	"	"	"	" " Hinge Pin	...	...	...
435e	1324	"	"	"	"	" " " Set Screw	...	...	...
52130	---	"	"	"	"	" Thread Eyelet Bushing	...	...	...
52025	---	Thread Take-up Lever , complete, Nos. 52022 to 52024							

No.	Plate	
56013	1323	Arm Shaft (upright) Gear (lower) with two 1253c ...
1253c	1325	" " (") " (") Set Screw ...
56101	1323	" " (") " (upper) with two 1253c ...
1253c	1325	" " (") " (") Set Screw ...
56015	1323	" " (") Oil Tube (lower) ...
56015	1323	" " (") " " (upper) ...
12480	1313	" Side Cap ...
219d	1324	" " " Screw ...
12193	1313	" " Cover ...
286d	1324	" " " Thumb Screw ...
12403	1498	" Spool Pin ...
41591	1314	Arm Top Cover Tension Bracket with 460c ...
24131	1498	" " " " " Oil Tube with 52045 ...
52045	1498	" " " " " " " Packing (cotton wick) ...
180d	1515	" " " " " " " Screw ...
12403	1498	" " " " " " " Spool Pin ...
8879	1316	" " " " " " " Washer (cloth) ...
2455	1498	" " " " " " " Disc ...
41593	1316	" " " " " " " Spring ...
41594	1316	" " " " " " " Stud ...
460c	1324	" " " " " " " Set Screw ...
41595	1316	" " " " " " " Thread Guide ...
41592	1314	Arm Top Cover Tension Bracket , complete, Nos. 12403, 24131, 41591, 41593 to 41595 and two 2455 ...
52005	1313	Balance Wheel (power), light rim, 2 $\frac{3}{16}$ " pulley, with two 448c ...
52063	1497	" " " Oil Cover ...
210d	1324	" " " " " Screw ...
448c	1324	" " " Set Screw ...
*52402	—	Bed ...
<i>NOTE.--Due to the accuracy required for Gear alignment, Bed cannot be supplied separately and can only be sent out as a unit, Arm and Bed assembled.</i>		
12431	—	Bed Slide ...
12432	1313	" " complete, Nos. 4307, 12431 and two 725c ...
4307	1497	" " Spring ...
725c	1324	" " " Screw ...
52051	—	Face Plate ...
190d	1324	" " " Screw ...
52053	1323	" " " Thread Guard (lower) ...
226d	1324	" " " " (") Screw ...
56086	1323	" " " " (upper) ...
226d	1324	" " " " (") Screw ...
50190d	1325	" " " Thumb Screw ...
52052	1313	Face Plate , complete, Nos. 52051, 52053, 56086 and two 226d ...

No.	Plate	
52452	1313	Feed Bar ...
313c	1324	" " " Screw Centre (2) ...
1519c	1325	" " " " " Nut (2) ...
3033	1498	" Connecting Link ...
375c	1324	" " " " " Hinge Screw ...
1518e	1325	" " " " " " " Nut ...
52073	1498	" " " " " " " Stud ...
50083c	1325	" " " " " " " Set Screw ...
120001	1502	Feed Dog (spiked teeth) ...
50117c	1325	" " " Screw (2) ...
127018	1503	Feed and Feed Lifting Eccentric with two 448c ...
448c	1324	" " " " " " " Set Screw ...
24036	1497	" " " " " " " Sleeve ...
52407	1501	" Forked Connection ...
375c	1324	" " " " " " " Hinge Screw ...
1518e	1325	" " " " " " " Nut ...
52384	1500	Feed Lifting Rock Shaft ...
12430	1497	" " " " " " " Connecting Rod (steel) with 12204 and two 966c ...
*12204	—	" " " " " " " " " Cap ...
966c	1325	" " " " " " " " " Screw ...
375c	1324	" " " " " " " " " Hinge Screw ...
1518e	1325	" " " " " " " " " " " Nut ...
52434	1502	" " " " " " " Crank with 157c and 1813 ...
157c	1324	" " " " " " " " " Clamping Screw ...
1813	1498	" " " " " " " " " Roller and Stud ...
50191c	1325	" " " " " " " " " Screw Centre (2) ...
1513j	1317	" " " " " " " " " Nut (2) ...
52433	—	Feed Lifting Rock Shaft , complete, Nos. 52384 and 52434 ...
50338c	1515	Feed Regulating Screw Stud ...
56032	1502	" " " " " " " Head with 56033 ...
50193j	1515	" " " " " " " " " Cap Screw ...
56033	1504	" " " " " " " " " Stop Pin ...
56034	1502	" " " " " " " " " Lock Pin ...
56035	1502	" " " " " " " " " " " Spring ...
52408	1502	Feed Regulator with 50083c ...
1128e	1325	" " " " " " " Hinge Screw ...
52409	1502	Feed Reverse Lever with 158e and 51846 ...
50339d	1515	" " " " " " " Hinge Screw ...
158e	1324	" " " " " " " " " Clamping Screw ...
52410	1502	" " " " " " " " " Friction Washer ...
51846	1515	" " " " " " " " " Roller and Stud ...

No.	Plate								
52386	1500	Feed Rock Shaft	...	...	...	...	...	...	...
29633	1498	" " " Crank with 157c	...	...	...	...	...	...	...
157c	1324	" " " " Clamping Screw	...	...	...	...	...	...	...
50191c	1325	" " " " Screw Centre (2)	...	...	...	...	...	...	...
1513j	1317	" " " " " Nut (2)	...	...	...	...	...	...	...
52387	—	Feed Rock Shaft , complete, Nos. 29633 and 52386	...	...	...	...	...	...	...
25866	1512	Guide ...	...	...	...	...	...	...	...
50190b	1325	" Thumb Screw	...	...	...	...	...	...	...
52455	1505	Needle Bar (hollow)	...	...	...	...	...	...	...
52305	1504	" " Bushing (lower) with 29532	...	...	...	...	...	...	...
1133e	1515	" " " (") Set Screw	...	...	...	...	...	...	...
52448	1503	" " " (upper)	...	...	...	...	...	...	...
1133e	1515	" " " (") Set Screw	...	...	...	...	...	...	...
24040	1505	" " Connecting Link with 794e	...	...	...	...	...	...	...
21894	—	" " " " 24040 with 24041	...	...	...	...	...	...	...
794e	1515	" " " " Adjusting Screw	...	...	...	...	...	...	...
775e	1515	" " " " Cap Screw	...	...	...	...	...	...	...
24041	1505	" " " " Stud with 207e	...	...	...	...	...	...	...
207e	558	" " " " Clamping Screw	...	...	...	...	...	...	...
52436	1503	" " Crank with 858c, 1036c, 1037c and 1065c	...	...	...	...	...	...	...
1065c	1325	" " " Position Screw	...	...	...	...	...	...	...
858c	1325	" " " Set Screw	...	...	...	...	...	...	...
29532	1498	" " Oil Cup	...	...	...	...	...	...	...
52306	1505	" " Thread Guard	...	...	...	...	...	...	...
229d	1515	" " " " Screw	...	...	...	...	...	...	...
52307	1505	" Clamp with 808f	...	...	...	...	...	...	...
808f	1515	" " " Screw	...	...	...	...	...	...	...
12391	1497	Presser Bar (hollow)	...	...	...	...	...	...	...
52338	1316	" " Guide Bracket with 223c and 453c	...	...	...	...	...	...	...
453c	1316	" " " " Set Screw	...	...	...	...	...	...	...
5990	1503	" " Lifter	...	...	...	...	...	...	...
689c	1316	" " " " Screw	...	...	...	...	...	...	...
1520r	1317	" " " " Nut	...	...	...	...	...	...	...
12327	1316	" " Lifting and Releasing Lever Bracket	...	...	...	...	...	...	...
11167	1497	" " Spring	...	...	...	...	...	...	...
11170	1316	" " " Washer	...	...	...	...	...	...	...
7298	1498	Presser Foot Hinge Pin	...	...	...	...	...	...	...
52437	—	" " Plate	...	...	...	...	...	...	...
52438	—	" " Shank	...	...	...	...	...	...	...
26231	1498	" " Spring	...	...	...	...	...	...	...
52439	1502	Presser Foot (spring, hinged), complete, Nos. 7298, 26231, 52437 and 52438	...	...	...	...	...	...	...
190d	1324	" " Screw	...	...	...	...	...	...	...

No.	Plate								
688j	1324	Pressure Regulating Thumb Screw	...	...	...	...	...	...	...
52121	1499	Rotating Hook ...	...	...	...	...	...	...	...
52123	—	" " 52121 with 52090 and four 1053c	...	...	...	...	...	...	...
52440	1499	" " 52123 " 52444, three each 1253c and 1367d	...	...	...	...	...	...	...
52480	—	" " 52440 " 52474	...	...	...	...	...	...	...
40264	1499	" " Bobbin	...	...	...	...	...	...	...
52472	1499	" " " Case	...	...	...	...	...	...	...
52481	—	" " " " 52472 with 591f, 1380d and 40394	...	...	...	...	...	...	...
40392	1499	" " " " Latch	...	...	...	...	...	...	...
40409	1499	" " " " " Lever	...	...	...	...	...	...	...
2974	1499	" " " " " Fulcrum Pin	...	...	...	...	...	...	...
2975	1499	" " " " " Spring	...	...	...	...	...	...	...
592c	1324	" " " " " Stop Screw	...	...	...	...	...	...	...
40393	—	" " " " " Hinge, Nos. 2974, 40392 and 40409	...	...	...	...	...	...	...
591f	1324	" " " " " Tension Regulating Screw	...	...	...	...	...	...	...
40394	1499	" " " " " Spring	...	...	...	...	...	...	...
1380d	1325	" " " " " Screw	...	...	...	...	...	...	...
52473	—	" " " " " complete, Nos. 592c, 2975, 40393 and 52481	...	...	...	...	...	...	...
52474	—	" " " " " 52473 with 52477	...	...	...	...	...	...	...
52477	1499	" " " " " Holder with 52475 and two 52476	...	...	...	...	...	...	...
52018	1498	" " " " " Position Bracket	...	...	...	...	...	...	...
704j	1324	" " " " " " Screw	...	...	...	...	...	...	...
*52475	—	" " " " " Locating Plate	...	...	...	...	...	...	...
*52476	—	" " " " " Rivet	...	...	...	...	...	...	...
52444	1499	" " Section	...	...	...	...	...	...	...
1367d	1325	" " " Screw	...	...	...	...	...	...	...
1253c	1325	" " Set Screw	...	...	...	...	...	...	...
52388	1501	" " Shaft	...	...	...	...	...	...	...
56106	1323	" " " Bushing (back)	...	...	...	...	...	...	...
52045	1498	" " " " (") Packing (cotton)	...	...	...	...	...	...	...
1143c	1325	" " " " (") Set Screw	...	...	...	...	...	...	...
56107	1323	" " " " (front)	...	...	...	...	...	...	...
52045	1498	" " " " (") Packing (cotton)	...	...	...	...	...	...	...
1148c	1325	" " " " (") Set Screw	...	...	...	...	...	...	...
54897	1323	" " " Front Bearing Oil Cup	...	...	...	...	...	...	...
56013	1323	" " " Gear with two 1253c	...	...	...	...	...	...	...
52072	1313	" " " " Case (two pieces) with 121e and 50234d	...	...	...	...	...	...	...
50234d	1325	" " " " " Plug Screw	...	...	...	...	...	...	...
121e	1324	" " " " " Screw	...	...	...	...	...	...	...
1253c	1325	" " " " Set Screw	...	...	...	...	...	...	...
52090	1499	" " Thread Guard	...	...	...	...	...	...	...
1053c	1325	" " " " Screw	...	...	...	...	...	...	...
52337	1316	Slack Thread Regulator	...	...	...	...	...	...	...
223c	1316	" " " " Set Screw	...	...	...	...	...	...	...

No.	Plate						
2102	1498	Tension Disc	...	...	...	...	...
1560c	1325	"	Regulating Thumb Nut	...	...	...	...
32572	1498	"	Releasing Disc	...	...	...	...
52445	1503	"	"	Lever	...	...	...
12398	1316	"	"	"	Hinge Pin	...	...
12329	1316	"	"	"	Spring	...	...
32574	1498	"	"	"	Pin	...	...
50304c	1498	"	"	"	Screw Stud	...	...
50305c	1325	"	"	"	Set Screw	...	...
2103	1505	"	"	"	Spring	...	...
52397	—	Tension , complete, Nos. 1560c, 2103, 32572, 32574, 50304c, 52083, 52394 and two 2102	...	...	...	...	...
52454	1323	Thread Retainer	...	...	...	...	...
624c	1515	"	"	"	Set Screw	...	...
52447	—	Thread Take-up , complete, Nos. 11204, 52025 and 127065	...	...	...	...	...
52446	1502	Thread Take-up Crank	...	...	...	...	...
127065	—	"	"	"	52446 with 775c and 24894	...	...
1037c	1515	"	"	"	Position Screw	...	...
1036c	1515	"	"	"	Set Screw	...	...
52022	1503	Thread Take-up Lever with 52130	...	...	...	...	...
52023	1505	"	"	"	"	Hinge Pin	...
52024	1505	"	"	"	"	Link	...
11204	1505	"	"	"	"	"	Hinge Pin
435c	1324	"	"	"	"	"	Set Screw
52130	—	"	"	"	"	"	Thread Eyelet Bushing
52025	—	Thread Take-up Lever , complete, Nos. 52022 to 52024	...	...	...	...	...
52394	1505	Thread Take-up Spring	...	...	...	...	...
52083	1498	"	"	"	"	Regulator with 50305c	...
448c	1324	"	"	"	"	Set Screw	...
26605	1502	Throat Plate , large needle hole, for 120001	...	...	...	...	...
26606	—	"	"	"	"	small " " 120001	...
691f	1324	"	"	"	"	Screw (2)	...
<i>NOTE.—No. 26605 is sent with this machine unless otherwise specified on order.</i>							
*15404	—	Trade Mark	...	...	...	...	...
15405	—	"	"	"	"	Rivet	...
44212	—	Drip Pan with four Wood Screws $\frac{1}{2}$ " No. 5	...	...	...	...	...

No. 96K3 MACHINE (Obsolete)

For Cloaks, Clothing and other Work in Cloth. Drop Feed.

This Machine is the same as 96K10 with the following exceptions:—

No.	Plate						
*52392	—	Arm	...	...	...	...	...
52302	1500	"	"	"	"	Shaft	...
43921	1504	"	"	"	"	Flanged Bushing (back)	...
448c	1324	"	"	"	"	(") Set Screw	...
52078	1497	"	"	"	"	(front)	...
435c	1324	"	"	"	"	(") Set Screw	...
144d	1324	"	"	"	"	Screw	...
24297	1501	Balance Wheel Oil Cover	...	...	...	...	...
*52303	—	Bed	...	...	...	...	...
44136	1510	Feed Dog	...	...	...	...	...
20283	1505	"	"	"	"	and Feed Lifting Eccentric with 446c	...
446c	1324	"	"	"	"	"	Set Screw
44125	1500	Feed Lifting Rock Shaft	...	...	...	...	...
307c	1317	"	"	"	"	"	Screw Centre (2)
44126	—	Feed Lifting Rock Shaft , complete, Nos. 12376 and 44125	...	...	...	...	...
3039	1504	Feed Regulator	...	...	...	...	...
12379	1500	Feed Rock Shaft	...	...	...	...	...
20333	—	Feed Rock Shaft , complete, Nos. 12379 and 29633	...	...	...	...	...
25878	1319	Guide	...	...	...	...	...
52304	1504	Needle Bar (hollow)	...	...	...	...	...
29534	1511	Presser Foot	...	...	...	...	...
40258	1497	Rotating Hook Belt	...	...	...	...	...
52037	1497	"	"	"	"	Guard	...
181d	1515	"	"	"	"	Screw (2)	...
52048	1504	"	"	"	"	Pulley (lower, steel) with two 1147c and sixteen 52049	...
1147c	1515	"	"	"	"	(lower) Set Screw	...
52049	1504	"	"	"	"	(") Stud	...
52050	1504	"	"	"	"	(upper) with 1362c and thirty 40263	...
1362c	1515	"	"	"	"	(") Set Screw	...
40263	1504	"	"	"	"	(") Stud	...
52308	1501	"	"	"	"	Shaft	...
52044	1504	"	"	"	"	Bushing (back)	...
447c	1515	"	"	"	"	(") Set Screw	...
52039	1504	"	"	"	"	(front)	...
50145c	1515	"	"	"	"	(") Position Screw	...
44137	1510	Throat Plate , large needle hole, for 14136	...	...	...	...	...

IRON BASE

No.	Plate							
19219	1512	Bed Frame Cushion (leather)	...	...	...	...	...	...
158c	1324	" " " Screw	...	...	...	...	...	...
19220	1512	" " " Spring	...	...	...	...	...	...
19226	1512	" " Hinge Connection	...	...	...	...	...	...
19398	---	" " " " 19226 with 211f and 19397	...	...	...	...	...	...
19397	1512	" " " " Cap	...	...	...	...	...	...
211f	1515	" " " " " Screw	...	...	...	...	...	...
16555	1512	" " " " Plate	...	...	...	...	...	...
14010	1512	" " " " Rivet	...	...	...	...	...	...
20067	1513	Bed Frame with two each 16555, 19398, four each 19219, 19220, six each 14010, Wood Screws 1½" No. 12, and eight 158c	...	...	...	...	...	...

ACCESSORIES

No.	Plate							
40264	1499	Bobbin (5)	...	...	...	...	...	...
12361	1512	Machine Hinge Connection (2)	...	...	...	...	...	...
36569	1319	Oiler with 36571	...	...	...	...	...	...
36570		" 36569, filled with Oil	...	...	...	...	...	...
36571	1319	" Spout, 1¾" long	...	...	...	...	...	...
25537	1319	Screw Driver (large)	...	...	...	...	...	...
120378	1319	" " (small)	...	...	...	...	...	...

BOBBIN WINDER

(Swinging Automatic, Left Hand) for 40264.

No.	Plate							
41913	1314	Bracket with 457c	...	...	...	...	...	...
41583	1314	Frame with 457c	...	...	...	...	...	...
34105	1314	" Hinge Pin	...	...	...	...	...	...
457c	1324	" " " Set Screw	...	...	...	...	...	...
41914	1314	" Spring	...	...	...	...	...	...
41585	1314	Pulley with 171d	...	...	...	...	...	...
171d	1324	" Set Screw	...	...	...	...	...	...
41586	1314	Spindle	...	...	...	...	...	...
41587	1314	Stop Latch	...	...	...	...	...	...
42614	1314	" " Hinge Stud	...	...	...	...	...	...
457c	1324	" " " " Set Screw	...	...	...	...	...	...
7958	1498	" " Stop Pin	...	...	...	...	...	...
41588	1314	" " Tripping Arm with 185h	...	...	...	...	...	...
185h	1324	" " " " Clamping Screw	...	...	...	...	...	...
60845	1314	Bobbin Winder, Nos. 7958, 34105, 41583, 41585 to 41588, 41913, 41914 and 42614	...	...	...	...	...	...
41915	-	Bobbin Winder, complete, Nos. 880c, 25446 and 60845	...	...	...	...	...	...
880c	1325	Bobbin Winder Screw	...	...	...	...	...	...
25446	1323	" " " Washer	...	...	...	...	...	...

BOBBIN WINDER

(SWINGING AUTOMATIC, RIGHT HAND)

For use with Series 800, 900, 1700, 1900 and 2100 Motors.

No.	Plate								
41339	1687	Base	...	...	...	...	...	...	...
41340	1687	Frame	...	...	...	...	...	...	...
1429d	1688	" Hinge Screw	...	...	...	...	...	...	...
41341	1687	" Spring	...	...	...	...	...	...	...
207d	558	" " Screw	...	...	...	...	...	...	...
41342	1687	Pulley with 200f	...	...	...	...	...	...	...
200f	1688	" Set Screw	...	...	...	...	...	...	...
41343	1688	Spindle	...	...	...	...	...	...	...
27306	1688	Spool Pin	...	...	...	...	...	...	...
27307	1687	" Stand	...	...	...	...	...	...	...
†27308	1687	Spool Stand , complete, Nos. 418c, 1562j, 2106, 10141, 11241, 27306, 27307, two each 2455 and Wood Screws 1" No. 10	...	...	...	...	...	...	...
11241	1687	Spool Washer (Cloth)	...	...	...	...	...	...	...
41344	1688	Stop Latch	...	...	...	...	...	...	...
41345	1688	" " Finger	...	...	...	...	...	...	...
152f	1688	" " " Screw	...	...	...	...	...	...	...
1430d	1688	" " Hinge Screw	...	...	...	...	...	...	...
1550h	1688	" " " " Nut	...	...	...	...	...	...	...
41346	1688	" " Lever	...	...	...	...	...	...	...
1430d	1688	" " " Hinge Screw	...	...	...	...	...	...	...
2455	1688	Tension Disc	...	...	...	...	...	...	...
1562j	1688	" Regulating Thumb Nut	...	...	...	...	...	...	...
418c	1688	" Screw Stud	...	...	...	...	...	...	...
10141	1688	" Spring	...	...	...	...	...	...	...
2106	1688	" Thread Guide	...	...	...	...	...	...	...
9331	1688	Washer	...	...	...	...	...	...	...
60456	---	Bobbin Winder , Nos. 152f, 207d, 1429d, 1550h, 41339 to 41346, and three 1430d	...	...	...	...	...	...	...
41347	1687	Bobbin Winder , Nos. 60456, two each 9331 and Wood Screws 1" No. 10 R.H.B.	...	...	...	...	...	...	...
41348		Bobbin Winder (swinging automatic, right hand), complete, Nos. 27308 and 41347	...	...	...	...	...	...	...

† As No. 27308 can be supplied either Plated or Japanned, it is necessary, when ordering, to state which is required.

ATTACHMENTS

BINDERS

When ordering Binders send sample of the Binding and of the Material to be Bound.

BINDER for Cap Peak Work.

No.	Plate								
85678	559	Feed Dog	...	...	...	...	...	...	...
85459	559	Folder Base	...	...	...	...	...	...	...
85460	559	" (top)	...	...	...	...	...	...	...
207d	558	" (") Binding Screw	...	...	...	...	...	...	...
85461	---	" (bottom)	...	...	...	...	...	...	...
SS50d	186	" (") Binding Screw	...	...	...	...	...	...	...
85462	559	Folder Roller Guide , complete, Nos. 701d, 85463 and 85464	...	...	...	...	...	...	...
85463	---	" " " Bracket	...	...	...	...	...	...	...
85464	---	" " " Roller	...	...	...	...	...	...	...
701d	1324	" " " " Screw	...	...	...	...	...	...	...
SS50d	186	" " " Binding Screw	...	...	...	...	...	...	...
176d	559	" Screw (to fasten to machine)	...	...	...	...	...	...	...
85325	186	" " Washer	...	...	...	...	...	...	...
85458	559	Folder , complete, Nos. 85459 to 85462, two 207d and four SS50d	...	...	...	...	...	...	...
85679	559	Presser Foot	...	...	...	...	...	...	...
85680	559	Throat Plate	...	...	...	...	...	...	...
85681	559	Binder , complete, Nos. 85458, 85678 to 85680, two each 176d and 85325	...	...	...	...	...	...	...

BINDER for Cardigan Jackets.

No.	Plate								
85682	558	Feed Dog	...	...	...	...	...	...	...
85336	---	Folder Base	...	...	...	...	...	...	...
85337	---	" Folding Plate (top)	...	...	...	...	...	...	...
85338	---	" " " (bottom)	...	...	...	...	...	...	...
233d	1324	" " " Screw for 85337 and 85338	...	...	...	...	...	...	...
SS50d	186	" Screw	...	...	...	...	...	...	...
85325	186	" " Washer	...	...	...	...	...	...	...
85335	---	Folder , complete, Nos. 85336 to 85338 and four 233d	...	...	...	...	...	...	...

No.	Plate							
85683	558	Presser Foot	...	...	...	...	...	...
85324	—	Tape Tension Pin (bent)	...	...	...	...	...	...
85323	—	" " " (straight)	...	...	...	...	...	...
85340	—	" " Plate	...	...	...	...	...	...
85339	558	" " complete, Nos. 85324, 85340 and four 85323	...	...	...	...	...	...
207d	558	" " Screw	...	...	...	...	...	...
85325	186	" " Washer	...	...	...	...	...	...
85684	558	Throat Plate	...	...	...	...	...	...
85685	558	Binder , complete, Nos. SS50d, 207d, 85335, 85339, 85682 to 85684 and two 85325	...	...	...	...	...	...

BINDER $\frac{1}{2}$ ", for General Work.

No.	Plate							
85686	558	Feed Dog	...	...	...	...	...	...
85320	558	Folder	...	...	...	...	...	...
SS50d	186	" Screw	...	...	...	...	...	...
85325	186	" " Washer	...	...	...	...	...	...
85687	—	Presser Foot Bracket	...	...	...	...	...	...
85688	—	" " " Hinge Pin	...	...	...	...	...	...
85689	—	" " Sole	...	...	...	...	...	...
85690	558	" " (hinged), complete, Nos. 85687 to 85689	...	...	...	...	...	...
85324	—	Tape Tension Pin (bent)	...	...	...	...	...	...
85323	—	" " " (straight)	...	...	...	...	...	...
85322	—	" " Plate	...	...	...	...	...	...
85321	557	" " complete, Nos. 85322, 85324 and eight 85323	...	...	...	...	...	...
SS50d	186	" " Screw	...	...	...	...	...	...
85325	186	" " Washer	...	...	...	...	...	...
85691	558	Throat Plate	...	...	...	...	...	...
85692	558	Binder , complete, Nos. 85320, 85321, 85686, 85690, 85691, two each SS50d and 85325	...	...	...	...	...	...

BINDER $\frac{1}{2}$ ", for Stay Work.

No.	Plate							
85693	557	Feed Dog	...	...	...	...	...	...
85614	—	Folder	...	...	...	...	...	...
SS65d	1324	" Screw	...	...	...	...	...	...
85694	—	Presser Foot Bracket	...	...	...	...	...	...
85616	—	" " " Hinge Pin	...	...	...	...	...	...
85695	—	" " Sole	...	...	...	...	...	...
85696	557	" " (hinged), complete, Nos. 85616, 85694 and 85695	...	...	...	...	...	...
85324	—	Tape Tension Pin (bent)	...	...	...	...	...	...
85323	—	" " " (straight)	...	...	...	...	...	...
85322	—	" " Plate	...	...	...	...	...	...
85321	557	" " complete, Nos. 85322, 85324 and eight 85323	...	...	...	...	...	...
SS50d	186	" " Screw	...	...	...	...	...	...
85325	186	" " Washer	...	...	...	...	...	...
85697	557	Throat Plate	...	...	...	...	...	...
85698	557	Binder , complete, Nos. SS50d, SS65d, 85321, 85325, 85614, 85693, 85696 and 85697	...	...	...	...	...	...

BINDER $\frac{1}{2}$ ", for Stay Work.

No.	Plate							
85699	186	Base	...	...	...	...	...	...
85597	186	Binder	...	...	...	...	...	...
85324	—	Tape Tension Pin (bent)	...	...	...	...	...	...
85323	—	" " " (straight)	...	...	...	...	...	...
85700	186	Binder and Tension only, complete, Nos. 85324, 85597, 85699 and nine 85323	...	...	...	...	...	...
SS50d	186	" Screw	...	...	...	...	...	...
85325	186	" " Washer	...	...	...	...	...	...
85701	186	Feed Dog	...	...	...	...	...	...
85702	—	Presser Foot Bracket	...	...	...	...	...	...
85703	—	" " " Hinge Pin	...	...	...	...	...	...
85704	—	" " Sole	...	...	...	...	...	...
85705	186	" " (hinged), complete, Nos. 85702 to 85704	...	...	...	...	...	...
85706	186	Throat Plate	...	...	...	...	...	...
85707	186	Binder , complete, Nos. SS50d, 85325, 85700, 85701, 85705 and 85706	...	...	...	...	...	...

BINDER, FOLDER and TENSION $\frac{3}{16}$ " for Stay Work.

No.	Plate								
85711	187	Base	...	...	...	...	...	...	...
85603	187	Binder	...	...	...	...	...	...	...
85604	187	Folder	...	...	...	...	...	...	...
207d	558	" Screw	...	...	...	...	...	...	...
85325	186	" " Washer	...	...	...	...	...	...	...
85605	187	Tape Guide	...	...	...	...	...	...	...
85606	187	" " Bracket	...	...	...	...	...	...	...
207d	558	" " " Screw	...	...	...	...	...	...	...
85325	186	" " " Washer	...	...	...	...	...	...	...
207d	558	" " " Screw	...	...	...	...	...	...	...
85325	186	" " " Washer	...	...	...	...	...	...	...
85607	...	" Tension Pin	...	...	...	...	...	...	...
85712	187	Binder, Folder and Tension only, complete, Nos. 85603 to 85606, 85711, three each 207d, 85325 and seven 85607							
SS50d	186	Binder Screw	...	...	...	...	...	...	...
85325	186	" " Washer	...	...	...	...	...	...	...
85701	186	Feed Dog	...	...	...	...	...	...	...
85702	...	Presser Foot Bracket	...	...	...	...	...	...	...
85703	...	" " " Hinge Pin	...	...	...	...	...	...	...
85704	...	" " Sole	...	...	...	...	...	...	...
85705	186	" " (hinged), complete, Nos. 85702 to 85704	...	...	...	...	...	...	...
85706	186	Throat Plate	...	...	...	...	...	...	...
85713	187	Binder , complete, Nos. SS50d, 85325, 85701, 85705, 85706 and 85712							

BRAIDER FOOT (Long Shank, Adjustable)

No.	Plate								
86179	...	Braider Foot	...	...	...	...	...	...	...
86176	...	" " Guide (Wire)	...	...	...	...	...	...	...
SS182d	1324	" " " Screw	...	...	...	...	...	...	...
86180	560	Braider Foot , complete, Nos. 86179, two each SS182d and 86176							
86178	560	Braider Foot	...	...	...	...	...	...	...

CORDERS

When ordering state Size or No. of Cords to the inch.

CORDER (Adjustable), for Fine Cording.

No.	Plate								
85812	560	Base	...	...	...	...	...	...	...
85813	560	Finger Arm	...	...	...	...	...	...	...
85844	560	" " Adjustable Bracket	...	...	...	...	...	...	...
85845	...	" " " Block	...	...	...	...	...	...	...
393c	1324	" " " Screw	...	...	...	...	...	...	...
316c	1324	" " " Centre Screw	...	...	...	...	...	...	...
1547d	1325	" " " " Nut	...	...	...	...	...	...	...
NN 11d	1325	" " " Thumb Nut	...	...	...	...	...	...	...
286d	1324	" " " Set Screw	...	...	...	...	...	...	...
85846	560	Corder only, complete, Nos. NN 11d, 286d, 393c, 85842 to 85845, two each 316c and 1547d							
85864	560	Feed Dog	...	...	...	...	...	...	...
85865	560	Presser Foot	...	...	...	...	...	...	...
85866	560	Throat Plate	...	...	...	...	...	...	...
85867	560	Corder , complete, Nos. SS50d, 85846 and 85864 to 85866							
SS50d	186	Corder Screw (to fasten to machine)							

CORDER (Bow), for Top Cording.

No.	Plate								
85868	201	Corder Bow	...	...	...	...	...	...	...
85869	201	Presser Foot	...	...	...	...	...	...	...
759d	1324	" " Thumb Screw	...	...	...	...	...	...	...
85870	201	Corder (Bow) , complete, Nos. 759d, 85868 and 85869							

CORDER, for Top Cording.

No.	Plate								
85783	—	Base	...	...	...	...	...	...	...
85871	—	Guide Finger	with 85414, 85872 and two 85416						...
SS28b	1324	"	"	Adjusting Screw	...	...	...	...	...
85414	—	"	"	Eyelet	...	...	...	...	...
85413	—	"	"	Hinge Pin	...	...	...	...	...
879d	1325	"	"	Locking Thumb Screw	...	...	...	...	...
85872	—	"	"	Tip	...	...	...	...	...
85416	—	"	"	" Rivet	...	...	...	...	...
85873	1320	Corder	only, complete, Nos. SS28b, 879d, 85413, 85783 and 85871						...
85874	1320	Presser Foot	...	...	...	...	...	...	...
85875	1320	Corder ,	complete, Nos. SS44d, 85412, 85873 and 85874						...
SS44d	1320	"	"	Screw (to fasten to machine)	...	...	...	...	...
85412	1320	"	"	Washer	...	...	...	...	...

CORDER GUIDE (Adjustable)

No.	Plate								
85382	—	Extension Guide	...	...	...	...	...	...	...
228d	1324	"	"	Screw	...	...	...	...	...
85876	—	Presser Foot	...	...	...	...	...	...	...
85877	560	Corder Guide ,	complete, Nos. 228d, 85382 and 85876						...
85881	562	Cording and Hemming Foot	...	...	...	...	...	...	...
86182	562	Cording Foot	(grooved on right side)						...

CRIMPING SET.

No.	Plate								
85882	557	Feed Dog	...	...	...	...	...	...	...
85883	—	Presser Foot	...	...	...	...	...	...	...
85391	—	"	"	Spring	...	...	...	...	...
219d	1324	"	"	" Screw	...	...	...	...	...
85884	557	"	"	complete, Nos. 219d, 85391 and 85883	...	...	...	...	...
85885	557	Throat Plate	...	...	...	...	...	...	...
85886	557	Crimping Set ,	complete, Nos. 85882, 85884 and 85885						...

FELLING FEET.

No.	Plate								
85896	201	Felling Foot ,	$\frac{3}{16}$ " Fell	...	...	...	...	...	...
85897	562	"	" (steel) $\frac{3}{16}$ " Fell	...	...	...	...	...	...

FINGER GUARD

No.	Plate								
86417	1510	Finger Guard	...	...	...	...	...	...	...
102d	1324	"	"	Binding Screw	...	...	...	...	...
86478	1510	"	"	Bracket with 207f	...	...	...	...	...
207f	558	"	"	" Screw	...	...	...	...	...
86479	1510	Finger Guard ,	complete, Nos. 102d, 86417 and 86478						...

GATHERING FEET.

No.	Plate								
85955	562	Gathering Foot	...	...	...	...	...	...	...
86193	560	"	" (slotted)	...	...	...	...	...	...

HEMMERS.

No.	Plate								
86005	88	Hemmer ,	$\frac{3}{16}$ " to $\frac{7}{8}$ ",	in grades of $\frac{1}{16}$ "	...	...	...	...	...
86008	88	"	1" to 1 $\frac{1}{4}$ ",	in grades of $\frac{1}{8}$ "	...	...	...	...	...
86010	88	"	1 $\frac{3}{8}$ " and 1 $\frac{1}{2}$ "	...	...	...	...	...	...
85447	88	"	Base with SS54e	...	...	...	...	...	...
SS54e	1324	"	" Stud Screw	...	...	...	...	...	...
NN40d	88	"	" " " " Thumb Nut	...	...	...	...	...	...
85448	88	"	" " " " " Washer	...	...	...	...	...	...
85446	—	Hemmer Base ,	complete, Nos. NN40d, 85447 and 85448						...

Flat Sole.

No.	Plate								
86537	—	$\frac{1}{16}$ "	...	...	...	...	...	...	...
86538	—	$\frac{3}{32}$ "	...	...	...	...	...	...	...
86539	1931	$\frac{1}{8}$ "	...	...	...	...	...	...	...
86540	—	$\frac{5}{32}$ "	...	...	...	...	...	...	...
86541	—	$\frac{3}{16}$ "	...	...	...	...	...	...	...
86542	—	$\frac{7}{32}$ "	...	...	...	...	...	...	...
86543	—	$\frac{1}{4}$ "	...	...	...	...	...	...	...

86025	562	Hemmer Foot, $\frac{1}{16}$ " to $\frac{9}{32}$ " Hem, in grades of $\frac{1}{32}$ "	...	...
-------	-----	--	-----	-----

PRESSER FOOT.

No.	Plate			
86188	958	Presser Foot (narrow) for narrow tucking	...	...

QUILTER.

No.	Plate							
86041	958	Clamp	with 207d	...	...	...	...	...
207d	558	"	Screw	...	...	...	...	...
86042	958	Rod	...	...	...	...	...	...
86043	958	Quilter , complete, Nos. 86041 and 86042	...	...	...	...	...	...

TUCKERS (Long Arm).

No.	Plate								
36387	1315	Space Guide	...	...	...	...	...	...	...
35510	1315	" "	Base with 35512, 35514 and two 1426e	...	...	...	...	...	...
162d	1317	" "	" Screw	...	...	...	...	...	...
35511	1317	" "	Indicator	...	...	...	...	...	...
35512	1317	" "	Pin	...	...	...	...	...	...
35513	1317	" "	Stop (left)	...	...	...	...	...	...
35514	1317	" "	" (") Guide Pin	...	...	...	...	...	...
1426e	1317	" "	" (") Screw Stud	...	...	...	...	...	...
1657d	1317	" "	" (") Thumb Nut	...	...	...	...	...	...
17718	1317	" "	" (") " " Washer	...	...	...	...	...	...
35515	1317	" "	(right)	...	...	...	...	...	...
1426e	1317	" "	" (") Screw Stud	...	...	...	...	...	...
1657d	1317	" "	" (") Thumb Nut	...	...	...	...	...	...
17718	1317	" "	" (") " " Washer	...	...	...	...	...	...
287d	1317	" "	Thumb Screw	...	...	...	...	...	...
36388	--	Space Guide , complete, Nos. 287d, 35510, 35511, 35513, 35515, 36387, two each 1657d and 17718	...	...	...	...	...	...	...

No.	Plate
35517	1309 Tuck Guide Arm
1177d	1317 " " Screw
35518	1309 " " Base
50134e	1317 " " Screw Stud
36389	1309 " " Bracket
307c	1317 " " Screw Centre
1513j	1317 " " " Nut
36390	1317 " " Spring
36391	1315 " " " Plate
9d	1317 " " " Screw
423c	1317 " " Stop Screw
1520r	1317 " " " Nut
36392	1309 " " Frame
36393	1317 " " Spring
1510e	1317 " " " Nut
35524	1317 " " " Washer
803c	1317 " " Stop Screw
1520r	1317 " " " Nut
35511	1317 " " Indicator
35525	1309 " " Plate
1415f	1317 " " Screw

36394 **Tuck Guide**, complete, Nos. 9d, 123c, 843c, 1510c, 35511, 35517, 35518, 35521, 35525, 36389 to 36393, 5013e, two each 307c, 1115f, 1177d, 1513j, 1520r and three Wood Screws 11" No. 10

36395 **Tucker** (long arm), complete, Nos. 35528, 36388, 36394 and two

52031	967	Feed Dog for shirt work	...	...	...	...	...
35528	1510	Presser Foot (wide) for 36395	...	...	...	...	...
40322	1510	" " (narrow) for 36395	...	...	...	...	...
36654	1510	" " for tucking shirt bosoms, for 36670	...	...	...	...	...
52032		Throat Plate , large needle hole, for 52031	...	...	...	...	...
52033	967	" " small " " " 52031	...	...	...	...	...

36670 - **Tucker** (long arm), complete, for tango tucking, Nos. 36388, 36394, 36654 and two 402d

KNEE LIFTER

No.	Plate								
5596	1497	Bell Crank	...	...	...	...	...	...	...
5599	1497	" "	Bracket	...	...	...	...	...	...
178e	1324	" "	" Screw	...	...	...	...	...	...
5601	1498	" "	Hinge Pin	...	...	...	...	...	...
5735	1498	" "	Spring	...	...	...	...	...	...
56848	---	" "	5596 with 5599 and 5601	...	...	...	...	...	...
5598	1497	Bell Crank , complete, Nos. 5735 and 56848	...	...	...	...	...	...	...
12237	1514	Lifting Lever with 448c	...	...	...	...	...	...	...
52028	1497	" "	Connecting Rod	...	...	...	...	...	...
12416	1316	" "	" " Joint	...	...	...	...	...	...
76d	1324	" "	" " Hinge Screw	...	...	...	...	...	...
1521e	1325	" "	" " Lock Nut	...	...	...	...	...	...
802d	1325	" "	Hinge Screw	...	...	...	...	...	...
12241	1316	" "	Link	...	...	...	...	...	...
766d	1324	" "	" Hinge Screw	...	...	...	...	...	...
12240	1316	" "	Pin	...	...	...	...	...	...
448c	1324	" "	" Set Screw	...	...	...	...	...	...
2763	1514	Rock Shaft	...	...	...	...	...	...	...
97502	1815	" "	Bracket	...	...	...	...	...	...
---	---	" "	" Screw (Wood), 1" No. 10	...	...	...	...	...	...
2765	1514	" "	Knee Arm	...	...	...	...	...	...
2766	1514	" "	" " Hub with 356c	...	...	...	...	...	...
356c	1324	" "	" " Set Screw	...	...	...	...	...	...
2768	-	" "	" " complete, Nos. 2765 to 2767	...	...	...	...	...	...
2767	1514	" "	" Plate with 356c	...	...	...	...	...	...
356c	1324	" "	" " Set Screw	...	...	...	...	...	...
6337	1514	" "	Lifting Bracket with two 356c	...	...	...	...	...	...
2778	1514	" "	" " Hook	...	...	...	...	...	...
356c	1324	" "	" " Set Screw	...	...	...	...	...	...
356c	1324	" "	" " Set Screw	...	...	...	...	...	...
2770	1514	" "	Stop Dog with 356c	...	...	...	...	...	...
356c	1324	" "	" " Set Screw	...	...	...	...	...	...
85245	1514	Rock Shaft , complete, Nos. 2763, 2768, 2778, 6337, two each 2770, 97502 and four Wood Screws 1" No. 10	...	...	...	...	...	...	...
85246	---	Knee Lifter , complete, Nos. 76d, 766d, 802d, 1521e, 5598, 12237, 12240, 12241, 12416, 52028, 85245 and two 178e	...	...	...	...	...	...	...

TAPE HOLDER

(8 IN. DISC)

FOR 96K14 MACHINE.

No.	Plate								
26061	7708	Bracket Wire with Disc	...	...	...	...	...	...	...
26062	7708	Disc (adjustable) with 286d and 35925	...	...	...	...	...	...	...
35925	---	" Hub	...	...	...	...	...	...	...
286d	1324	" Thumb Screw	...	...	...	...	...	...	...
26063	7708	Tape Holder (straight), 8" disc, complete, Nos. 26061 and 26062	...	...	...	...	...	...	...
190d	1324	Tape Holder Set Screw	...	...	...	...	...	...	...

THREAD UNWINDER

FOR TWO SPOOLS OF THREAD.

No.	Plate								
225325	1621	Spool Rest with 201018c	...	...	...	...	...	...	...
225388	1621	" " Rod	...	...	...	...	...	...	...
200383c	1325	" " Set Screw	...	...	...	...	...	...	...
201018c	1515	" " Set Screw	...	...	...	...	...	...	...
202490	1621	" Stand with 200383c	...	...	...	...	...	...	...
225391	1621	Thread Guide	...	...	...	...	...	...	...
201696j	1515	" " Lock Nut	...	...	...	...	...	...	...
225326	---	" " Position Cup	...	...	...	...	...	...	...
225324	1621	" " Rod with 208c and 225322	...	...	...	...	...	...	...
208c	1515	" " Screw	...	...	...	...	...	...	...
225322	---	" " Washer	...	...	...	...	...	...	...
225396	1621	Thread Unwinder , complete, Nos. 201696j, 202490, 225324 to 225326, 225388, two 225391 and three Wood Screws $\frac{7}{8}$ " No. 12	...	...	...	...	...	...	...