

A large, light gray watermark logo is centered on the page. It consists of a semi-circular arc at the top and bottom, with the word "CSMP" in a bold, stylized font across the middle. The "S" and "M" are particularly large and stylized.

SINGER
111G156

Form 3215w
(359)

LIST OF PARTS
for
MACHINE NO. 111G156

CSTMP

MACHINE NO. 111G156

* 240571 Arm with 202135
224002 " Cap
200278X " " Screw
202248 " " " Washer
204235 " Position Pin (2)
200004E " Screw (3)
202005 " " Washer (3)
240360 " Shaft with 224392 and 350431E
249440 " " Ball Bearing
*240054 " " " " Collar with two 200378C
240055 " " " " " 240054 with 249440
200378C " " " " " Set Screw
240056 " " " " Retainer Washer
*240053 " " Bushing (back)
200335C " " " " Set Screw
240057 " " " (back, ball bearing) complete, Nos. 240053, 240055
and 240056
263096 " " " (front) with 202423
202423 " " " " Oil Packing (wick)
200502X " " " " " Thumb Screw
204329 " " " " " Pad
200338C " " " " Set Screw
224195 " " Connection Belt (reinforced neoprene)
240361 " " " " Pulley with 200327C, 2003880, 200425C
and two 202253
200425C " " " " " Position Screw
200388C " " " " " Check Screw
200327C " " " " " Set Screw

MACHINE NO. 111G156

202253	Arm Shaft Connection Belt Pulley Spring Flange
224139	" " " " Timing Plate
200164B	" " " " " " Screw (2)
224392	" " Oil Packing (wick)
350431E	" " " " Stop Screw
*240587	Bed
255168	" Oil Cup (6)
240003	" Slide (back)
223811	" " " Stop
223812	" " " " Spring
240004	" " (front))
203470	Bobbin (2)
*233764	" Case
203648	" " Latch
*202056	" " " Pin
203473	" " " Plunger
203474	" " " Spring
241674	" " Oiling Felt
241675	" " " " Retainer
350405C	" " " " " Screw
224004	" " Opener
224005	" " " Lever with 201349C, 201542C and 203101
201349C	" " " " Driving Screw Stud
201542C	" " " " " " Nut
203101	" " " " " " Oil Packing (wick)
265088	" " " " Hinge Stud with 202277
202277	" " " " " Oil Packing (wick)

MACHINE NO. 111G156

200364C Bobbin Case Opener Lever Hinge Stud Set Screw
223623 " " " " Link
200118D " " " Screw
203214 " " Tension Spring
200984C " " " " Regulating Screw
200594E " " " " Screw
203216 " " Washer (cloth)
233765 Bobbin Case complete, Nos. 200594E, 200984C, 202056, 203214,
203216, 203473, 203474, 203648, 233764,
241674, 241675 and two 350405C
240104 Face Plate
202135 " " Position Pin
200473X " " Thumb Screw
240223 Feed Bar
240224 " " 240223 with 225837, 267273 and 350197E
350393C " " Hinge Screw (driving)
201518E " " " " Nut
264510 " Dog, 40 elongated needle hole, for needle sizes 23 and 24
200106E " " Screw
240588 " Driving Connection with 240226 and 240227
240589 " " " Crank with 200029E
200029E " " " " Pinch Screw
350507C " " " " Hinge Screw
201531E " " " " " " Nut
276169 " " " Link
276170 " " " " 276169 with 270653
276171 " " " " Hinge Pin with 244071
244071 " " " " " " Oil Packing (wick)

MACHINE NO. 111G156

200394C	Feed Driving Connection Link Hinge Pin Set Screw	
270653	" " " " Needle Bearing	
240226	" " " Oiling Felt	
240227	" " " " Retaining Wire	
240229	" " Eccentric <i>4912</i> <i>508351</i>	38 ²
240230	" " " Adjusting Disc	110 ²
248415	" " " " " Spring	113 ⁴
248416	" " " " " Collar with two 200382ALX	34 ²
200382ALX	" " " " " " " Set Screw	
240231	" " " Friction Gib	3 ²
350578XC	" " " " " Adjusting Screw	113 11 ³
350562XC	" " " " " " " Set Screw	
240565	" " Flange with 200333C, 200346C, two each 350562XC and 350578XC	
200333C	" " " Position Screw	
200346C	" " " Set Screw	
223650	" " Rock Shaft	
240233	" " " " 223650 with 201518E, 240224 and 350393C	
248420	" " " " Bushing (left) (split)	
200347AL	" " " " " " Pinch Screw	
201007C	" " " " " " " " Set Screw	
244084	" " " " " " " " " " Packing (fibre)	
248421	" " " " " (right) (split)	
200327C	" " " " " " Pinch Screw	
200347AL	" " " " " " " " Set Screw	
244084	" " " " " " " " " " Packing (fibre)	

MACHINE NO. 111G156)

240590	Feed Driving Rock Shaft Crank with 200019E
200019E	" " " " " Pinch Screw
202625	" " " " Stop Collar with two 200383C (2)
200383C	" " " " " Set Screw
248449	" Indicating Disc with 200958C
200958C	" " " Set Screw
224154	" Lifting Cam with 201220ALX
267273	" " " Fork with 200173D and 223655
350197E	" " " " Screw
225837	" " " " " Washer
223655	" " " Oiling Felt
200173D	" " " " " Screw
201220ALX	" " " Set Screw
240235	" Regulating Stud
240245	" " " Retaining Spring
248425	" " " Spring
240591	" Reversing Lever with 201139E DISCONTINUED
201829	" " " Guide Roller
240574	" " " " " Position Plate
691F	" " " " " " " Screw (2)
200274C	" " " " " Screw Stud
240575	" " " Handle DISCONTINUED
200575X	" " " " Screw
201529X	" " " " " Nut
200247C	" " " Hinge Screw
240576	" " " Spring with two 208639
208639	" " " " Holding Eyelet

MACHINE NO. 111G156

201139E	Feed Reversing Lever Spring Screw (lower)
350583E	" " " " " (upper)
1517E	" " " " " " Nut
276173	" " Mechanism Support Link with 200388C
276174	" " " " Stud
200364C	" " " " " Set Screw
240592	" " Shaft with 200047E
240593	" " " Bracket with 200364C
232244	" " " " Position Pin (2)
200019E	" " " " Screw (2)
27083C	" " " Crank with 200040E and 200386C
240594	" " " " Hinge Stud with 276046
276046	" " " " " " Oil Packing (wick)
200386C	" " " " " " Set Screw
276165	" " " " Link with 200394C
200040E	" " " " Pinch Screw
240595	" " " Driving Stud
200047E	" " " " " Pinch Screw
265684	" " " Stop Collar with two 200382ALX
200382ALX	" " " " " Set Screw
*240556	Hook (sewing)
240557	" 240556 with 203525, 240559, two each 201253F and 201409F
240558	" and Bobbin Case complete, Nos. 233765 and 240557
224019	" Bushing (lower) (bronze)
200364C	" " " Set Screw
224020	" " (upper) (bronze)
200446C	" " " Position Screw

MACHINE NO. 111G156

223867	Hook Driving Gear (spiral) with 200362C and 201222C
201222C	" " " Position Screw
200362C	" " " Set Screw
240167	" " Pinion (spiral) with 200382ALX and 201220ALX
201220ALX	" " " Position Screw
200382ALX	" " " Set Screw
224022	" " " Thrust Washer
240241	" " Shaft
249440	" " " Ball Bearing
*240060	" " " " " Collar with 200378C and 201220ALX
240061	" " " " " " 240060 with 249440
201220ALX	" " " " " " Position Screw
200378C	" " " " " " Set Screw
240561	" " " " " Retaining Washer
200134F	" " " " " " " Set Screw
240562	" " " Bushing (back) with three 200134F
240563	" " " " (back,ball bearing) complete, Nos. 240061,240561 and 240562
237529	" " " " (front)
200327C	" " " " Set Screw (2)
265314	" " " Lock Ratchet with 200354C and 200362C
200354C	" " " " " Position Screw
200362C	" " " " " Set Screw
240244	" " " " Stud
240245	" " " " " Retaining Spring
248425	" " " " " Spring
203525	" Gib

MACHINE NO. 111G156

201253F	Hook Gib Screw
240559	" Needle Guard
201409F	" " " Screw
223850	" Saddle with 200009E
224024	" " 223850 with 200364C, 200446C, 224019 and 224020
240243	" " Bearing
200335C	" " " Set Screw
200009E	" " Pinch Screw
200006E	" " Screw
225585	" " " Washer
240560	Hook Saddle complete, Nos. 200118D, 200364C, 223623, 224004, 224005, 224022, 224024, 240167, 240558 and 265088
240067	Knee Lifter Connection Lever
200262X	" " " " Hinge Screw
240564	" " " " Lifting Rod
206628	" " " " " " Spring
227227	" " " " " " " Collar with 200113F
200113F	" " " " " " " Collar Set Screw
240516	" " Lifting Lever
200262X	" " " " Hinge Screw
240205	Lifting Bell Crank
200996C	" " " Cap Screw
240125	" " " Link
350172C	" " " " Screw Stud
201524E	" " " " " " Nut
*237195	" Eccentric

MACHINE NO. 111G156

240362 Lifting Eccentric Body with 443C
350107C " " " Position Screw
443C " " " Set Screw
240126 " " Connection
240171 " " " Crank with 200029E and 248821
248821 " " " " Oil Packing (wick)
200029E " " " " Pinch Screw
1103C " " Regulating Screw
201129D " " Set Screw
240363 " " complete, Nos. 1103C, 201129D, 237195, and
240362
240517 " Presser Foot, for cording and general upholstery
200074F " " " Screw
240136 " Rock Shaft with 201524E and 350172C
240174 " " " Bushing (2)
240545 Machine Pulley (aluminum alloy casting), for "V" belt
(outside diam. of belt groove 3.268
in.) for 3/8 in. "V" belt
(effective diam. 2-3/4 in., for
5/16 in. round belt) (rim diam.
5-15/64 in.) with 350540C and
350541C.
350419X Machine Pulley Adjusting Screw
350540C " " Position Screw
350541C " " Set Screw
240498 Needle Bar with 200175D, 201350F and 240499
238251 " " Connecting Link
264718 " " " " Oil Guard
201183D " " " " " Screw
202333 " " " " Stud with 202299

MACHINE NO. 111G156

202299	Needle Bar Connecting Link Stud Oil Packing (wick)
200374AL	" " " " " Set Screw
200383C	" " " " " " "
208552	" " " Stud with 200086ALX and 202330
202330	" " " " Oil Packing (wick)
200086ALX	" " " " Pinch Screw
202692	" " Crank with 200335C, 200374AL, 200383C, 200428C and 202333
240178	" " " 202692 with 202399, 202400, 208552, 238251, and 241518
203172	" " " Friction Washer
200428C	" " " Position Screw
200335C	" " " Set Screw
240248	" " Rock Frame
248437	" " " " Hinge Stud
200347AL	" " " " " " Set Screw
202666	" " " " Position Bracket
200098F	" " " " " Screw
223690	" " " " Rock Shaft
223691	" " " " " 223690 with 200387C and 210920
223692	" " " " " Crank with 200029E
240597	" " " " " " Connection with 202277
201407C	" " " " " " Hinge Screw (lower)
200833C	" " " " " " Hinge Screw (upper)
201517E	" " " " " " Hinge Screw (lower) Nut

MACHINE NO. 111G156

201522E	Needle	Bar	Rock	Frame	Rock	Shaft	Crank	Connection	Hinge	Screw	(upper) Nut
202277	"	"	"	"	"	"	"	Connection	Oil	Packing	(wick)
206758	"	"	"	"	"	"	"	Connection	Hinge	Screw	(lower) Oil Packing (wick)
200029E	"	"	"	"	"	"	"	Shaft	Crank	Pinch	Screw
202668	"	"	"	"	"	"	"	Slide	Block		
210920	"	"	"	"	"	"	"	202668	with	201141C	
201141C	"	"	"	"	"	"	"	Screw	Stud		
200387C	"	"	"	"	"	"	"	"	"	Set	Screw
240499	"	"	"	"	"	"	"	Thread	Guide		
200175D	"	"	"	"	"	"	"	Screw			
201350F	"	"	"	"	"	"	"	Set	Screw		
208566	Presser	Bar	with	200074F							
241352	"	"	"	Bushing	(lower)						
207072	"	"	"	"	(upper)						
200352AL	"	"	"	"	Set	Screw	(2)				
202671	"	"	"	Lifter							
200653C	"	"	"	"	Hinge	Screw					
264526	"	"	"	Lifting	Bracket	with	200054E				
200975F	"	"	"	"	"	Guide	Screw				
200054E	"	"	"	"	"	Pinch	Screw				
202337	"	"	"	Position	Guide						
202338	"	"	"	"	"	Lever	with	200086ALX			
200086ALX	"	"	"	"	"	"	Pinch	Screw			
200352AL	"	"	"	"	"	Set	Screw				
237836	"	"	"	Spring	(flat)						
210949	"	"	"	"	Bracket	with	200086ALX				

MACHINE NO. 111G156

200086ALX	Presser Bar Spring Bracket Pinch Screw
201110F	" " " Regulating Screw
200948F	" " " Support Screw
265032	Safety Clutch Hook Driving Shaft Position Collar with two 201254C
201254C	" " " " " " Collar Set Screw
240519	" " Locking Lever
240520	" " " " Connecting Link
240536	" " " " Hinge Stud
200364C	" " " " " " Set Screw
265102	" " " " Spring
240641	" " " " " Stud (eccentric)
200364C	" " " " " Hinge Stud Set Screw
240538	" " Pulley with 202253 and two 200364C
202253	" " " Spring Flange
265057	" " Throw-in Latch
240522	" " " " Pin
265051	" " " " Spring
240539	Safety Clutch complete, Nos. 240519, 240520, 240522, 240536, to 240538, 265032, 265051, 265057 and 265102
241518	Take-up Lever
202399	" " Driving Stud with 244071
244071	" " " " Oil Packing (wick)
202400	" " Hinge Stud with 202423
202423	" " " " Oil Packing (wick)
200363AL	" " " " Set Screw

MACHINE NO. 111G156

240023 Tension Bracket with 201224X and 236060

200159F " " Screw

240446 " " complete, Nos. 200978X, 201199F, 204271, 223438,
223703, 223704, 223706, 267368, 240023,
two each 200309E, 201572X and 244048

244048 Tension Disc

236060 " " Position Pin

223703 " Release Lever

235576 " " " Rod

200309E " " " Screw

223704 " " Plunger

240500 " " Slide

240142 " " " Spring

204271 " " Washer

223438 " Spring

201224X " Stud

201572X " Thumb Nut

223706 Thread Controller Disc

200978X " " " Screw

267368 " " Spring

241360 " " " Stop

200132E " " " " Screw

201199F " " Stud with 204925

200061ALX " " " Set Screw

201572X " " " Thumb Nut

204925 " " Stud Washer

210954 " Guide (center)

MACHINE NO. 111G156

224040	Thread Guide (lower)
202412	" " (top of Arm)
267246	" " (upper)
200582X	" " Screw (3)
240034	" Retainer
200366X	" " Set Screw
240144	Throat Plate
691F	" " Screw (2)
240183	Vibrating Presser Bar
240184	" " " Connecting Link
240185	" " " Extension with 204264 and 240186
240186	" " " " Collar
204264	" " " " " Pin
202277	" " " Oil Packing (wick)
240188	" " " Spring
350299C	" " " Thumb Screw (pressure regulating)
240518	" " Foot, 40 needle hole, with 201015X
201015X	" " " Pinch Screw

ACCESSORIES
FOR
MACHINE NO. 111G156

200157X	Attachment Screw					
200861E	Bed Slide (back) Locking Thumb Screw					
203470	Bobbin (2)					
228476	Screw Driver (Bobbin Case)					
135x17	Needles, three each, size 20 and 22					
231337	Cloth Guide					
200861E	"	"	Thumb Screw			
224121	Drip Pan					
12361	Machine Hinge Connection (2)					
41400	"	Rest Pin (wood)				
120342	Oiler					
225498	Screw Driver					
225554	Wrench					
259462	Bobbin Winder					
228710	Knee Lifter complete					
240566	Wrench, 1/16" hex					
236955	Thread Lubricating Cup with 200059C and 350575C					
236957	"	"	"	Oil Pad (felt)		
236959	"	"	"	"	"	(upper) Reinforcing Plate
350575	"	"	"	"	"	Tension Screw Stud
222712	"	"	"	"	"	" Spring
201572X	"	"	"	"	"	" Thumb Nut
236961	"	"	"	"	"	Complete, Nos. 236957 and 236959
200059C	"	"	"	Set Screw		
236962	"	"	"	Thread Guide		

MACHINE NO. 111G156

236963 Thread Lubricating Cup Complete Nos. 201572X, 222721, 236955,
236961, 236962 and three 236957

224413 Knee Lifter Connection Lever Lifting Rod Roller Bracket
complete

