



Catalog No. 90 L

La La

LIST OF PARTS

Left and Right Hand Bag Machines

STYLES

51000 A 51100 N

The parts listed in this catalog are furnished at list prices for repairs only.

First Edition

Copyright 1942 By Union Special Machine Co. Rights Reserved In All Countries

Union Special Machine Company Chicago, U.S.A.

Printed in U.S.A.

# OFFICES, SERVICE STATIONS, FOREIGN DISTRIBUTORS

★ CHICAGO, ILL. Union Special Machine Co., 404 N. Franklin St. Main Office and Factory. T. S. Whitsel, Gen. Sales Mgr. J. W. McLain, Asst. Gen. Sales Mgr. L. C. Morris, Foreign Sales Mgr. A. E. Brauch, Manager, Technical Sales Division. Tel. Superior 6920.

2

- ALLENTOWN, PA. 1055 N. 22nd St. B. C. Mathews. Tel. 2-1330.
- ★ ATLANTA, GA. Spring at Biltmore Pl. P. T. McLendon, Mgr. Tel. Atwood 2733 and 2734
- BALTIMORE, MD. 34 S. Eutaw St. C. D. Mairs. Tel. Plaza 8499.
- ★ BOSTON, MASS. 210 South St. Wm. E. Palm, Mgr. Tel. Liberty 0147-48.
- ★ CINCINNATI, O. 422 Temple Bar Bldg. W. E. LeRoy, Mgr. Tel. Parkway 2521.
- CLEVELAND, O. 1276 W. Third St. K. D. Bear. Tel. Main 9657
- COLUMBUS, OHIO. 1669 Elmwood Ave. R. J. Lindhorst. Kingswood 5520.
- DALLAS, TEXAS. 2719 N. Haskell St. J. H. Muir. Tel. 8-1084.
- DETROIT, MICH. John Lux, 11832 Ohio
- Ave. Tel. Hogarth 5289.
  FT. WORTH, TEX. 912 Morningside Drive. H. M. Petershagen. Tel. 4-7776.
- GREENSBORO, N. C. 4109 Walker Ave. L. F. McGwier. Tel. 6301.
- GREENVILLE, S. C. 601 Cleveland St. O. S. Bachelor. Tel. 5404W.
- INDIANAPOLIS, IND. B. L. Rogers, 3731
- N. Tacoma Ave. Tel. Cherry 2521. JACKSON, MISS. M. O. Moulton, 909 Whitworth St. Tel. 2-2924.
- [OHNSON CITY, N. Y. 49 Cherry St. Wm. Browne. Tel. 7-3179.
- KANSAS CITY, MO. 3616 E. 59th St. T. O. Biggers. Tel. Highland 5797.
- LOS ANGELES, CAL. 119 E. Pico Blvd. C. E. Downs. Tel. Prospect 5636.
- MINNEAPOLIS, MINN. 3608 27th Ave. So. R. W. Bredahl. Tel. Drexel 3331.
- MONTREAL, QUE. Blvd. St. Laurent at Prince Arthur. S. J. Storey. Tel. LA 7944.
- NASHVILLE, TENN. Observatory Drive. W. J. Brauch. Tel. 8-5123.
- NEWARK, N. J. 60 Park Place. H. K. Lanning. Tel. Market 3-3123. NEW HAVEN, CONN. C. H. Verdeur,
- 500 Eastern St.
- NEW ORLEANS, LA. 312 Chartres St. I. A. Boyette. Tel. Raymond 1926.

- ★ NEW YORK, N. Y. 116 E. 27th St. Wm. Bleicher, Mgr. Tel. Murray Hill 4-4665 or 4-4666.
- ★ PHILADELPHIA, PA. 1316 Arch St. T. M. Murphey, Mgr. Tel. (Bell) Locust 1023 & 1024, (Key.) Race 1078.
- PITTSBURGH, PA. 3265 Raleigh Ave. R. G. Timm. Tel. Locust 1086.
- PORTLAND, ORE. I. C. Looper. 1903 N. E. Weidler St. Tel. Webster 1405. POTTSVILLE, PA. 20 South Center St. L. J. Perrin. Tel. 2508.
- ★ ST. LOUIS, MO. 1700 Olive St. E. E.
- Gratsch, Mgr. Tel. Chestnut 2368. ★ SAN FRANCISCO, CAL. 371 4th St. Ben W. Merz, Mgr. Tel. Garfield 7999. ★ TORONTO, ONT. 137 Wellington St.
- G. A. Rundle, Mgr. Tel. Adelaide 2909.
- UTICA, N. Y. 33 Leslie St. P. J. Steeper. Tel. 4-6422.
- WATERFORD, N. Y. 22 Fourth St. A. J. Brown. Tel. 467.
- WINNIPEG, MAN. 1065 Dominion St. Walter Baldwin. Tel. 24244.
- WORCESTER, MASS. 1 Einhorn Rd. F. E. Hodtum. Tel. 2-1412. YORK, PA. 837 Florida Ave. Wm. Den-
- holm. Tel. 64196.

## **OVERSEAS**

- AFRICA-Capetown, Durban, Johannes-burg, Port Elizabeth, South Africa. Port Louis, Mauritius. Cairo, Egypt.
- ASIA-Calcutta, India. Surabaya, D. E. I.
- ASIA MINOR-Tel Aviv, Palestine, Beirut,
- Syria. Baghdad, Iraq. Teheran, Iran. AUSTRALIA - Brisbane, Melbourne, Perth, Sydney.
- EUROPE-Leicester, London and Manchester, England. Oporto, Portugal. Dundee and Glasgow, Scotland. Bar-celona, Spain. Boras, Stockholm and Orebro, Śweden. Zurich, Switzerland. NEW ZEALAND – Auckland, Christ-
- church, Dunedin, Wellington.
- NORTH AMERICA-Havana, Cuba. Mexico City and Monterrey, Mexico. Ja-maica, B. W. I. San Juan, P. R. PACIFIC ISLANDS-Honolulu, Hawaii.
- SOUTH AMERICA-Buenos Aires, Argentina. Porto Alegre, Sao Paulo, Recife, Brazil. Santiago, Chile. Barranquilla, Bogota, Medellin, Colombia. Guayaquil, Ecuador. Lima, Peru. Montevideo, Uruguay. Caracas, Venezuela.

\*MAIN OFFICES

## FOREWORD

The one dominating idea back of "Union Special" is to build the best industrial sewing machines in the world. Our new line of high speed flat bed right and left hand bag machines in Classes 51000 and 51100, equipped with enclosed type oiling system for looper drive eccentric and crank is a pronounced achievement along these lines. All parts are made to gauges with exceedingly close limits.

It is our constant aim to furnish carefully prepared information that will enable the customer to secure all possible economies and advantages from the use of Union Specials. On the pages which follow will be found illustrations and descriptions of the parts for Styles 51000 A and 51100 N.

Additional catalogs, containing information relative to these machines, and which will be furnished on request, are listed below.

Catalog No. 29 Catalog No. 45 Catalog No. 45 A Catalog No. 89

Form 357

Accessories Manual Needle Manual Price List of Needles Instructions for installing and operating Engineering Department Adjusting Instructions. Specify the style of machine for which the Adjusting Instructions are required.

In all manufacturing centers will be found Union Special representatives, who will cooperate with those who desire in planning and estimating their requirements.

## UNION SPECIAL MACHINE COMPANY

Engineering Department

## IDENTIFICATION OF MACHINES

Each Union Special carries a style number which is stamped in the name plate on the machine. Style numbers are classified as standard and special. Those which are standard have one or more letters suffixed, but never contain the letter "Z". Example: 51100 N. Style numbers containing the letter "Z" are special. When only minor changes are made in a standard machine a "Z" is merely suffixed to the respective standard style number. Example: 51100 NZ. Styles of machines similar in construction are grouped

Styles of machines similar in construction are grouped under a class number which differs from the style numbers in that it contains no letters. Example: 51100.

#### APPLICATION OF CATALOG

This catalog applies only to the standard styles of machines as listed herein. It can also be applied with discretion to the special machines covered by these classes.

## STYLES OF MACHINES IN CLASS 51000

Enclosed Type Left Hand Flat Bed One Needle Machine

51000 A For seaming valve multi-wall paper bags, upper and under feed, stitch range 7 to 3 1/2 per inch, enclosed type oiling system for looper drive eccentric and crank, Type 947 G needle.

51000 Z A special style similar to the standard styles in Class 51000, but differing in one or more of its component parts.

#### STYLES OF MACHINES IN CLASS 51100

Enclosed Type Right Hand Flat Bed One Needle Machine

- 51100 N For seaming valve multi-wall paper bags, upper and under feed, stitch range 7 to 3 1/2 per inch, enclosed type oiling system for looper drive eccentric and crank, Type 947 G needle.
- 51100 Z A special style similar to the standard styles in Class 51100, but differing in one or more of its component parts.

-4-

#### NEEDLES

## TYPE NUMBERS AND SIZES

Each needle has a type number and size number. The former denotes the kind of shank, point, length, groove, finish, and other details. The latter denotes the largest diameter of the blade, measured in thousandths of an inch midway between the shank and eye, and is stamped in the needle shank. Collectively, the type number and size number is the complete symbol.

To have orders promptly and accurately filled, the empty package, a sample needle, or the type and size numbers should be given. See marks on packages. An intelligent order would read as follows: "1000 Needles Type 947 G Size 073". The type number of the needles most commonly used in the styles of machines covered by this catalog is listed below. Set opposite the type number is the description of the needle.

> Type No.

#### Description

947 G

Round shank, spear point, long, double groove, ball eye, spotted, chromium plated- sizes 067, 073, 080.

## ORDERING REPAIR PARTS

#### PLATES

Illustrations of parts similar in appearance, and, to some extent, component parts of the same subdivision of the mechanism, are grouped according to scale.

When a part is made in two or more sizes, usually only one illustration is shown. In ordering these parts, the additional information requested under these illustrations such as, "specify length" or "specify size", must be furnished.

#### LIST OF PARTS

The list of parts describes each part and its principal uses. Always check the symbol against its description before ordering. It is not necessary to furnish the plate number.

When a part is used, or can be used, in all machines covered by this catalog, no specific use is mentioned in the description.

For convenience in ordering, minor parts such as screws, nuts, and similar articles are repeated after each major part.

(-) A dash in the "plate number" column of the list of parts denotes the absence of an illustration.

(‡) A double dagger in the "symbol to order by" column denotes that the component parts cannot be furnished separately. Due to the high speed of these machines it is impossible for these associated parts to be fitted a second time and make a serviceable job.

## ORDERING REPAIR PARTS (Continued)

### IDENTIFYING PARTS

Where the construction permits, each part is stamped with its part number. Some of the smaller parts are stamped with an identification letter to distinguish them from parts similar in appearance.

All part numbers represent the same part, regardless of the catalog in which they appear.

#### SUPPLIES

All supplies, including taps, reamers, belting, belt hooks, belt fasteners, screw drivers, wrenches and powdered oil stone will be promptly furnished.

### USE GENUINE NEEDLES AND REPAIR PARTS


Success in the operation of these machines can be secured only by the use of genuine Union Special Needles and Repair Parts as furnished by the Union Special Machine Company, its subsidiaries and authorized distributors. Obviously, it is to our interest to maintain the reputation of Union Specials by furnishing the very best goods obtainable. They are designed according to the most approved engineering principles, and are made with the utmost precision.

Genuine needles are put up in packages marked at the top "Trade 'UNION SPECIAL' mark". Genuine repair parts are stamped with a reproduction of the well known two padlocks with a link connecting the shackles.

#### TERMS .

Prices are strictly "net cash" and subject to change without notice. All shipments are forwarded at the buyer's risk f.o.b. shipping point. Parcel post shipments are insured unless otherwise directed. A charge is made to cover the postage and insurance.











и.































· · · · ·





Symbol to to Order RyThe figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Prices furnished on application.Plate No.8 WA15Feed Rocker Shaft-139Stop Watch			LIST OF PARTS	
<ul> <li>WA15 Stop Watch - 113</li> <li>18 Looper Connecting Rod Nut, right thread; also for Nos. 51041, 51841 D - 17</li> <li>20 Feed Crank Stud Washer, right - 17</li> <li>20 M Feed Crank Stud Washer, right - 4</li> <li>36 G Washer, for looper conceting rod ball joint assemblies Nos. 51041 C, 51841 4</li> <li>47 Frame Needle Thread Eyelet (screw No. 98 A) - 6</li> <li>54 Hand Tally 6</li> <li>55 A Hand Tally - 1000 to 8000 R.P.M 8</li> <li>76 M eedle Clamp Nut - 6</li> <li>77 M for attaching customer's gear to pilley; also for No. 51228 V - 4</li> <li>76 To Tower needle lever link pin; also for No. 51286 A - 6</li> <li>77 M for lower needle lever link pin - 3</li> <li>76 Screw, for feed crank link pin; also for No. 51286 A - 7</li> <li>77 S A " for lower needle lever link pin - 3</li> <li>80 Screw, for looper rocker cone; also for No. 51246 A - 3</li> <li>81 Sort Screw, for noeper rocker shaft sleeve- 3</li> <li>82 Screw, for looper rocker shaft sleeve- 3</li> <li>83 Screw, for looper rocker frame; also for No. 41046 D 3</li> <li>84 A Set Screw, for presser foot - 3</li> <li>85 Screw, for looper rocker frame; also for No. 41046 D 3</li> <li>86 Screw, for looper rocker frame; also for No. 41046 D 3</li> <li>87 Screw, for looper rocker frame; also for No. 41046 D 3</li> <li>88 A Set Screw, for presser foot - 3</li> <li>89 Screw, for looper rocker frame; also for No. 41046 D 3</li> <li>90 Screw, for looper rocker frame; also for No. 41046 D 3</li> <li>91 Clamp Screw, for looper rocker frame; also for No. 51042 C</li></ul>		to	to the plates illustrating the parts and are not to be used in ordering. Prices	
20       Pressure pump Oil Can, 1 1/2 pints capacity - 17         20       Feed Crank Stud Washer, left; also for Nos.         36 G       Washer, for looper connecting rod ball joint         35 A       Frame Needle Thread Eyelet (screw No. 98 A) - 6         54       Frame Needle Thread Eyelet (screw No. 98 A) - 6         54       Needle Lever Link - 9         73 A       Screw, for looper 3         73 A       Screw, for looper 3         74       " for attaching customer's gear to pulley; also for No. 51236 A 3         75 A       " for lower needle lever link pin - 3         76       Set Screw, for looper drive levers; also for No. 51236 A 3         77       Set Screw, for looper drive levers; also for No. 51236 A 3         78       " " for lower needle lever link pin - 3         80       Screw, for looper drive levers; also for No. 51236 A 3         81       Spot Screw, for looper drive levers; also for No. 5124 B 3         82       Screw, for looper rocker cone; also for No. 14649		WA15	Stop Watch	
<ul> <li>20 M</li> <li>20 M</li> <li>Feed Crank Stud Washer, right4</li> <li>36 G</li> <li>Washer, for looper connecting rod ball joint assemblies Nos. 51041 C, 512414</li> <li>52 A</li> <li>Frame Needle Thread Eyelet (screw No. 98 A) - 6</li> <li>Meedle Lever Link4</li> <li>TA55 A</li> <li>Hand Tachometer, 2000 to 8000 R.P.M4</li> <li>Set Screw, for looper needle guard3</li> <li>74 " for attaching customer's gear to pulley; also for No. 51242 V4</li> <li>75 A " for lower needle lever connecting rod bearing4</li> <li>77 Set Screw, for feed crank link pin; also for No. 51266 A3</li> <li>80 Screw, for looper needle lever link pin3</li> <li>81 Spot Screw, for looper drive levers; also for No. 51042 B, 51242 K3</li> <li>82 Screw, for looper rocker cone; also for No. 41046 D3</li> <li>83 A</li> <li>84 A Set Screw, for presser foot3</li> <li>85 Screw, for looper rocker shaft sleeve3</li> <li>86 B</li> <li>87 for No. 21102 B3</li> <li>87 for looper rocker frame; also for No. 41046 D3</li> <li>89 Screw, for looper rocker frame; also for No. 41046 D3</li> <li>80 Screw, for looper rocker frame; also for No. 51051 G3</li> <li>81 Screw, for looper rocker frame; also for No. 51051 G3</li> <li>83 Screw, for looper rocker frame; also for No. 51051 G3</li> <li>84 A Sct Screw, for looper rocker frame; also for No. 51051 G3</li> <li>85 Screw, for looper rocker frame; also for Nos. 5205 Q, 29105 T, 51025, 51142,3</li> <li>86 Screw, for looper connecting rod ball joints; also for No. 51243 C3</li> <li>87 A Screw, for looper rocker frame; also for Nos. 29105 Q, 29105 T, 51025, 51135 N, K60323, K603253</li> <li>88 A Screw, for frame thread eyelets3</li> <li>89 Fension Disc3</li> <li>80 Srew, for frame thread eyelets3</li> <li>81 A Screw, for fr</li></ul>			Feed Crank Stud Washer, left: also for Nos	
<ul> <li>52 A Frame Needle Thread Eyelet (screw No. 98 A) - 6</li> <li>54 Frame Needle Thread Eyelet (screw No. 98 A) - 9</li> <li>75 A Hand Tally 9</li> <li>75 A Hand Tachometer, 2000 to 8000 R.P.M 8</li> <li>76 Needle Clamp Nut</li></ul>			Feed Crank Stud Washer, right-	
<ul> <li>TA55 A Hand Tachometer, 2000 to 8000 R.P.M</li></ul>		54	Frame Needle Thread Eyelet (screw No. 98 A) Needle Lever Link	6
<pre>74 "for looper needle guard</pre>		56 73	Hand Tachometer, 2000 to 8000 R.P.M	4
<ul> <li>75 A</li> <li>77 Set Screw, for feed crank link pin; also for No. 51236 A</li> <li>78 " for lower needle lever link pin</li> <li>78 Set Screw, for looper needle lever link pin</li> <li>79 Spot Screw, for looper drive levers; also for Nos. 51042 B, 51242 K</li> <li>88 Serew, for looper rocker cone; also for No. 14649</li> <li>88 A Set Screw, for needle bar</li> <li>89 Screw, for looper rocker shaft sleeve</li> <li>80 Screw, for looper rocker shaft sleeve</li> <li>81 Spot Screw, for presser foot</li> <li>82 Screw, for looper rock shaft arm; also for No. 41046 D</li> <li>83 Clamp Screw, for looper rock shaft arm; also for No. 2102 B</li> <li>84 Set Screw, for looper rock shaft arm; also for No. 2102 B</li> <li>85 Screw, for looper rock shaft arm; also for No. 51051 G</li> <li>86 Screw, for looper rocker frame; also for Nos. 529105 Q, 29105 T, 51023, 51142, 51142 A, K56749</li> <li>86 Screw, for looper connecting rod ball joints; also for No. 51216 A</li> <li>87 A Screw, for looper rocker frame; also for Nos. 29105 Q, 29105 T, 51035, 51135 N, K60323, K60325</li> <li>88 A Screw, for frame thread eyelets</li> <li>88 A Screw, for frame thread eyelets</li> <li>89 A Screw, for frame thread eyelets</li> <li>80 For needle clamp</li> </ul>		74	" for attaching customer's gear to	3
<ul> <li>Set Screw, for feed crank link pin; also for No. 51236 A</li> <li>80 Screw, 33/64 inch long, for cloth plate</li> <li>81 Spot Screw, for looper drive levers; also for Nos. 51042 B, 51242 K</li> <li>88 Screw, for looper rocker cone; also for No. 14649</li> <li>88 A Set Screw, for needle bar</li> <li>88 Screw, for looper rocker shaft sleeve</li> <li>89 Screw, for looper rocker shaft sleeve</li> <li>80 Screw, for looper rocker shaft sleeve</li> <li>81 Clamp Screw, for presser foot</li> <li>82 Screw, for needle bar</li> <li>83 Screw, for looper rock shaft arm; also for No. 41046 D</li> <li>84 Clamp Screw, for looper rocker frame; also for No. 41046 D</li> <li>85 Screw, for looper rocker frame; also for No. 51051 G</li> <li>86 Screw, for looper rocker frame; also for Nos. 29105 Q, 29105 T, 51023, 51142, 51142 A, K56749</li> <li>87 A Screw, for looper rocker frame; also for Nos. 51243 C</li> <li>87 A Screw, for looper rocker frame; also for Nos. 5126 A</li> <li>87 A Screw, for looper rocker frame; also for Nos. 29105 Q, 29105 T, 51025, 51142, 51142 A, K56749</li> <li>88 A Screw, for looper rocker frame; also for Nos. 29105 Q, 29105 T, 51035, 51135 N, K60323, K60325</li> <li>88 A Screw, for frame thread eyelets</li> <li>88 A Screw, for frame thread eyelets</li> <li>89 A Screw, for frame thread eyelets</li> <li>80 B Screw, for frame thread eyelets</li> <li>81 Screw, 9/32 inch opening, for needle clamp</li> </ul>		75 A	" for lower needle lever connecting rod	Ŧ
<ul> <li>78 " " for lower needle lever link pin</li></ul>			Set Screw, for feed crank link pin; also for No. 51236 A	
<ul> <li>Screw, for looper rocker cone; also for No. 14649</li></ul>		80	" " for lower needle lever link pin Screw, 33/64 inch long, for cloth plate Spot Screw, for looper drive levers: also for	3
<ul> <li>88 A Set Screw, for needle bar</li></ul>		88	Screw, for looper rocker cone: also for	
<ul> <li>91</li> <li>93</li> <li>93</li> <li>94</li> <li>95</li> <li>95</li> <li>95</li> <li>96</li> <li>96</li> <li>97</li> <li>97</li> <li>96</li> <li>97</li> <li>98</li> <li>98</li> <li>98</li> <li>98</li> <li>99</li> <li>99</li> <li>91</li> <li>90</li> <li>91</li> <li>91</li> <li>92</li> <li>93</li> <li>94</li> <li>95</li> <li>96</li> <li>96</li> <li>97</li> <li>98</li> <li>98</li> <li>99</li> <li>99</li> <li>90</li> <li>91</li> <li>91</li> <li>92</li> <li>93</li> <li>94</li> <li>95</li> <li>96</li> <li>97</li> <li>98</li> <li>98</li> <li>99</li> <li>99</li> <li>90</li> <li>91</li> <li>91</li> <li>92</li> <li>93</li> <li>94</li> <li>95</li> <li>95</li> <li>96</li> <li>96</li> <li>97</li> <li>98</li> <li>98</li> <li>99</li> <li>99</li> <li>90</li> <li>90</li> <li>90</li> <li>91</li> <li>91</li> <li>91</li> <li>92</li> <li>94</li> <li>95</li> <li>95</li> <li>96</li> <li>97</li> <li>98</li> <li>98</li> <li>98</li> <li>99</li> <li>99</li> <li>90</li> <li>90</li> <li>90</li> <li>91</li> <li>91</li> <li>91</li> <li>92</li> <li>94</li> <li>95</li> <li>95</li> <li>96</li> <li>97</li> <li>97</li> <li>98</li> <li>98</li> <li>98</li> <li>99</li> <li>99</li> <li>99</li> <li>90</li> <li>90</li> <li>90</li> <li>91</li> <li>91</li> <li>91</li> <li>92</li> <li>94</li> <li>94</li> <li>95</li> <li>95</li> <li>96</li> <li>97</li> <li>97</li> <li>98</li> <li>98</li> <li>98</li> <li>98</li> <li>99</li> <li>99</li> <li>99</li> <li>99</li> <li>90</li> <li>90</li> <li>90</li> <li>90</li> <li>90</li> <li>90</li> <li>90</li> <li>90</li> <li>91</li> <li>91</li> <li>92</li> <li>94</li> <li>94</li> <li>95</li> <li>95</li> <li>96</li> <li>97</li> <li>98</li> <li>98</li> <li>98</li> <li>98</li> <li>99</li> <li>99</li> <li>99</li> <li>99</li> <li>99</li> <li>90</li> <li>90</li> <li>90</li> <li>90</li> <li>90</li> <li>91</li> <li>91</li> <li>92</li> <li>94</li> <li>94</li> <li>95</li> <li>96</li> <li>96</li> <li>97</li> <li>98</li> <li>98</li> <li>98</li> <li>98</li> <li>98</li> <li>99</li> <li>99</li> <li>99</li> <li>99</li> <li>90</li> &lt;</ul>		88 B	Set Screw, for needle bar	3 3
<ul> <li>95</li> <li>96</li> <li>96</li> <li>96 Spot Screw, for looper rocker frame; also for Nos. 29105 Q, 29105 T, 51023, 51142, 51142 A, K56749-</li> <li>97</li> <li>97 Screw, for needle lever ball stud fork; also for No. 51243 C-</li> <li>97 A</li> <li>98 Screw, for looper connecting rod ball joints; also for No. 51216 A -</li> <li>98 Set Screw, for looper rocker frame; also for Nos. 29105 Q, 29105 T, 51035, 51135 N, K60323, K60325 -</li> <li>98 A</li> <li>98 Screw, for frame thread eyelets-</li> <li>97 A</li> <li>98 A</li> <li>98 Descrew, for frame thread eyelets-</li> <li>99 A</li> <li>99 B</li> <li>90 B&lt;</li></ul>			Clamp Screw, for presser foot	3 3
<ul> <li>96</li> <li>96</li> <li>97 Spot Screw, for looper rocker frame; also for Nos. 29105 Q, 29105 T, 51023, 51142, 51142 A, K56749-</li> <li>97 Screw, for needle lever ball stud fork; also for No. 51243 C-</li> <li>97 A</li> <li>97 Screw, for looper connecting rod ball joints; also for No. 51216 A -</li> <li>98 Set Screw, for looper rocker frame; also for Nos. 29105 Q, 29105 T, 51035, 51135 N, K60323, K60325 -</li> <li>98 A</li> <li>98 Screw, for frame thread eyelets-</li> <li>3 3</li> <li>98 A</li> <li>98 M</li> <li>98 A</li> <li>98 M</li> <li>98 A</li> <li>99 B</li> <li>99 B</li> <li>90 B</li> <li>90 B</li> <li>90 B</li> <li>90 B</li> <li>90 B</li> <li>90 B</li> <li>91 Disc -</li> <li>91 Disc -</li> <li>92 C</li> <li>93 C</li> <li>94 A</li> <li>95 C</li> <li>95 C</li> <li>96 A</li> <li>97 A</li> <li>98 A</li> <li>99 B</li> <li>90 B</li> <li>91 C</li> <li>91 C</li> <li>92 C</li> <li>93 C</li> <li>94 C</li> <li>94 C</li> <li>95 C</li> <li>96 C</li> <li>97 A</li> <li>98 A</li> <li>99 B</li> <li>99 B</li> <li>99 B</li> <li>90 B</li> <li>90 B</li> <li>90 B</li> <li>90 B</li> <li>90 C</li> <li>90 B</li> <li>91 C</li> <li>91 C</li> <li>92 C</li> <li>93 C</li> <li>94 C</li> <li>94 C</li> <li>95 C</li> <li>96 C</li> <li>97 A</li> <li>98 A</li> <li>99 A</li> <li>99 A</li> <li>99 A</li> <li>99 A</li> <li>99 A</li> &lt;</ul>		95	Screw, for main shaft collar; also for No.	3
<ul> <li>97</li> <li>97 Screw, for needle lever ball stud fork; also</li> <li>97 A</li> <li>97 A</li> <li>98 Screw, for looper connecting rod ball joints; also for No. 51216 A</li></ul>		9 <b>6</b>	Spot Screw, for looper rocker frame; also for Nos. 29105 Q, 29105 T, 51023, 51142	3
<ul> <li>97 A Screw, for looper connecting rod ball joints; also for No. 51216 A</li></ul>		97	Screw, for needle lever ball stud fork: also	
<ul> <li>98</li> <li>98</li> <li>98 Set Screw, for looper rocker frame; also for Nos. 29105 Q, 29105 T, 51035, 51135 N, K60323, K60325</li></ul>		97 A	Screw, for looper connecting rod ball joints.	3
98 A 109 B 116 Wrench, 9/32 inch opening, for needle clamp		1	Set Screw, for looper rocker frame; also for Nos. 29105 Q, 29105 T, 51035, 51135 N.	3
wrench, 9/32 inch opening, for needle clamp			Screw, for frame thread evelets	33
	_		Wrench, 9/32 inch opening, for needle clamp	

LIST OF PARTS

-25-

1 B 1		LIST OF PARTS	
2	Symbol to Order By	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Prices furnished on application.	Plate No.
	<b>V</b> 118	Tap, marked "X-2", for plus size cloth plate screw No. 22521	7
	187 A	Screw, for crankshaft chamber cover oil drip plate, also for Nos. 51082 D, 51282 N	3
	258 A 269	Looper Rocker Cone Nut; also for No. 35833 A Looper Connecting Rod Nut, left thread; also	4
	402	for Nos. 51036, 51136 E	4 3 15
	¥500-257	Expansion Reamer, for needle bar bearings, size .257 inch	16
	¥502-319	" " for upper presser bar bear- ing, size .319 inch	16
	¥503-319	" " for lower presser bar bear- ing, size .319 inch	16
	¥505-407	" " for looper rocker and feed rocker shaft bearings, size	16
· · ·	¥506-530	" "	16
	538 627	Screw, for supporting feed dog	33
	650 A-18	Clamp Screw, for looper drive lever rocker Stove Bolt, flat head, 5/16 x 2 inches " " flat head, 5/16 x 2 1/2 inches	4 4
	652-16 666-13	Washer, 1/4 inch	4
	666-19	" " for needle lever connecting rod bearing	7 7
	666-28 666-29	Oil Cup, for needle lever stud (nut No.12987A) Felt Wick, for needle lever stud	7 13
]	666-77 666-82	Constant Level Oiler	11 7
	668-1 668-14	avoid eccentric oil wick	4
	719	eyelet	4
	¥802	51250 B	3
	906 A	crank pins Adjusting Screw, for upper feed dog (nut No. 907)	16 4
	907 1280	Adjusting Screw Lock Nut, for upper feed Tilting Feed Dog Holder Lock Nut	4 4 4
	1286	Feed Crank Link Pin Assembly; one each Nos. 1286 A, 1286 B, 12964 C, 22560	7
	1286 A	Feed Crank Link Pin; also needle lever link pin (screw No. 77)	7
	1286 B 6042 A	Feed Crank Link Pin Spring (screw No. 22560) Tilting Feed Dog Holder Washer, also for No.	6
		55235 D	4

LIST OF PARTS

-26-

LIST OF PARTS

er;

		LIST OF PARTS	
2	Symbol to Order By	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Prices furnished on application.	Plate No.
2	8372 A 12538	Looper Drive Ball Joint Locking Stud Washer Looper Connecting Rod and Ball Joint Assem-	4
4	12964 C 12987 A	Feed Crank Link Pin Ball	4 4
	14649 15430 C 15430 D	Feed Rocker Shaft Collar (screw No. 88) Needle Lever Connecting Rod Nut, left thread	4 13 4 4
	15465 F 21102 B 21104 B-18	Looper Rocker Cone (screw No. 88, nut No. 258 A)	6 17
	21104 B-24	also horizontal spool seat rod (screw No. 22509)	14
	21104 C 21104 D 21104 E 21104 G	Thread Stand Rod Connection (screw No.22509) Thread Stand Spool Seat-	14 8 17 8
anza (internet) (internet) Anzai (internet)	21104 G 21105 J 21114 A 21127	" " " " " " " " " " " " " " " " " " "	17 7 17
	21145 21201	No. 22580) Cone, wood, for thread stand	17 8
and the second secon	21202	overall, 11 1/4 inches	16 16
	21203 21204	overall 15 1/2 inches	16
	21204 21205 A	overall 15 inches-	16
	21207	overall 14 inches	16
	21210 21217 A	Looper Collar, .040 inch thick Thread Stand Thread Guide Rod Support (screw No. 22591)	8 4
	21225-5/32	Looper Adjusting Gauge, 5/32 inch measure-	7 7
2	21227 HK	Steel Insert Replacement Tool Set, for assembling insert No. 668-1 and ferrule	i
٤	21260	No. 668-14 in tension thread eyelet. Ferrule should always be replaced Emery Cord, 3/64 inch diameter, grade No.	8
2	21260 A	120, fifty yard spool	
ан сараан ал ал ан			

-27-

LIST OF PARTS

24

=		LIST OF PARTS	
-	Symbol to	The figures in the last column refer only to the plates illustrating the parts and	Plate No.
	Order By	are not to be used in ordering. Prices furnished on application.	
	21260 B	Emery Cord, 1/32 inch diameter, grade No. 180, fifty yard spool	
	21260 C	" " .025 inch diameter, grade No. 200, fifty yard spool	
	21260 D	Emery Tape, 3/32 inch wide, grade No. 180, fifty yard spool	
	21260 E	Emery Cord, .018 inch diameter, grade No. 200, fifty yard spool	
	21355	Chair Leg Extension, 4 inches long	8
	21388	Wrench. single end, 3/8 inch opening	8
	21388 F	" offset, for adjusting the stitch length	17
	21388 N	double end, 3/16 and 5/16 inch openings	8
	21388 R	<pre>double end, 3/16 and 5/16 inch openings double end, 3/8 and 1/2 inch openings</pre>	8
	21388 X	" for main shaft bearing housing	17
	21388 Z	Wrench, for setting needle lever stud correctly	
	21000 2	with respect to oil groove. Stud is set	
		correctly when the pin hole nearest the	
	· ·	periphery is up and a line drawn between the	
		two pin holes is 45 degrees to the right of	
	01 204	the vertical	8
	21394	Utility Grinder, including emery wheel, 5	
		inches diameter, 1/4 inch face, round belt	
		drive, recommended speed 3000 R.P.M	
	21394 G	drive, recommended speed 3000 R.P.M Emery Wheel, 5 inches diameter, 1/4 inch face,	
		3/8 inch hole, grade "M" emery 60	
	21394 Н	" " 5 inches diameter, 1/2 inch face,	
		3/8 inch hole, grade "M" emery 60	
	21394 K	3/8 inch hole, grade "M" emery 60 Utility Grinder, including emery wheel, 5 inches diameter, 1/2 inch face, round belt	
		drive, recommended speed 3000 R.P.M	
	21657 E	Cast-off Wire Support Washer	4
	22509	Set Screw, square head, cup point, 5/16 inch	
		diameter, 18 threads per inch, 1/2 inch long,	
		for thread stand rod connection	4
	22513	Screw, for presser bar connection guide plate	3
	22519 C	Clamp Screw, for feed rocker arm	3
	22521	Screw, plus size, for cloth plate (tap No.V118)	3
	22524	" countersunk head, for oil reservoir top	0
	~~~~		3
	00500	COVER	8
	22528	ior cast-orr write support, arso for hos.	7
	00570 4	K42774, 51005 A, 51026 A, 51243 B,K58615	
	22539 A	Plug Screw, for looper drive lever shaft hole	3
	22559 A	Bearing Screw, lower, for looper drive connec-	_
		tion	3
	22559 B	" " upper, for looper drive connec-	
		tion	4
	22560	Screw, for feed crank link pin spring	3
	22560 B	" for presser bar guide; also for Nos.	
	22000	51034, 51134 B	3
	22561	" for stitch regulator indicator	
			3 3 3
	22569 B	" for main shaft bushing housing	Ð
	22570	" fillister head, for throat plates	17

LIST OF PARTS

Symbol to Order By	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Prices	Plate No.
	furnished on application.	
22571 A	Plug Screw, for spring pressed felt wicks on main shaft bearings; also for oil drain	
22580	hole in main oil reservoir	3
22585 A	Screw, fillister head, for oil reservoir top	3 3
22585 B 22591	Screw, for needle rear guard	3
22593	Screw, for looper thread cast-off guide wire; also for No. 51158 D	3
22595 22597 22597 A	Screw, for needle lever link pin oil tube Spot Screw, for pulley	3 3
22733 A	Set Screw, for pulley	- 3 3
22747 22799 F	Screw, for needle lever thread eyelet Locating Screw, for stitch regulator index washer	3
22801 22829	Pivot Screw, for needle rear guard	3
22834 22837 22839	Screw, for regulating needle rear guards Thumbscrew, for face plate	3 3
22840 22848	Adapter Screw, for frame thread eyelet Screw, for oil reservoir back cover; also for No. 51070, 51170 E, 51758	3 3 3
22849	Screw, right, for upper crank chamber cover; also for Nos. 51093 C. K59292	3
22850 22863 22864	Stud, for hand lifter	4 3
22872	Plug Screw, for lower tension post hole on Style 51100 N	4
22882 A	Clamp Screw, for looper drive levers Nos. 51042, 51242 N	4
28604 G	Straight Mineral Oil, S.A.E. 10 "W" put up in 10 fluid ounces to can, which is the capa- city of machine	~
28606-1/2 28606-1	Powdered Oil Stone, 1/2 lb. package	
29066 F	Needle Lever Connecting Rod Upper Bearing Assembly; one each Nos. 51216 A. 51243 B-	10
\$29105 Q	Looper Drive Eccentric Assembly, includes eccentric No. 51343, for Style 51100 N (set screw No. 98, spot screw No. 96, bearing	
	screw, upper, No. 22559 B, bearing screw,	10

.... a Sect

nin April a 

LIST OF PARTS

··· .			_
Symbo to Order		The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Prices furnished on application.	Plate No.
<b>‡</b> 29105	T	Looper Drive Eccentric Assembly, includes eccentric No. 51043, for Style 51000 A (set screw No. 98, spot screw No. 96, bearing screw, upper, No. 22559 B, bearing screw, lower, No. 22559 A)	10
29192		Looper Rocker Assembly, for Style 51100 N; one each Nos. 51213, 15465 F, 51745 lapped to-	
29192	J	gether, Nos. 258 A, 22829; two No. 88 Looper Rocker Assembly, for Style 51000 A; one each Nos. 51013, 15465 F, 51745 lapped to-	10
29348	D	gether, Nos. 258 A, 22829; two No. 88 Needle Lever Assembly, for Style 51100 N; one each Nos. 51215 C, 51250 lapped together.	10
29348	E	Nos. 54, 78, 22864, 35759, 51250 C; two each Nos. 88 A, 1286, 22528- Needle Lever Assembly, for Style 51000 A; one each Nos. 51015, 51250 lapped together, Nos.	14
<b>\$</b> 29476	AK	54, 78, 22864, 35759, 51250 C; two each Nos. 88 A, 22528, 51054	14
		cludes crankshaft No. 51322 A (bearing screw No. 75 A)	14
+29476	DA	Crankshaft Assembly, for Style 51000 A, in- cludes crankshaft No. 51022 A (bearing screw No. 75 A)	14
35731		Presser Bar Connection Guide Plate (screw No. 22513)	
35733 35759	В	Presser Spring Regulating Screw Lock Nut Needle Bar Connection (needle bar set screw No.	4
35768 35833 35833	A	88 A, link pin set screw No. 78) Screw, left, for upper crank chamber cover Presser Spring Regulating Stud (nut No. 258 A) Presser Spring Plate	2 3 7 9
39236 41046 K42774		Needle Rear Guard Washer	4 7
K43502		adjusting screw nut No. 907)	1
51001 51005	A	Cloth Plate, for Style 51000 A (screw No. 80) Feed Dog, lower, for Style 51000 A (screw No. 22528)	1 17
51008 51010		Looper, for Style 51000 A (screw No. 73) Looper Needle Guard, for Style 51000 A (screw No. 73 A)	1 2
51013 \$51015		Looper Rocker, for Style 51000 A Needle Lever, includes bushing, for Style 51000 A	2 10
51020	A	Presser Foot, for Style 51000 A (clamp screw No. 91)	14 1
\$See Pa	.ge	5 -30-	

Se J

LIST OF PARTS

		LIDI UF PARIS	
	Symbol	The figures in the last column refer only	Plate
	to	to the plates illustrating the parts and	No.
	Order By	are not to be used in ordering. Prices	NO.
	Older by	furnished on application.	
		idinished on apprication.	
	51021	Pullow (anot comer No. SOFOR and	
	01001	Pulley (spot screw No. 22597, set screw No.	
	51022	22597 A, gear attaching screw No. 74)	10
	51022	Main Shaft, right section, for Style 51000 A	14
	STORS	Looper Thread Take-up, for Style 51000 A (spot	ł
	F1004 4	screw No. 96, set screw No. 22580)	10
	51024 A	Throat Plate, for Style 51000 A (screw No.	
		22570)	1
	51025 A	Needle Rear Guard, for Style 51000 A (screw	
		No. 22585 B, washer No. 39236 A)	2
	51026 A	Upper Feed Dog, for Style 51000 A (attaching	
		screw No. 22528, adjusting screw No. 906 Å,	
		adjusting screw nut No. 907)	1
	<b>\$51034</b>	Feed Bar, lower, including tiltable feed dog	1 -
		holder, for Style 51000 A (set screw No.	
		22560 B, feed dog supporting screw No. 538,	
		feed dog holder No. 51134 G, holder adjust-	
		ing screw No. 22863, holder nut No. 1280.	
		holder washer No. 6042 A)	0
	51034 A	Feed Bar Shaft	9 13
	51034 L	Feed Bar, upper, for Style 51000 A	13
مراجع الأراح	51034 M	Upper Feed Bar Arm, for Style 51000 A (pin No.	9
		41046 D, pin screw No. 90)	
1997 - 1997 1997 - 1997	51034 N	Upper Feed Bar Spring, for Style 51000 A	9
1. St. 1.	51035	Feed Rocker, .562 inch diameter stem, for	9
	01000	Style 51000 A (screw No. 98)	3.0
	51035 A	Feed Bocken Ann. 561 inch diamater $h_{1}$	10
a de la composición d Composición de la composición de la comp	JICOU A	Feed Rocker Arm, .561 inch diameter hole, for	,
1997 - 1998 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 -		Style 51000 A (locking stud No. 55235 D,	
at di	1	locking stud washer No. 6042 A, locking stud nut No. 55235 E)	-
1.1.2.2.2.3	51036	Food (reply Stud (sub No. 900)	9 2
. · · · ·	\$51041	Feed Crank Stud (nut No. 269)	2
	+OTOTT	Looper Connecting Rod Ball Joint Assembly,	
		right, for Style 51000 A equipped with loop-	
		er drive lever No. 51242 V (bearing screw	
	\$51041 C	No. 97 A, nut No. 18)	2
	*01041 C	Looper Connecting Rod, jointed section and	
•		ball joint assembly, for Style 51000 A	
		equipped with looper drive lever No. 51242 V	
		(ball stud washer No. 36 G, bearing screw	
		No. 97 A, jointed section sleeve No. 51240B,	
		sleeve spring No. 51240 C)	10
	51041 D	Looper Connecting Rod, jointed section and	
		ball joint assembly, with .232 inch diameter	
		shoulder on ball stud, for Style 51000 A	
		equipped with looper drive lever No. 51042	
		(ball stud washer No. 51741 E, bearing screw	
		No. 97 A, jointed section sleeve No. 51240B.	
		sleeve spring No. 51240 C)	10
+	51041 E	Looper Connecting Rod Ball Joint Assembly,	10
		right, for Style 51000 A equipped with loop-	
	1	er drive lever No. 51042 (bearing screw No.	
		97 A, nut No. 18)	2
		,	- <b>N</b>
		· · · · · · · · · · · · · · · · · · ·	
-	See Page		

LIST OF PARTS

Symbol toThe figures in the last column refer to to the plates illustrating the parts a are not to be used in ordering. Price furnished on application.51042Looper Drive Lever, steel, with .232 to to	
to to the plates illustrating the parts a Order By are not to be used in ordering. Price furnished on application.	only Plate
Order By are not to be used in ordering. Price furnished on application.	
furnished on application.	
	30
51049 Joopon Drive Leven steel with 929	
- DIUGA I LOUDER DELVE DEVER, SLEEF, WILD JOAN -	inch diame-
ter reamed hole for ball stud, clam	ning lug on
right, for Style 51000 A (spot screw	
clamp screw No. 22882 A) $   -$	· · ·
51042 A Looper Drive Lever Shaft, for Style 5	9
equipped with looper drive lever No.	
clamp screw No. 627)	9
51044 Looper Rocker Frame, for Style 51000 A	
screw No. 96, set screw No. 98)	10
51051 Presser Bar Guide, for Style 51000 A (	
22560 B)	2
51051 G Upper Feed Dog Lifter (screw No. 95) -	9
51054 Needle Lever Link Pin (clamp screw for	r upper
link pin No. 22864, clamp screw nut	No.51250C,
set screw for lower link pin No. 78)	) 7
51057 Cast-off Wire Support, for Style 51000	D A (screw
No. 22528, washer No. 21657 E)	13
No. 22528, washer No. 21657 E) 51058 Needle Lever Thread Eyelet, for Style	51000 A
(screw No. 22747)	6
51070 Frame Needle Thread Guide Wire, for St	tvle
51000 A (screw No. 22848, washer No.	. 20) 6
51080 Throat Plate Support, for Style 51000	A (screw
No. 22839)	14
51080 A Throat Plate Support Pin	
51082 A Crankshaft Chamber Cover, upper, for S	13
51002 A Crankshart Chamber Cover, upper, for 3 51000 A (attaching screw, right, No.	22240
attaching conow left. No. 75000	, 22049,
attaching screw, left, No. 35768 A,	
51082 B Crankshaft Chamber Cover Oil Drin Plat	15
Style 51000 A (screw No. 187 A)	11
51082 C   Oil Reservoir Top Cover, for Style 510	A 000
(screw, countersunk head, No. 22524, fillister head, No. 22585 A, gasket	, screw,
fillister head, No. 22585 A, gasket	No.51282 M 15
51082 D   Oil Reservoir Top Cover Oil Drip Plate	e, for
Style 51000 A (screw No. 187 A)	11
51082 E   Oil Reservoir Back Cover, for Style 51	
(screw No. 22848)	15
$= 51007 \qquad $	<b>Io.</b> 22850) 8
51083   Hand Lifter, for Style 51000 A (stud N	DO A 10
51085 Stitch Regulator Index, for Style 5100	
51085 Stitch Regulator Index, for Style 5100	-1. insert
51085 Stitch Regulator Index, for Style 5100 51092 Tension Thread Eyelet (insert No. 668-	-1, insert
51085 51092 Stitch Regulator Index, for Style 5100 Tension Thread Eyelet (insert No. 668- ferrule No. 668-14)	-1, insert
51085Stitch Regulator Index, for Style 510051092Tension Thread Eyelet (insert No. 668- ferrule No. 668-14)51093Looper Rocker Stud Oil Tube (screw No.	-1, insert 6 22829,
51085Stitch Regulator Index, for Style 510051092Tension Thread Eyelet (insert No. 668- ferrule No. 668-14)51093Looper Rocker Stud Oil Tube (screw No. coupling No. 61294 X)	-1, insert 6 . 22829, 12
51085Stitch Regulator Index, for Style 510051092Tension Thread Eyelet (insert No. 668- ferrule No. 668-14)51093Looper Rocker Stud Oil Tube (screw No. coupling No. 61294 X)51093 AFeed Rocker Oil Tube, also feed lift a	-1, insert 6 . 22829, 12 and looper
<ul> <li>51085</li> <li>51092</li> <li>51093</li> <li>51093 A</li> <li>51094 A</li> <li>51094 A</li> <li>510</li></ul>	-1, insert 6 22829, 12 and looper 51000 A
<ul> <li>51085</li> <li>51092</li> <li>51093</li> <li>51093 A</li> <li>Feed Rocker Oil Tube, also feed lift a avoid eccentric oil tube, for Style (coupling No. 61294 X)</li></ul>	-1, insert 6 22829, 12 and looper 51000 A 11
<ul> <li>51085</li> <li>51092</li> <li>51093</li> <li>51093 A</li> <li>51093 A</li> <li>51093 A</li> <li>51093 B</li> <li>510</li></ul>	-1, insert 22829, 
<ul> <li>51085</li> <li>51092</li> <li>51093</li> <li>51093 A</li> <li>51093 A</li> <li>51093 B</li> <li>51093 B</li> <li>51093 B</li> <li>51093 B</li> <li>51093 A</li> <li>51093 B</li> <li>51093 B</li> <li>51093 B</li> <li>51093 B</li> <li>51093 B</li> <li>51093 A</li> <li>51093 B</li> <li>510</li></ul>	-1, insert 22829, 
<ul> <li>51085</li> <li>51092</li> <li>51093</li> <li>51093 A</li> <li>51093 A</li> <li>51093 B</li> <li>51093 B</li> <li>51093 C</li> <li>51093 C</li> <li>51093 C</li> <li>51093 C</li> <li>51093 A</li> <li>51093 B</li> <li>51093 C</li> <li>510</li></ul>	-1, insert 22829, and looper 51000 A 11 1000 A (nut 12 12
<ul> <li>51085</li> <li>51092</li> <li>51093</li> <li>51093 A</li> <li>51093 A</li> <li>51093 B</li> <li>51093 B</li> <li>51093 B</li> <li>51093 B</li> <li>51093 A</li> <li>51093 B</li> <li>51093 B</li> <li>51093 B</li> <li>51093 B</li> <li>51093 B</li> <li>51093 A</li> <li>51093 B</li> <li>510</li></ul>	-1, insert 22829, 

-32-

â		LIST OF PARTS	
:	Symbol to Order By	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Prices furnished on application.	Plate No.
	51093 D	Right Main Shaft Bearing Oil Tube (coupling No. 61294 X)	
	51104 D	Looper Thread Cast-off Guide Wire (screw No. 22593)	12
	51108 D 51110 D	Looper, for Style 51100 N (set screw No. 73)- Looper Needle Guard, for Style 51100 N (screw No. 73 A)	10 2
4	51115	Needle Lever, includes bushing, for Style 51100 N	2
:	51134 B	Feed Bar, including tiltable feed dog holder, for Style 51100 N (set screw No. 22560 B, feed dog supporting screw No. 538, feed dog holder No. 51134 G, holder adjusting screw No. 22863, holder nut No. 1280, holder washer	14
	51134 G	NO. 6042 A)	9
	51134 L 51134 M	Feed Bar, upper, for Style 51100 N	6 9
	51134 N 51135 N	Upper Feed Bar Spring, for Style 51100 N Feed Rocker, .562 inch diameter stem, for Style 51100 N (screw No. 98)	
	51135 P	Feed Rocker Arm, .562 inch hole, for Style 51100 N (locking stud No. 55235 D, locking stud washer No. 6042 A, locking stud nut No.	10
ы 4 	51136	55235 E)	9
	51136 E 51142 51142 A 51145	No. 22799 F)	4 2 5 5
	51147 51158 D 51158 E 51170 E	eccentric link- Main Shaft Collar (screw No. 95)- Looper Thread Take-up Eyelet (screw No. 22593) Needle Lever Thread Eyelet (screw No. 22747)- Frame Needle Thread Guide Wire, for Style	2 4 6 6
	51183 51185 D 51186 D 51190 D 51192 B 51192 G	51100 N (screw No. 22848, washer No. 20) Hand Lifter, for Style 51100 N (stud No. 22850) Stitch Regulator Index, for Style 51100 N " " Indicator (screw No. 22561) Main Shaft Bearing Housing Gasket Tension Post Ferrule Tension Thread Eyelet (steel insert No. 668-1,	6 8 10 6 15 4
	51193 U	insert ferrule No. 668-14)	6 19
	51213 51216	Looper Rocker, for Style 51100 N Needle Lever Connecting Rod Tube (nut, left thread, No. 15430 C, nut, right thread, No. 15430 D)	12
+ (	See Page		13

---

د. مورد م

n Alban Amsola Albana

· · · · · · · · · · · · · · · · · · ·	LIST OF PARTS	
Symbol to Order By	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Prices furnished on application.	Plate No.
51216 A	Needle Lever Connecting Rod Bearing, upper	
51217 51225	(screw No. 97 A)	
51235 G	No. 22585 B, washer No. 39236 A) Feed Rocker Arm Clamp Screw Washer	2 4
51236 A	Feed Lift Eccentric Link Pin and Looper Avoid Eccentric Link Pin (screw No. 77)	* 7
\$51236 E	Feed Crank Link Assembly	2
51236 F 51240 A	Feed Crank Link Ferrule	5
51240 B	(nut, right thread, No. 18, nut, left thread, No. 269)	7
TOTOTO D	Sleeve	6
51240 C	Looper Connecting Rod Jointed Section Sleeve Spring	
<b>\$</b> 51241	Looper Connecting Rod, jointed section, and ball joint assembly, right, for Style 51100 N equipped with looper drive lever	6
	No. 51242 V (ball stud washer No. 36 G, bearing screw No. 97 A, jointed section sleeve No. 51240 B, sleeve spring No. 51240 C)	10
\$51241 D	Looper Connecting Rod Ball Joint Assembly, left, for Style 51100 N equipped with	10
\$51241 G	<pre>looper drive lever No. 51242 V (bearing screw No. 97 A, nut No. 18) Looper Connecting Rod, jointed section, and ball joint assembly, with .232 inch diam-</pre>	2
	eter shoulder on ball stud, for Style 51100 N equipped with looper drive lever No. 51242 N (ball stud washer No. 51241E, bearing screw No. 97 A, jointed section sleeve No. 51240 B, sleeve spring No.	
	51240 Č)	10
51242 H	Looper Drive Lever Shaft, for machines equipped with looper drive lever No. 51242 V	1 🕫
51242 K	Looper Drive Lever Rocker, for Style 51100 N (spot screw No. 81, clamp screw No. 627)	13
51242 L-595	Looper Drive Lever Rocker Thrust Washer,	9
51242 L-600	.0595 inch thick Looper Drive Lever Rocker Thrust Washer, .0600 inch thick	4
51242 L-605	Looper Drive Lever Rocker Thrust Washer,	4
51242 L-610	.0605 inch thick	4
51242 L-615	.0610 inch thick Looper Drive Lever Rocker Thrust Washer, .615 inch thick	4 4
<b>‡See Page 5</b>	-34-	

LIST OF PARTS

**‡See Page 5** 

24

21

		LIST OF PARTS	
2	Symbol to Order By	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Prices furnished on application.	Plate No.
4	51242 L-620 51242 M 51242 N	<ul> <li>Looper Drive Lever Rocker Thrust Washer, .620 inch thick</li> <li>Looper Drive Lever Clamp Screw Washer</li> <li>Looper Drive Lever, steel, with .232 inch diameter reamed hole for ball stud, clamping lug on left, for Style 51100 N</li> </ul>	4 4
	51242 P	(spot screw No. 81, clamping screw No. 22882 A)	9 13
	51242 Q 51242 R 51242 S 51242 V	Looper Drive Lever Shaft Bushing, front """"""""""""""""""""""""""""""""""	5 5 5 5
	51243 B 51243 C	Looper Drive Lever Ball Stud, also for Nos. 51015, 51115 (clamp screw No. 22528)	9
	51245 C	Looper Drive Lever Ball Stud Guide Fork, also for No. 51216 A (screw No. 97) Looper Rocker Frame, for Style 51100 N	6
	51244 A 51244 B 51244 C	(spot screw No. 96, set screw No. 98) Looper Rock Shaft	10 13 2 5
	51244 E 51250 51250 A 51250 B 51250 C 51254 51254 A 51257 D 51282 B 51282 E	" " " " " " " " " " " " " " " " " " "	5 4 13 5 5 4 5 5 11
	51282 F	51100 N (attaching screw, right, No. 22849, attaching screw, left, No. 35768A) Crankshaft Chamber Cover Oil Drip Plate, for Style 51100 N (screw No. 187 A)	15 11
	51282 L 51282 M 51282 N 51282 R	Oil Reservoir Top Cover Gasket Oil Reservoir Top Cover Oil Drip Plate, for Style 51100 N (screw No. 187 A) Oil Reservoir Back Cover, for Style 51100 N	15 15 11
_	51282 S	Oil Peremutin Deals Q Q i i	15

-35-

			LIST OF PARTS	
	Symi to Orden	0	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Prices furnished on application.	Plate No.
		_		
	51282	T	Crankshaft Chamber Cover, right, for Style	
			51100 N and left, for Style 51000 A (screw No. 90)	11
	51282	U	Crankshaft Chamber Cover Gasket	11.
	51290	_	Main Shaft Bushing, inner right, 3/4 inch	
			long, for Style 51000 A, also inner left	
	E1900	٨	bushing for Style 51100 N	5
	51290	A	Main Shaft Bushing, outer left, 1 9/32 inch long, for Style 51000 A; also outer right	
			bushing for Style 51100 N	5
	51290	D	Main Shaft Bushing, right, 3/4 inch long, for	
			Style 51000 A; also left bushing for Style	
	51900	F	51100 N	5 5
3	51290 51290		Main Shaft Bushing, middle	Э
	FOT 200	-	(screw No. 22569 B)	9
	51292		Tension Post	7
	51292		" Regulating Nut	4
	51292	' <b>F</b> '1	Tension Spring, .016 inch diameter wire, for	<u> </u>
	51292	F-2	looper thread	6
	UTNON	1 -2	looper thread	6
	51292	F-8	".037 inch diameter wire, for	Ū
			needle thread	6
	51292	F-14	" ".047 inch diameter wire, for	
	51293	М	needle thread Looper Rocker Stud Oil Tube, for Style	6
	01000	1 6	51100 N (screw No. 22829, coupling No.	
			61294 X)	12
	51293	Q	Left Main Shaft Bearing Oil Tube, for Style 51100 N (coupling No. 61294 X)	
	51294	ਸ਼ਾ	0il Tube Coupling, for attaching oil tubes	12
	01604	т.	to oil reservoir	7
	51722		Main Shaft, left section, for Style 51100 N	14
	51741	E	Washer, for looper connecting rod ball joint	
	517745		assemblies Nos. 51041 D, 51241 G	4
	51745 51751		Looper Rocker Cone Stud	6 2
	51758		Frame Needle Thread Eyelet, intermediate	
			(attaching screw No. 22848, adapter screw	
	F0074	37	No. 22840, washer No. 20)	6.
	52834	N	Looper Drive Ball Joint Locking Stud Nut	4
	52841 52882	E	Upper Crank Chamber Cover Gasket	7 15
	52887	-	Presser Spring (locating screw No. 35768 A)	13
	52887	G	" " Rest	6
	52888		" Bar	13
	52889	ъ	" " Bushing, upper	5
	55235	U	Feed Rocker Arm Locking Stud, for Nos. 51035 A, 51135 P	7
	55235	E	Feed Rocker Arm Locking Stud Nut	4
		-		T
	See Pa	900 F	-36-	
		~~~ U	-00-	

LIST OF PARTS


**‡**See Page 5

-36-

LIST OF PARTS

-		LIST OF PARTS	
_	Symbol to Order By	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Prices furnished on application.	Plate No.
	\$55241 N	Looper Connecting Rod Ball Joint Assembly, left, for Style 51100 N equipped with looper drive lever No. 51242 N (bearing screw No.	
К	56749	97 A, nut No. 18)	2
K	(56750	screw No. 96, set screw No. 22580) Cast-off Wire Support, for Style 51100 N	10
K	56755	(screw No. 22528, washer No. 21657 E) Throat Plate Support, for Style 51100 N (screw	13
K	56760	No. 22839)	14
K	58614	51100 N	5
К	58615	22570)	1
. K	59048	22528)	1
K	59292	Needle Lever Link Pin Oil Tube, for Style 51100 N (screw, right, No. 22595, screw,	11
	59837 60323	Cloth Plate, for Style 51100 N (screw No. 80) Feed Rocker, with .470 inch diameter stem, for	12 17
۲. دروبا با ا	60324	Style 51100 N (screw No. 98)	10
K	60325	Feed Rocker, with .470 inch diameter stem, for	9
K	60326	Feed Rocker Arm, with .468 inch diameter hole, for Style 51000 A (clamp screw No. 22519 C, clamp screw washer No. 51235 G)	10
	61294 X	Coupling, for oil line tubes	9 4
		-37-	
	s .		

i i de la composición de la composición




ANALYSIS OF COMPARATIVE SEWING COSTS

This form offers a simple method for you to determine the effect of modern, high speed machines on your production and overhead costs. To use it, merely fill in the started items. Any Union Special representative will supply the necessary information on the improved machine which will enable you to complete the record.

-39-





# WORLDWIDE SALES AND SERVICE

Union Special Corporation maintains sales and service facilities throughout the world. These offices will aid you in the selection of the right sewing equipment for your particular operation. Union Special Corporation representatives and service technicians are factory trained and are able to serve your needs promptly and efficiently. Whatever your location, there is a qualified representative to serve you. Brussels, Belgium Charlotte, N.C. El Paso, TX Hong Kong, China Huntley, IL Leicester, England Lille, France Miami, FL Milan, Italy Möglingen, Germany Montreal, Quebec Osaka, Japan Santa Fe Springs, CA

Other Representatives throughout all parts of the world.



